

[Manuals.plus](#) /

› [Devoko](#) /

› Devoko Patio Furniture Set DVCH250953-8BG Instruction Manual

Devoko DVCH250953-8BG

Devoko Patio Furniture Set Instruction Manual

Model: DVCH250953-8BG

1. INTRODUCTION

This manual provides essential instructions for the assembly, operation, maintenance, and safety of your Devoko 3-piece outdoor patio furniture set. Please read this manual thoroughly before assembly and use, and retain it for future reference.



Image: The Devoko patio furniture set, featuring two swivel rocking chairs and a coffee table, placed on a porch. A woman and a man are seated, and a child is playing nearby. This image illustrates the typical use of the furniture set in an outdoor home environment.

2. SAFETY INFORMATION

Caution:

This furniture has a swivel feature. To prevent tip-over, do not let children play on or around the chairs. Always keep the chairs on a stable, level surface. Inspect the furniture regularly for any signs of wear or damage, and follow the manufacturer's instructions for proper maintenance and storage.

- Ensure all bolts and screws are securely tightened before use.
- Do not exceed the weight capacity of the chairs (300 lbs per chair) or the table (150 lbs).
- Keep furniture away from open flames or extreme heat sources.
- Avoid placing sharp objects directly on the wicker or table surface to prevent damage.

3. SETUP AND ASSEMBLY

The Devoko patio furniture set requires assembly. All necessary hardware and tools are included in the

package. Please follow the step-by-step instructions provided with your product for a smooth assembly process. Assembly typically takes approximately 30 minutes.

1. Unpack all components and verify against the parts list in your product manual.
2. Place all components on a soft, clean surface to prevent scratches during assembly.
3. Attach the chair bases to the chair seats, ensuring all bolts are aligned and tightened securely.
4. Assemble the coffee table by attaching the legs to the tabletop and then the lower shelf.
5. Once assembled, gently test the stability of each piece before full use.



Image: A diagram showing the dimensions of the Devoko swivel rocking chair and the coffee table. The chair measures 27.9 inches wide, 22.2 inches deep, and 37.4 inches high, with a weight capacity of 300 lbs. The side table measures 19.9 inches wide, 18.7 inches deep, and 22.4 inches high, with a weight capacity of 150 lbs. This image is crucial for understanding the physical size and capacity of the furniture.

4. OPERATING INSTRUCTIONS

Your Devoko patio furniture set is designed for comfort and versatility in outdoor spaces.

4.1 Swivel and Rocking Chairs

The chairs feature a 360° swivel and a gentle rocking motion for enhanced relaxation. To use:

- **Swivel:** Simply rotate the chair in any direction. The smooth mechanism allows for effortless turning.
- **Rocking:** Lean back gently to initiate the rocking motion. The design provides a comfortable and soothing glide.



Image: A diagram illustrating the 360-degree swivel and back-and-forth glide (rocking) functionality of the chairs. It highlights the sturdy base frame that supports these movements, ensuring stability and durability.

4.2 Coffee Table

The coffee table provides a convenient surface for drinks, snacks, or decorative items. It features a premium wooden top and an additional lower shelf for extra storage.



Premium Wooden Top for Outdoor Leisure

Image: A close-up of the Devoko coffee table, showcasing its premium wooden top and an additional lower shelf for storage. A person is reaching for a glass of orange juice on the table, which also holds a basket of fruit and sunglasses on the lower shelf. This image demonstrates the table's functionality and storage capacity.

5. MAINTENANCE AND CARE

To ensure the longevity and appearance of your Devoko patio furniture set, follow these maintenance guidelines:

- **Cleaning:** The UV-resistant PE wicker and rust-proof steel frame can be wiped clean with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The cushions are made with splash-proof fabric. For deeper cleaning, remove covers if possible and follow care instructions on the label. Allow to air dry completely before re-use.
- **Protection:** While designed for all-weather durability, covering the furniture during prolonged periods of harsh weather (heavy rain, snow, intense sun) or when not in use can extend its lifespan.
- **Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if necessary.



Image: An image highlighting key features of the Devoko patio furniture, including the high rebound sponge cushions for comfort, wide armrests for support, and the all-weather PE rattan construction for durability. This image emphasizes the quality materials used in the furniture's design.

6. TROUBLESHOOTING

If you encounter any issues with your Devoko patio furniture set, please refer to the following common solutions:

- **Wobbly Chair/Table:** Ensure all assembly bolts are securely tightened. Check that the furniture is placed on a flat, level surface.
- **Stiff Swivel/Rocking:** Over time, the swivel mechanism might require lubrication. Apply a silicone-based lubricant to the moving parts if needed. Ensure no debris is obstructing the mechanism.
- **Fading Wicker:** While UV-resistant, prolonged exposure to intense sunlight can still cause some fading. Consider using furniture covers when not in use to minimize exposure.
- **Cushion Discoloration:** Clean cushions regularly as per maintenance instructions. For stubborn stains, a specialized outdoor fabric cleaner may be used, following product directions carefully.

7. SPECIFICATIONS

Feature	Detail
Brand	Devoko
Model Number	DVCH250953-8BG
Color	Brown
Material Type	Alloy Steel (Frame), PE Wicker, Fabric Cushions
Item Weight	83.11 Pounds (Total Set)
Chair Dimensions	27.9 x 22.2 x 37.4 inches (L x W x H)
Table Dimensions	19.9 x 18.7 x 22.4 inches (L x W x H)
Chair Weight Capacity	300 lbs per chair
Table Weight Capacity	150 lbs

Feature	Detail
Assembly Required	Yes
Included Components	2 chairs and 1 table

8. WARRANTY INFORMATION

Specific warranty details for the Devoko Patio Furniture Set (Model DVCH250953-8BG) are typically provided with the product packaging or can be obtained directly from the manufacturer. Please refer to the documentation included with your purchase for comprehensive warranty terms and conditions. Retain your proof of purchase for any warranty claims.

9. CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Devoko Patio Furniture Set, please contact Devoko customer support. Contact information is usually available on the product packaging, the manufacturer's official website, or through the retailer where the product was purchased. When contacting support, please have your model number (DVCH250953-8BG) and proof of purchase readily available.