

[Manuals.plus](#) /

› [KXAITO](#) /

› KXAITO 8105 Men's Sports Watch User Manual

KXAITO 8105

KXAITO 8105 Men's Sports Watch User Manual

Model: 8105

INTRODUCTION

Thank you for choosing the KXAITO 8105 Men's Sports Watch. This manual provides detailed instructions for the proper setup, operation, and maintenance of your watch. Please read this manual carefully to ensure optimal performance and longevity of your device.



Image: Front view of the KXAUTO 8105 Men's Sports Watch.

PRODUCT OVERVIEW

The KXAUTO 8105 is a multi-functional digital watch designed for sports and outdoor activities. It features a durable, lightweight design with a high-contrast LED display for clear readability.

Key Features:

- **Ultra-Light Design:** Weighs only 49g for all-day comfort.
- **Multi-Functionality:** Includes 1/100s chronograph, 12/24h time, date/week display, hourly chime, and dual alarms.
- **LED Backlight:** Ensures clear visibility in low-light conditions.
- **Water Resistance:** Rated for 50 meters (5ATM), suitable for swimming and showering (not for hot water or diving).
- **Shock-Resistant:** Designed for durability in active environments.

Watch Components:




Image: KXAUTO 8105 watch with labeled buttons (LIGHT, MODE, START, RESET) and display sections (Week, Date, Time, Alarm).

The watch features four primary buttons: **LIGHT** (top left), **MODE** (bottom left), **START** (top right), and **RESET** (bottom right). These buttons are used to navigate modes and adjust settings.




Image: Detailed view of watch components including high-definition mirror, multi-function buttons, shockproof structure, stainless steel back cover, TPU strap, and stainless steel clasp.

SETUP

Initial Time and Date Setting:

1. In normal time display mode, press the **MODE** button repeatedly until the seconds begin to flash. This indicates you are in setting mode.
2. Press the **RESET** button to cycle through the setting options: seconds, hour, minute, month, date, day of the week.
3. Use the **START** button to adjust the flashing value. For example, to set the hour, press **START** to advance the hour.
4. Once all settings are correct, press the **MODE** button to exit the setting mode and return to normal time display.

12/24 Hour Format:

While in time setting mode (seconds flashing), press the **LIGHT** button to toggle between 12-hour (AM/PM) and 24-hour formats.

Activating Luminous Function:

The watch features luminous hands and calibration. For optimal glow, expose the watch to a light source for a period to charge the luminous material.

OPERATING INSTRUCTIONS

Mode Switching:

Press the **MODE** button to cycle through the different functions: Normal Time Display → Stopwatch → Alarm Setting → Time Setting.

Stopwatch Function:

1. From normal time display, press **MODE** once to enter Stopwatch mode. The display will show '00:00:00'.

2. Press **START** to begin timing.
3. Press **START** again to pause timing.
4. Press **RESET** to reset the stopwatch to '00:00:00'.
5. To record split times, press **RESET** while the stopwatch is running. The display will show the split time. Press **RESET** again to return to the running stopwatch.

Alarm Setting:

1. From normal time display, press **MODE** twice to enter Alarm setting mode. The hour digits will flash.
2. Press **START** to adjust the hour.
3. Press **RESET** to switch to minute setting. The minute digits will flash.
4. Press **START** to adjust the minutes.
5. Press **MODE** to confirm the alarm setting and exit.

Alarm ON/OFF and Hourly Chime:

In Alarm setting mode, press **START** and **RESET** simultaneously to toggle the alarm ON/OFF. An alarm icon will appear/disappear on the display. Press **RESET** to toggle the hourly chime ON/OFF. A chime icon will appear/disappear.

LED Backlight:

Press the **LIGHT** button at any time to illuminate the display for a few seconds. This provides instant clarity in low-light conditions.

Dual Time Display:

The watch supports dual time display. To set the second time zone, navigate to the dual time mode (usually after alarm mode) by pressing **MODE**. Then use **RESET** and **START** buttons to adjust the time similar to the main time setting.

Your browser does not support the video tag.

Video: Demonstration of KXAUTO 8105 watch features, including water resistance and backlight function.

MAINTENANCE

Water Resistance:

The KXAUTO 8105 watch is water-resistant to 50 meters (5ATM). This means it is suitable for recreational swimming and showering. However, it is not recommended for diving or prolonged submersion. Avoid pressing buttons underwater, as this can compromise the water seal.

Cleaning:

Clean the watch case and strap regularly with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly. Avoid harsh chemicals or abrasive materials.

Battery Replacement:

The watch is powered by a standard watch battery. When the display becomes dim or the watch stops functioning, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.

TROUBLESHOOTING

Watch Not Functioning:

- Check if the battery needs replacement.
- Ensure no buttons are stuck in a pressed position.

Display is Dim or Hard to Read:

- The battery may be low and require replacement.
- Ensure you are using the LED backlight in low-light conditions by pressing the **LIGHT** button.

Water Inside the Watch:

- Immediately stop using the watch.
- Take it to a professional watch repair service as soon as possible to prevent further damage.

SPECIFICATIONS

PRODUCT SIZE PARAMETER

KXAITO

Electronic Watch



Length of watch
9.6 inch / 24cm

Diameter of case
1.8inch / 4.6cm

Case thickness
0.6 inch / 1.60 cm

Strap width(Band width)
0.86 inch / 2.2 cm

Weight 1.73oz / 49g

PS: Adjustable Strap Fit 14-23 cm/5.5-9 inch

Image: Diagram showing the dimensions of the KXAITO 8105 watch.

Feature	Detail
Model Name	8105
Brand	KXAITO
Movement Type	Japanese Quartz
Display Type	Digital
Case Material	Polycarbonate
Band Material	Thermoplastic Polyurethane (TPU)
Clasp Type	Buckle
Water Resistance Depth	50 Meters (5ATM)
Case Diameter	46 Millimeters
Case Thickness	16 Millimeters
Band Width	22 Millimeters
Band Length	254 Millimeters
Item Weight	2 Ounces (49g)
Additional Features	Chronograph, LED Backlight, Dual Time Display, Shock-Resistant, Alarm, Stopwatch

WARRANTY AND SUPPORT

This product comes with standard manufacturer support. For any issues not covered in this manual, or for warranty claims, please contact the seller directly through your purchase platform. Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question