

VGR YS-V477

VGR 477 7-in-1 Hot Air Multi-Styler Instruction Manual

Model: YS-V477

1. INTRODUCTION

Thank you for choosing the VGR 477 7-in-1 Hot Air Multi-Styler. This versatile styling tool is designed to dry, straighten, curl, and add volume to your hair with professional results. Featuring advanced BLDC motor technology, ionic care, and precise temperature control, it offers a superior styling experience. Please read this manual carefully before use to ensure safe and optimal operation.

2. SAFETY INSTRUCTIONS

To reduce the risk of electric shock, burns, fire, or injury, always follow these basic safety precautions:

- Do not use this appliance near water.
- Always unplug the appliance immediately after use.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If the appliance falls into water, unplug it immediately. Do not reach into the water.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.


- Do not use an extension cord with this appliance.
 - Do not direct hot air towards eyes or other heat-sensitive areas.
 - Attachments may be hot during use. Allow them to cool before handling.
 - Clean the air filter regularly to maintain optimal performance.
-

3. PACKAGE CONTENTS


Your VGR 477 Multi-Styler package includes:

- 1 x VGR 477 Main Unit
- 1 x 65x45 mm Oval Volumizing Brush
- 1 x 40 mm Round Brush
- 1 x Left Auto-Wrap Curler
- 1 x Right Auto-Wrap Curler
- 1 x Concentrator Nozzle
- 1 x Diffuser
- 1 x Anti-Frizz Attachment

Bigoudis Automatiques



Avant



Après

Aspire et enroule automatiquement les cheveux, température constante
coiffage complet des cheveux bouclés

Image: The VGR 477 main unit is shown alongside its seven interchangeable attachments, including various brushes, curlers, and nozzles.

4. PRODUCT FEATURES

- **7-in-1 Multifunction Styling Kit:** Combines drying, straightening, curling, and volumizing with interchangeable attachments.
- **Powerful BLDC Motor:** 110,000 rpm digital motor (1200-1400 W) for fast and gentle styling, reducing drying time by up to 50%.
- **Precise Control with LED Display:** Real-time display of heat and airflow.
- **4 Temperature Settings:** Adjustable from 30°C to 120°C for various hair types and styles.
- **3 Speed Settings:** Customizable airflow levels.
- **Cool Shot Button:** Instantly sets hairstyles for a lasting finish.
- **Ionic Technology:** Releases millions of negative ions to reduce frizz, static, and preserve hair hydration, promoting smoother, shinier, and healthier hair.
- **Innovative Cooling System:** Protects sensitive hair and sets style.

- **Ergonomic Design:** 360° swivel cord (2m) for freedom of movement and a rotary selector for easy mode switching.
- **Removable Air Filter:** Protects the motor from dust and extends appliance lifespan.



Image: The VGR 477 Multi-Styler is shown with text indicating its 110,000 RPM BLDC motor and 1200-1400W power, emphasizing its fast drying capabilities.



Image: A visual representation of the VGR 477's ionic technology, showing how negative ions reduce frizz and enhance hair shine and hydration.

5. SETUP

Attaching and Detaching Attachments

1. Ensure the appliance is unplugged and cool before attaching or detaching any accessories.
2. To attach an accessory, align the attachment with the main unit's connection point and push firmly until it clicks into place.
3. To detach an accessory, press the release button (if present) or twist gently and pull the attachment away from the main unit.

6. OPERATING INSTRUCTIONS

General Operation

1. Plug the appliance into a suitable power outlet.
2. Press the power button to turn on the multi-styler. The LED display will illuminate.
3. Use the temperature control button to select one of the 4 temperature settings (30°C, 60°C, 90°C, 120°C).
4. Use the speed control button to select one of the 3 airflow speeds.
5. For a lasting finish, press the Cool Shot button to deliver a burst of cool air.
6. After use, press the power button to turn off the appliance and unplug it.

The advertisement features a woman with long brown hair using a blue and black hair dryer. She is smiling and looking upwards. Surrounding her head are several blue spheres with molecular structures inside, and yellow flower-like icons. To the right, there are two images of the back of a head with long brown hair. The top image is labeled 'Avant' and shows frizzy hair. The bottom image is labeled 'Après' and shows smooth, shiny hair.

Technologie ionique

Générateur d'ions négatifs

Avant

Après

Image: A close-up of the VGR 477 Multi-Styler's control panel, showing the LED display, power button, temperature and speed selection buttons, and the cool shot button.

Using the Attachments

Ensure hair is towel-dried before styling, unless using a specific attachment for wet hair.

- **Oval Volumizing Brush (65x45 mm):**

Use this brush to add volume and shape to your hair. Work in sections, lifting hair at the roots for maximum volume.

- **Round Brush (40 mm):**

Ideal for creating soft waves and curls, or for smoothing and shaping ends. Wrap sections of hair around the brush and gently pull through.

- **Auto-Wrap Curlers (Left & Right):**

These attachments use the Coanda effect to automatically wrap hair around the barrel. Hold a section of hair near the barrel, and it will automatically attract and wrap the hair. Use the left curler for curls facing left and the right curler for curls facing right, or alternate for a natural look. Hold for a few seconds, then use the cool shot to set the curl.



Image: Step-by-step instructions demonstrating how to use the automatic curling attachments to create curls.

- **Concentrator Nozzle:**

Directs airflow for targeted drying and precise styling, ideal for smoothing hair before using other attachments or for quick drying specific sections.

- **Diffuser:**

Designed to enhance natural curls and waves, reducing frizz and adding volume. Use on damp hair, gently cupping sections of hair in the diffuser.

- **Anti-Frizz Attachment:**

Helps to smooth down flyaways and reduce frizz for a sleek finish. Use on dry hair, gliding the attachment over the surface of your hair.

Vent à 3 Vitesses

4 Niveaux de Température




Image: The VGR 477 Multi-Styler is shown with the diffuser attachment for curly hair and the concentrator attachment for smooth hair.

Peigne Multifonctionnel

LE PEIGNE VOLUMISANT DE FORME OVALE SÈCHE LES CHEVEUX RAPIDEMENT TOUT EN PERMETTANT DE RÉALISER DIFFÉRENTES COIFFURES.



Peigne ovale volumisant



Sèche-cheveux anti-vibrations



Brosse ronde



Image: The VGR 477 Multi-Styler is displayed with the oval volumizing brush and round brush attachments, demonstrating their use for adding volume and shaping hair.

7. MAINTENANCE

Cleaning the Air Filter

Regular cleaning of the air filter is crucial for maintaining the appliance's performance and extending its lifespan.

1. Ensure the appliance is unplugged and completely cool.
2. Locate the removable air filter at the bottom of the main unit.
3. Twist or pull to remove the filter cover.
4. Gently clean any accumulated dust, lint, or hair from the filter using a soft brush or cloth.
5. Reattach the filter cover securely.

General Cleaning

- Wipe the main unit and attachments with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure all parts are completely dry before storing or using again.
- Store the appliance and its attachments in a dry, safe place.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; internal fault.	Ensure plug is securely inserted. Test outlet with another device. If problem persists, contact support.
Weak airflow or overheating.	Blocked air filter; blocked air intake/outlet.	Clean the air filter as described in the Maintenance section. Ensure air intake/outlet are clear.
Hair not curling/styling effectively.	Incorrect temperature/speed setting; hair too wet/dry; incorrect technique.	Adjust temperature/speed. Ensure hair is damp for curling attachments. Review operating instructions for proper technique.
Excessive frizz.	Hair too dry; high humidity; not using ionic technology effectively.	Ensure hair is not overly dry. Use the ionic technology feature. Consider using the anti-frizz attachment.

9. SPECIFICATIONS

- **Model Number:** YS-V477
- **Power:** 1200-1400 W
- **Motor Speed:** 110,000 rpm (BLDC Motor)
- **Temperature Settings:** 4 (30°C, 60°C, 90°C, 120°C)
- **Speed Settings:** 3
- **Cord Length:** 2 meters (360° swivel)

- **Dimensions (L x W x H):** 43 x 5 x 5 cm
- **Weight:** 2.4 kg
- **Material:** Metal
- **UPC:** 702103662245
- **Country of Origin:** China

10. WARRANTY AND SUPPORT

Your VGR 477 Multi-Styler comes with a **1-year warranty** from the date of purchase. We also offer a **30-day refund policy** and **24-hour customer support** for any inquiries or issues you may encounter.

For warranty claims, technical assistance, or general support, please contact VGR Direct through your purchase platform or visit the official VGR website for contact information.



Image: An infographic detailing VGR's customer service offerings, including a 30-day refund, 1-year warranty, and 24-hour support.