

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DWVO](#) /

› [DWVO LED Lift Top Coffee Table MADWVeL2se Instruction Manual](#)

DWVO MADWVeL2se

DWVO LED Lift Top Coffee Table Instruction Manual

Model: MADWVeL2se

		Safety Information	Package				
Contents	Assembly	Operation	Maintenance	Troubleshooting	Specifications	Support	

1. SAFETY INFORMATION

Please read and understand all instructions before beginning assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Keep all small parts and packaging materials away from children.
- Assemble the product on a soft, clean surface to prevent scratches.
- Ensure all connections are secure before using the table.
- Do not stand or sit on the table.
- Avoid placing excessively heavy items on the lift top or inside the storage compartments.
- Exercise caution when operating the lift top mechanism to prevent pinching.
- Do not expose the LED lights or electrical components to water or excessive moisture.
- Regularly check all fasteners to ensure they remain tight.

2. PACKAGE CONTENTS

Verify that all components are present before assembly. If any parts are missing or damaged, contact customer support.

- Tabletop Panel (1)
- Base Frame Components (various)
- Lift Mechanism Hardware (2 sets)
- Drawer Components (4 sets)
- LED Light Strip (1)
- Remote Control for LED (1)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Assembly Guide (1)

PRODUCT SIZE




Figure 2.1: Diagram showing the dimensions of the DWVO LED Lift Top Coffee Table, including overall height, width, depth, and internal storage measurements. The table measures 35.4 inches wide, 21.7 inches deep, and 16.1 inches high when closed. The lift top extends to a higher position for dining or working.

3. ASSEMBLY INSTRUCTIONS

Assembly typically requires two people and a screwdriver. Follow the included assembly guide for detailed, step-by-step instructions. Ensure all parts are correctly oriented before tightening fasteners.

- 1. Prepare Workspace:** Clear a spacious area and lay out all components on a soft surface to prevent damage.
- 2. Assemble Base Frame:** Connect the side panels and support beams using the provided hardware. Do not overtighten.
- 3. Install Drawer Slides:** Attach the drawer slides to the internal sections of the base frame according to the guide.
- 4. Assemble Drawers:** Construct the four drawers and install their respective slides. Insert the assembled drawers into the base frame.
- 5. Attach Lift Mechanism:** Secure the lift top mechanisms to the base frame and the underside of the tabletop. Ensure smooth operation before proceeding.
- 6. Install Tabletop:** Carefully align and attach the tabletop to the lift mechanisms.
- 7. Apply LED Strip:** Adhere the LED light strip to the designated area, typically within the open storage compartment. Connect the power cable.

8. **Final Check:** Verify that all screws and connections are tight and the table is stable. Test the lift top mechanism and drawers for smooth movement.

COFFEE TABLE



COFFEE TABLE WITH LIFT TOP



HIDDEN STORAGE COFFEE TABLE



Figure 3.1: Visual representation of the coffee table in its standard position, with the lift top raised, and with the hidden storage compartment and drawers open, demonstrating its versatile functionality.

4. OPERATING INSTRUCTIONS

4.1 Lift Top Mechanism

The table features a smooth lift-and-lower mechanism for adjustable height. To operate:

- **To Raise:** Gently pull the front edge of the tabletop upwards. The spring-assisted mechanism will smoothly lift the top to its elevated position.
- **To Lower:** Apply gentle downward pressure on the tabletop. Guide it back into the lowered position, ensuring no objects are obstructing its path.



Figure 4.1: The coffee table with its lift top extended, providing a comfortable surface for working or dining while seated on a sofa.



Figure 4.2: Detail of the robust spring-assisted lift mechanism, designed for smooth and stable operation.

4.2 RGB LED Lights

The integrated RGB LED lights can be controlled using the provided remote control to customize the ambience.

- **Power On/Off:** Press the **ON/OFF** button on the remote.
- **Color Selection:** Use the color buttons to choose from 16 different colors.
- **Brightness Adjustment:** Use the **Brightness Up/Down** buttons to adjust the light intensity.
- **Mode Selection:** Select from 4 dynamic modes:
 - **Jump:** Cycles through colors with abrupt transitions.
 - **Strobe:** Flashes a single color.
 - **Fade:** Smoothly transitions between colors.
 - **Smooth:** Gradually changes between colors.

16 COLORS AND 4 MODES

3-Color or 7-Color Jump, Strobe and Gradual



Figure 4.3: The coffee table illuminated by its RGB LED lights, showcasing different color options and the remote control used for adjustments.

4.3 Storage Drawers

The table includes four spacious drawers for organized storage. Simply pull the drawer fronts to open and push to close. Avoid overloading drawers to ensure smooth operation.

AMPLE AND VERSATILE STORAGE



Figure 4.4: The coffee table with its four drawers and hidden compartment open, demonstrating the extensive storage capacity for various items.



Figure 4.5: A detailed view of one of the spacious drawers, highlighting its smooth operation and capacity for storing household items.

5. MAINTENANCE

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the

finish or LED components.

- Dusting:** Regularly dust the table with a dry, soft cloth.
- Fasteners:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary to maintain stability.
- Lift Mechanism:** Keep the lift mechanism free of debris. Do not apply lubricants unless specifically recommended by the manufacturer.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Table is wobbly.	Loose fasteners. Uneven floor.	Tighten all assembly screws. Place shims under legs if the floor is uneven.
Lift top mechanism is stiff or noisy.	Debris in mechanism. Misalignment during assembly.	Inspect for obstructions and remove. Ensure all lift mechanism screws are properly tightened and aligned.
LED lights not working.	Power connection loose. Remote control battery dead. LED strip damaged.	Check power cable connection. Replace remote control battery. Contact support if LED strip is damaged.
Drawers do not slide smoothly.	Overloaded drawer. Misaligned drawer slides.	Reduce weight in the drawer. Recheck drawer slide installation and alignment.

7. SPECIFICATIONS

Brand:	DWVO
Model Number:	MADWVeL2se
Product Dimensions (D x W x H):	21.65" x 35.43" x 16.14" (55cm x 90cm x 41cm)
Item Weight:	67.2 Pounds (approx. 30.5 kg)
Material:	Engineered Wood
Color:	Black
Number of Drawers:	4
LED Features:	RGB, 16 Colors, 4 Modes (Jump, Strobe, Fade, Smooth)
Assembly Required:	Yes
Tools Recommended:	Screwdriver

8. WARRANTY AND CUSTOMER SUPPORT

For warranty information, missing parts, or technical assistance, please contact DWVO customer support. Refer to your purchase documentation for specific warranty terms and contact details.

Online Support: Visit the official DWVO website or the retailer's support page where the product was purchased.

When contacting support, please have your model number (MADWVeL2se) and purchase date available.

