Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bonnlo BL0SM07WA

Bonnlo Fireplace TV Stand User Manual

Model: BL0SM07WA

1. Introduction

This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your Bonnlo Fireplace TV Stand. Please read all instructions carefully before beginning assembly or use. Retain this manual for future reference.



Image 1.1: The Bonnlo Fireplace TV Stand, featuring a central electric fireplace, two glass-door cabinets, two drawers, and an open shelf, designed to accommodate TVs up to 80 inches.

2. Safety Information

Important Safety Instructions:

- Read all instructions before installing or using this appliance.
- Do not operate any fireplace with a damaged cord or plug, or if the heater malfunctions or has been dropped or damaged in any manner.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Always unplug the fireplace when not in use.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a

bed, where openings may become blocked.

- This fireplace is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the fireplace.
- The electric fireplace heater is CSA-certified for safety.

3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- TV Stand components
- Electric Fireplace Insert
- Instruction Book (Assembly Guide)
- Hardware pack (screws, dowels, etc.)
- Remote control for fireplace and LED lighting



Image 3.1: The Bonnlo Fireplace TV Stand is shipped in two separate packages, which may arrive on different days.

4. Setup and Assembly

Assembly of the Bonnlo Fireplace TV Stand requires following the detailed instructions provided in the included Instruction Book. Ensure you have adequate space and the necessary tools before starting.

4.1 Key Assembly Features

- **Reinforced Metal Frame:** Provides structural integrity and long-lasting support.
- **Sturdy Base Foundation:** Ensures stability and wobble-free placement.
- **Silent Drawer Slides:** For smooth and quiet operation of the storage drawers.
- **Adjustable Storage Shelves:** Allows customization of cabinet space to fit various items.
- **Exquisitely Crafted Handles:** Designed for both aesthetics and functionality.



Image 4.1: Detailed view of the stand's construction, highlighting silent drawer slides, adjustable shelves, a sturdy base, and elegant handles.

5. Operating Instructions

5.1 Electric Fireplace Heater

The 36-inch electric fireplace insert provides both heat and visual ambiance. It can be controlled via the included remote or the touch panel on the unit.

- **Realistic Flames:** Features 12 flame colors and 5 brightness levels for customizable ambiance.
- **Adjustable Heater:** Provides heat output ranging from 62°F to 95°F (17°C to 35°C).
- **Timer Function:** Set the heater to operate for 0.5 to 6 hours.
- **Overheat Protection:** CSA-certified safety feature automatically shuts off the unit if it overheats.
- **Flame Only Mode:** Enjoy the visual effect of flames without activating the heater.



Image 5.1: Features of the 36-inch electric fireplace, including remote control, adjustable heat, timer, and safety certifications.



Image 5.2: Visual representation of the 12 available flame colors for the electric fireplace.

5.2 Immersive LED Lighting

The built-in full-color LED strips can be controlled via a dedicated app or the included remote control.

- **Full-Color Spectrum:** Access millions of color options to match any mood or decor.
- **Music Rhythm Mode:** Sync the LED lights with your favorite music for dynamic lighting effects.
- **Auto-Off Timer:** Set a timer for the LED lights to automatically turn off.



Image 5.3: Control the full-color LED strips via app or remote, with features like Music Rhythm Mode and Auto-Off Timer.

6. Maintenance

Regular maintenance ensures the longevity and appearance of your TV stand.

- **Cleaning the Wood Surfaces:** Wipe engineered wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that can damage the finish.
- **Cleaning the Glass Doors:** Use a standard glass cleaner and a lint-free cloth. Spray cleaner onto the cloth, not directly onto the glass, to prevent overspray on wood.
- **Fireplace Insert:** Ensure the fireplace is unplugged and cool before cleaning. Wipe the exterior with a soft, damp cloth. Do not attempt to clean the interior components.
- **Dusting:** Regularly dust all surfaces with a dry, soft cloth to prevent buildup.

- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten as necessary.

7. Troubleshooting

If you encounter issues with your Bonnlo Fireplace TV Stand, refer to the following common solutions:

- **Fireplace Not Turning On:**
  - Ensure the power cord is securely plugged into a functional electrical outlet.
  - Check if the main power switch on the fireplace insert is in the 'ON' position.
  - Verify that the remote control batteries are not depleted.
  - If the unit overheated, the safety cutoff may have activated. Unplug the unit, wait 10-15 minutes, and plug it back in.
- **No Heat Output:**
  - Confirm the heater function is activated and the temperature setting is above the ambient room temperature.
  - Check for any obstructions around the heater's air intake or exhaust vents.
- **LED Lights Not Working:**
  - Ensure the LED strip is properly connected.
  - Check the remote control or app for proper function and battery levels.
- **Drawers or Doors Not Operating Smoothly:**
  - Inspect the drawer slides for any obstructions or debris.
  - Ensure all assembly hardware for drawers and doors is securely tightened.

For persistent issues, please contact Bonnlo customer support.

8. Specifications

Brand	Bonnlo
Model Name	Fireplace TV Stand
Item Model Number	BL0SM07WA
Product Dimensions	70"W x 13.66"D x 32.44"H
Material	Engineered Wood
Finish Type	Polished
Color	Walnut
Item Weight	114 Pounds
Power Source	Corded Electric
Fireplace Size	36 inches (3-sided glass)
Heater Temperature Range	62°F–95°F
Heater Timer	0.5–6 hours

TV Size Compatibility	Up to 80 inches



Image 8.1: Dimensional overview of the TV stand, illustrating its capacity for various TV sizes.

9. Customer Support

Bonnlo is dedicated to providing professional and reliable after-sales service. If you have any questions, concerns, or require assistance with your product, please refer to the contact information provided in your purchase documentation or visit the official Bonnlo website for support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FVFFYMHX

More documents and user manuals: **https://manuals.plus/**