

Futanwei EF16, S50

Futanwei Tempered Glass Screen Protector Instruction Manual

For SUNKTA EF16 and TIMU S50 Smart Watches

INTRODUCTION

This manual provides comprehensive instructions for the proper installation and care of your Futanwei Tempered Glass Screen Protector. Designed specifically for the SUNKTA EF16 and TIMU S50 Smart Watches, this protector offers advanced defense against scratches, impacts, and smudges, ensuring the longevity and clarity of your device's display.

PRODUCT FEATURES

- **9H Hardness:** Provides superior resistance against scratches and daily wear.
- **Oleophobic and Hydrophobic Coating:** Repels sweat and oil residue, reducing fingerprints and smudges.
- **Ultra HD Clarity:** Maintains 99.9% light transmission for original photo and video quality.
- **High Touch Sensitivity:** Ensures responsive and accurate touch screen interaction.
- **Bubble-Free Installation:** Designed for easy application without air bubbles.
- **Precision Cut:** Custom-fit to the exact dimensions of your smartwatch screen for seamless integration.



This image highlights the key features of the Futanwei Tempered Glass Screen Protector, including its ultra HD clarity, high transparency, oleophobic and smudge-resistant properties, 9H hardness, scratch resistance, easy installation, and perfect adhesion.

High Hardness

Guardian of screen.

All glass is more resistant to hard objects.

Daily scratch and wear resistance.



The image illustrates the high hardness of the screen protector, showing it resisting scratches from sharp objects like a utility knife, emphasizing its protective qualities.

INSTALLATION GUIDE

Follow these steps carefully for a successful, bubble-free installation of your screen protector.

1. **Prepare Your Workspace:** Ensure you are in a clean, dust-free environment. Wash your hands thoroughly to avoid transferring oils to the screen or protector.
2. **Clean the Smart Watch Screen:**
 - Use the provided alcohol wipe to thoroughly clean the smartwatch screen, removing all dirt, oil, and smudges.
 - Immediately follow with the microfiber cloth to dry the screen completely and remove any streaks.
 - Use the dust-absorber sticker to pick up any remaining dust particles. Ensure the screen is perfectly clean and dry before proceeding.
3. **Align the Screen Protector:**
 - Carefully peel off the protective film from the adhesive side of the tempered glass (usually marked "1" or with a tab). Avoid touching the adhesive surface.
 - Align the screen protector precisely with the edges and cutouts of your smartwatch screen. Take your time to

ensure perfect alignment.

4. Apply the Protector:

- Once aligned, gently lower the screen protector onto the smartwatch screen. The adhesive will begin to spread automatically.
- If bubbles appear, gently press them towards the edges of the screen using the microfiber cloth or a soft card. Small bubbles should disappear within 24-48 hours.

Bubble Free



This image represents the bubble-free application of the screen protector, indicating a smooth and clear finish after installation.

Touch Sensitive

Provide 100% touch screen effect. Keep the original touch sensitivity of the screen fast



The image illustrates the high touch sensitivity of the screen protector, showing a finger smoothly interacting with the smartwatch display, ensuring no loss of responsiveness.

MAINTENANCE AND CARE

To maintain the clarity and effectiveness of your screen protector, follow these simple care guidelines:

- **Regular Cleaning:** Use a soft, lint-free microfiber cloth to gently wipe the screen protector. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner specifically designed for electronics.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, alcohol (other than the initial cleaning wipe), or solvents, as these can damage the oleophobic coating.
- **Protect from Sharp Objects:** While the protector is 9H hard, extreme force or very sharp objects can still cause damage. Avoid placing your smartwatch face down on rough surfaces or with keys/coins.

TROUBLESHOOTING

Here are solutions to common issues you might encounter during or after installation:

- **Bubbles After Installation:**
 - **Small Bubbles:** Most small bubbles will naturally disappear within 24-48 hours as the adhesive settles.
 - **Large Bubbles/Dust Particles:** If a large bubble persists or you see a dust particle, gently lift the nearest corner of the protector with a fingernail or a thin card. Use a dust-absorber sticker to remove the dust, then re-apply the protector slowly.
- **Misalignment:** If the protector is significantly misaligned, gently lift it from one corner and re-align it carefully. Avoid excessive force to prevent damage.
- **Edges Not Sticking:** Ensure the screen was thoroughly cleaned and dry before application. If edges still don't adhere, gently press them down for a few seconds. Extreme cases might indicate a faulty protector or an incompatible screen curvature.

SPECIFICATIONS

Feature	Detail
Compatible Models	SUNKTA EF16 Smart Watch, TIMU S50 Smart Watch
Material	Tempered Glass
Item Hardness	9H
Clarity	99.9% (Ultra HD)
Special Features	Oleophobic, Hydrophobic, Anti-Scratch, Bubble Free, High Transparency, Touch Sensitive
Product Dimensions	3"L x 2"W (Approximate protector size)
Number of Items	3 Count



This image displays the compatible smartwatch models, SUNKTA EF16 and TIMU S50, for which this tempered glass screen protector is designed.

WARRANTY AND SUPPORT

Information regarding product warranty and customer support was not available in the provided product data. Please refer to the product packaging or the seller's official website for details on warranty coverage and how to contact support for further assistance.

© 2026 Futanwei. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FVFLCQXG>

More documents and user manuals: **<https://manuals.plus/>**