Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Supersonic /
- > Supersonic 43" QLED Smart Android TV (Model TV-SLM-50C6) User Manual

Supersonic TV-SLM-50C6

Supersonic 43" QLED Smart Android TV User Manual

Model: TV-SLM-50C6

1. Introduction

Thank you for choosing the Supersonic 43" QLED Smart Android TV. This manual provides essential information for the safe and efficient operation of your television. Please read it thoroughly before using the product and retain it for future reference.

2. SAFETY INFORMATION

- **Power Supply:** Ensure the TV is connected to a power source with the correct voltage as indicated on the product label.
- **Ventilation:** Do not block ventilation openings. Allow adequate space around the TV for proper airflow to prevent overheating.
- Water and Moisture: Do not expose the TV to rain or moisture. Avoid placing objects filled with liquids, such as vases, on the TV.
- Cleaning: Unplug the TV before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- Placement: Place the TV on a stable, level surface. Ensure children do not climb on the TV or stand.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Please check that the following items are included in your TV package:

• Supersonic 43" QLED Smart Android TV

- Remote Control
- Power Cable
- TV Stands (2)
- · Screws for TV Stands
- User Manual (this document)

4. SETUP

4.1 Attaching the TV Stands

- 1. Carefully place the TV face-down on a soft, clean surface to prevent screen damage.
- 2. Align each stand with the corresponding screw holes on the bottom of the TV.
- 3. Secure the stands using the provided screws. Ensure they are firmly attached.



Figure 1: Front view of the Supersonic 43" QLED Smart Android TV with its stands. This image shows the sleek, frameless design and the placement of the stands at the bottom corners of the television.

4.2 Wall Mounting (Optional)

If you choose to wall mount your TV, please consult a professional installer. Ensure you use a VESA-compatible wall mount kit appropriate for the TV's size and weight. Refer to the wall mount kit's instructions for installation.

4.3 Connecting Power

Connect the power cable to the TV's power input and then plug the other end into a wall outlet. The TV will enter standby mode.

4.4 Connecting External Devices

Your TV offers multiple connectivity options:

- HDMI: Connect Blu-ray players, game consoles, set-top boxes, or other HDMI-enabled devices.
- USB: Connect USB storage devices to view media files.
- Antenna/Cable: Connect an antenna or cable TV source for broadcast channels.



Figure 2: Side view of the Supersonic 43" QLED Smart Android TV, highlighting the various connectivity ports. This image illustrates the slim profile and the location of input/output connections for external devices.

4.5 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup process:

- 1. Language Selection: Choose your preferred language.
- 2. **Network Connection:** Connect to your Wi-Fi network or an Ethernet cable for internet access. This is essential for Smart TV features.
- 3. **Google Account Sign-in:** Sign in with your Google account to access the Google Play Store and other Android TV services.
- 4. Channel Scan: Scan for available broadcast channels if an antenna or cable is connected.
- 5. **Privacy Settings:** Review and adjust privacy settings as desired.

5. OPERATING YOUR TV

5.1 Remote Control Overview

The remote control allows you to navigate the TV's features. Familiarize yourself with the buttons for power, volume, channel, input selection, navigation, and dedicated app buttons (e.g., Netflix, YouTube).

5.2 Basic TV Functions

- Power On/Off: Press the power button on the remote or TV.
- Volume Control: Use the Volume Up/Down buttons.
- Channel Selection: Use the Channel Up/Down buttons or number pad.
- Input Source: Press the 'Input' or 'Source' button to switch between HDMI, USB, TV, etc.

5.3 Smart Android TV Features

Your Supersonic TV runs on the Android TV platform, providing access to a wide range of applications and services:

- **Home Screen:** Access your favorite apps, live TV, and recommended content from the customizable home screen.
- Google Play Store: Download and install additional apps, games, and streaming services.
- Netflix & YouTube: Dedicated buttons on your remote provide quick access to these popular streaming platforms.
- Google Assistant: Use voice commands via the remote control for search, control, and information.

5.4 Picture and Sound Settings

Navigate to the TV's settings menu to adjust picture and sound preferences:

- **Picture Modes:** Choose from standard, vivid, movie, sport, or custom settings. Adjust brightness, contrast, color, and sharpness.
- Sound Modes: Select from standard, music, movie, speech, or custom settings. Adjust bass, treble, and balance.

5.5 Gaming Features

This QLED TV is designed to enhance your gaming experience:




Figure 3: Diagram explaining the New Zero Delay Transient Response. This image compares standard transient response with zero delay, showing how the backlight response closely matches the input signal for reduced lag and improved visual clarity during fast-paced scenes.

- Zero Delay Transient Response: This technology minimizes the lag between the input signal and the
 backlight response, providing a virtually lag-free visual experience, crucial for fast-paced content like
 gaming.
- **Game Accelerator:** Designed to optimize performance for gaming, ensuring more responsive gameplay without noticeable lag.




Figure 4: Image illustrating the 'Game Accelerator' feature. This visual shows an intense gaming scene with explosions and spacecraft, emphasizing the benefit of responsive gameplay without lag, designed to keep players competitive.




Figure 5: The Supersonic QLED TV displaying brilliant, vivid, and lifelike colors. This image highlights the superior color reproduction capabilities of QLED technology, making content appear more vibrant and realistic.

6. MAINTENANCE

6.1 Cleaning the TV

- Screen: Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner (ensure it's safe for QLED screens) and wipe gently. Do not apply pressure.
- Body: Wipe the TV frame and back with a soft, dry cloth. Avoid using abrasive cleaners or solvents.

6.2 Software Updates

Your Android TV may receive software updates periodically. It is recommended to keep your TV connected to the internet to receive these updates, which can improve performance and add new features. You can usually check for updates in the TV's settings menu under 'About' or 'System Update'.

7. TROUBLESHOOTING

Problem	Possible Solution
No power	Check if the power cable is securely plugged into the TV and the wall outlet. Try a different outlet.
No picture, but sound is present	Ensure the correct input source is selected. Check cable connections to external devices.
No sound, but picture is present	Check volume level and mute status. Ensure external audio systems are correctly connected and powered on.
Cannot connect to Wi-Fi	Restart your router and TV. Re-enter the Wi-Fi password. Ensure the TV is within range of the router.
Apps are not working or slow	Check internet connection. Clear app cache/data in TV settings. Restart the TV.
Remote control not working	Replace batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.

7.1 Factory Reset

If problems persist, a factory reset may resolve them. This will erase all personal settings and installed apps, returning the TV to its original state. Navigate to **Settings > Device Preferences > About > Factory reset**.

8. SPECIFICATIONS

Feature	Detail
Brand	Supersonic
Model Name	TV-SLM-50C6
Display Size	43 inches (109 cm)
Display Technology	QLED
Resolution	1080p (Full HD)
Refresh Rate	60 Hz
Special Features	Wide Viewing Angle, Smart Android System, Netflix, YouTube, Zero Delay Transient Response, Game Accelerator
Connectivity	HDMI, USB, Wi-Fi, Ethernet
Product Dimensions	14D x 121W x 75H centimetres
Operating System	Android TV

9. WARRANTY

This Supersonic 43" QLED Smart Android TV comes with a**6 Months Manufacturer's Warranty**. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal

use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or natural disasters.

10. SUPPORT

For further assistance, technical support, or warranty inquiries, please contact your retailer or the Supersonic customer service department. Refer to your purchase documentation for contact details.

Related Documents - TV-SLM-50C6


Supersonic SC-4250GTV 42-inch Android TV User Manual

Comprehensive user manual for the Supersonic SC-4250GTV 42-inch Android TV, detailing setup, operation, connections, remote control functions, troubleshooting, specifications, and safety instructions.



Supersonic 90-Day Product Warranty Information and Service Guide

Comprehensive details on Supersonic's 90-day parts and labor warranty for products sold in the United States, including warranty terms, exclusions, service procedures, return instructions, and cost information.



Supersonic SC-619 High Digital TV Antenna User Guide

User guide for the Supersonic SC-619 High Digital TV Antenna, providing specifications, assembly instructions, connection guides, troubleshooting tips, and warranty information.



Supersonic SC-2211 21.5-Inch LED HDTV Specifications and Features

Detailed specifications and features for the Supersonic SC-2211 21.5-inch LED HDTV, including product dimensions, weight, resolution, connectivity options, and power requirements.



Supersonic SC-3226SDVD 32-Inch LED TV with DVD Player User Manual

Comprehensive user manual for the Supersonic SC-3226SDVD 32-inch LED TV with built-in DVD player. Learn about setup, operation, features, safety, and troubleshooting.



Supersonic SC-2812 Portable Player & LCD Television User Manual

Comprehensive user manual for the Supersonic SC-2812 portable player and LCD television, covering setup, operation, features, and troubleshooting.