

[Manuals.plus](#) /

- › [Wildgame Innovations](#) /
- › Wildgame Innovations Insite-V Cellular Trail Camera Instruction Manual

Wildgame Innovations Insite-V

Wildgame Innovations Insite-V Cellular Trail Camera Instruction Manual

Model: Insite-V (WGI-INSV-3PK)

INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Wildgame Innovations Insite-V Cellular Trail Camera. The Insite-V camera is designed to deliver real-time wildlife updates directly to your smartphone, featuring 32 MP image quality, invisible "Lightsout" infrared flash, and nationwide cellular coverage. It is a weather-proof device suitable for scouting, monitoring property, and tracking nocturnal activity.

SETUP

Follow these steps to prepare your Insite-V Cellular Trail Camera for use:

- Battery Installation:** The camera requires batteries for operation. Open the battery compartment, typically located on the bottom or back of the unit, and insert the required number of fresh batteries, ensuring correct polarity.
- SD Card Insertion:** Insert a compatible SD card (not included) into the designated slot. Ensure the card is formatted correctly before first use.
- Cellular Activation & HuntSmart App:** Download the HuntSmart app to your smartphone. Follow the in-app instructions to activate your camera's cellular service and link it to your account. This step is crucial for receiving real-time updates.
- Mounting the Camera:** Use the included tree strap to securely mount the camera to a tree or post. Position the camera at an appropriate height and angle to capture the desired area. Ensure the camera is stable and not prone to movement from wind or wildlife.



Image: The Insite-V Cellular Trail Camera securely mounted to a tree using the provided strap, ready for deployment in the field.

OPERATING INSTRUCTIONS

Once set up, operating your Insite-V camera is straightforward:

1. **Power On/Off:** Locate the power switch, typically inside the camera housing, and switch it to the 'ON' position. The camera will perform a self-check.
2. **Mode Selection:** Depending on your model, you may have different operating modes (e.g., Photo, Video, Time-Lapse). Select your desired mode using the internal controls or via the HuntSmart app.
3. **Detection and Capture:** The camera features a sub-0.7-second trigger speed and an 80 ft detection range. When motion is detected within this range, the camera will capture 32MP photos or video according to your settings.
4. **Infrared Illumination:** For night captures, the 42 invisible black IR LEDs provide discreet illumination, ensuring clear images without disturbing wildlife.
5. **HuntSmart App Integration:** Use the HuntSmart app to remotely monitor your camera, adjust settings, and view captured images and videos. The app also offers smart analysis features, allowing you to filter images by species, time, weather, and moon phase for data-driven game management.



Image: A clear daytime photograph of a deer, demonstrating the 32MP image quality of the Insite-V camera.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your camera:

- **Cleaning:** Periodically clean the camera lens and PIR sensor window with a soft, lint-free cloth. Avoid abrasive materials or harsh chemicals. Ensure the housing is free of dirt, dust, and debris.
- **Battery Replacement:** Replace batteries when the power indicator shows low battery or when performance degrades. Always use fresh, high-quality batteries.
- **SD Card Management:** Regularly check your SD card capacity. Format the SD card periodically to maintain optimal performance and prevent data corruption. Back up important images and videos before formatting.
- **Weather Protection:** While the camera has an IP54 rating for weather resistance, ensure all latches are securely closed to prevent moisture ingress. Avoid submerging the camera in water.

TROUBLESHOOTING

If you encounter issues with your Insite-V camera, consider the following:

- **Camera Not Powering On:** Check battery installation and ensure batteries are fresh. Verify the power switch is in the 'ON' position.
- **No Images Captured:** Ensure the camera is in an active mode (e.g., Photo or Video). Check the PIR sensor for obstructions. Verify the SD card is inserted correctly and has sufficient space.
- **Poor Image Quality:** Clean the camera lens. Ensure the camera is mounted stably to prevent blur. Check for adequate lighting conditions, especially at night.
- **Cellular Connectivity Issues:** Check the signal strength indicator on the camera or via the HuntSmart app. Relocate the camera to an area with better cellular reception if necessary. Ensure your cellular plan is active.
- **App Connection Problems:** Ensure your smartphone has an active internet connection. Verify the HuntSmart app is updated to the latest version. Restart both the camera and the app.

For further assistance, refer to the HuntSmart app's help section or contact Wildgame Innovations customer support.

SPECIFICATIONS

Brand	Wildgame Innovations
Model Name	Insite-V
Model Number	WGI-INSV-3PK
Image Quality	32 MP
Detection Range	80 ft
Trigger Speed	Sub-0.7 seconds
Infrared LEDs	42 invisible black IR LEDs
Connectivity Technology	Wireless, Cellular
Compatible Devices	Smartphone
Indoor/Outdoor Usage	Outdoor
Power Source	Battery Powered (Batteries Required)
Item Dimensions	3 x 1.5 x 8 inches
Item Weight	3.11 Pounds
Color	Gray
Mount Type	Tree Mount
UPC	888151097458

WARRANTY AND SUPPORT

For detailed warranty information, please consult the official Wildgame Innovations website or the product packaging. Warranty terms and conditions may vary.

For technical support, product inquiries, or assistance with the HuntSmart app, please visit the Wildgame Innovations support page or contact their customer service department directly. Contact information can typically be found on the manufacturer's website or within the HuntSmart application.