

[Manuals.plus](#) /

› [Monster](#) /

› Monster N-Lite 216 Wireless Earbuds User Manual

Monster E117

Monster N-Lite 216 Wireless Earbuds User Manual

Model: N-Lite 216 (E117)

1. INTRODUCTION

Thank you for choosing the Monster N-Lite 216 Wireless Earbuds. These earbuds are designed to provide a comfortable and secure audio experience, especially for sports and active lifestyles. Featuring ergonomic earhooks, IPX6 water resistance, and long battery life, they are built for performance and convenience.



A pair of black Monster N-Lite 216 wireless earbuds with ergonomic earhooks, designed for a secure fit.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Monster N-Lite 216 Earbuds
- Charging Case
- S/M/L Ear Tips
- USB-C Cable
- Quick Start Guide (User Manual)

What's in the Box

Monster N-Lite 216 Earbuds
Charging Case
S/M/L Ear Tips
USB-C Cable
Quick Start Guide



Image showing the Monster N-Lite 216 earbuds, charging case, S/M/L ear tips, USB-C cable, and Quick Start Guide.

3. SETUP

3.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. The charging case provides multiple charges for extended listening.

- Connect the provided USB-C cable to the charging port on the case and a power source.
- The indicator lights on the case will show the charging status.
- Place the earbuds into the charging case; they will begin charging automatically.

A single charge provides up to 8 hours of continuous use, with the charging case extending total playtime to up to 48 hours. A quick 10-minute charge can provide approximately 3 hours of playtime.

Long-Lasting Listening

8Hrs

Playtime per charge

48Hrs

Playtime with charging case

Fast charging ⚡ **10 Mins** = 🔋 **3Hrs** Playtime



An illustration of the Monster N-Lite 216 earbuds inside their charging case, connected via a USB-C cable, highlighting the 48-hour total playtime.


3.2. Bluetooth Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode, indicated by flashing lights.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Monster N-Lite 216" in the list of available Bluetooth devices.
4. Select "Monster N-Lite 216" to connect. Once connected, a voice prompt will confirm successful pairing.

The earbuds feature Bluetooth 6.0 for faster connectivity and improved stability.

Bluetooth 6.0

Featuring a Bluetooth 6.0 chip, Monster N-lite 216 delivers faster connectivity and improved stability.



A close-up illustration of the internal components of an earbud, showcasing the Bluetooth 6.0 chip for stable connectivity.


4. HOW TO WEAR

For optimal sound quality and a secure fit, follow these steps:


1. Select the appropriate ear tip size (S, M, L) for your ears.
2. Take out an earbud and place it above your ear, ensuring the earhook rests comfortably over the top of your ear.
3. Gently rotate the earbud backward along the auricle until it sits securely and comfortably in your ear canal.

The ergonomic earhook design provides a stable and comfortable wearing experience, ideal for active use.

How to Wear



Step 1 Take out the earbud, place it above the ear



Step 2 Rotate it backward along the auricle to the proper position

Two-step diagram illustrating how to correctly place the earbud above the ear and rotate it backward for a secure fit.

5. OPERATING THE EARBUDS

5.1. Smart Touch Controls

The Monster N-Lite 216 earbuds feature intuitive touch controls for managing audio and calls:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant:** Press and hold either earbud for 3 seconds.

Smart Touch Control

Effortlessly manage music and calls with a few taps.




Skip
Tracks



Adjust
volume



Answer
calls



An illustration of an earbud with a glowing fingerprint icon, indicating touch control functionality for skipping tracks, adjusting volume, and answering calls.

5.2. Audio Quality

Equipped with 14.2mm dynamic drivers, these earbuds deliver rich, resonant bass and precise audio clarity for an immersive listening experience.

14.2mm Dynamic Driver


Featuring a 14.2mm dynamic driver unit, these earbuds deliver pure and high-quality sound with a wider audio performance and powerful bass, enhancing your music experience.



An exploded diagram showing the internal 14.2mm dynamic driver components of the earbud, responsible for delivering powerful bass and clear audio.

5.3. Crystal-Clear Calls

The built-in high-performance ENC (Environmental Noise Cancellation) microphones reduce background noise, ensuring your voice remains clear and intelligible during calls, even in busy environments.



Crystal-Clear Calls

With ENC call noise reduction, Monster N-lite 216 wireless earbuds filter out unwanted noise from surroundings, ensuring voice remains clear and intelligible during calls.

A man smiling while talking on his phone, wearing a Monster N-Lite 216 earbud, illustrating the clear call quality even in noisy surroundings.

6. MAINTENANCE

6.1. Water Resistance

The earbuds are IPX6 water-resistant, protecting them from splashes, sweat, and light rain. They are suitable for workouts and outdoor activities but should not be submerged in water.

IPX6 Water-Resistant

Protected from spills, splashes, and light rain with IPX6 rating.



An illustration of the earbuds with water droplets, signifying their IPX6 water-resistant rating, protecting against spills and splashes.

6.2. Cleaning and Storage

- Regularly clean the earbuds and charging case with a soft, dry cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Avoid using abrasive cleaners or solvents.
- Store the earbuds in their charging case when not in use to protect them and maintain battery life.
- Keep the device away from extreme temperatures and humidity.

7. TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are charged and out of the case. Turn off and on your device's Bluetooth. If issues persist, try resetting the earbuds (refer to Quick Start Guide for specific reset instructions).
- **No sound:** Check volume levels on both your device and the earbuds. Ensure earbuds are properly connected to your device.
- **Charging issues:** Verify the USB-C cable is securely connected to both the case and power source. Ensure the charging contacts on the earbuds and inside the case are clean.
- **Intermittent connection:** Move closer to your connected device. Avoid environments with strong Wi-Fi or other wireless interference.

8. SPECIFICATIONS

Feature	Specification
Brand	Monster
Model Name	N-Lite 216 (E117)
Connectivity Technology	Bluetooth
Bluetooth Version	6.0
Ear Placement	In Ear
Form Factor	In Ear with Earhooks
Control Type	Touch Control
Water Resistance Level	IPX6 Waterproof
Driver Size	14.2mm
Playtime (Single Charge)	Up to 8 hours
Total Playtime (with Case)	Up to 48 hours
Item Weight	6.7 ounces
Included Components	User Manual, Wireless Charging Case

9. WARRANTY AND SUPPORT

Monster is committed to ensuring customer satisfaction. For any inquiries or feedback regarding your Monster N-Lite 216 Wireless Earbuds, please contact our professional customer service team. We are dedicated to providing a seamless experience and finding solutions to meet your needs.

Please refer to the Quick Start Guide included in your package for specific warranty details and contact information.

© 2025 Monster. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question