

H24-2201-B

## Generic H24-2201-B 39.4" Drawer Computer Desk with USB Charger User Manual

Model: H24-2201-B

### INTRODUCTION

---

This manual provides essential information for the assembly, operation, and maintenance of your Generic H24-2201-B 39.4" Drawer Computer Desk with USB Charger. Please read these instructions carefully before assembly and use to ensure safe and efficient operation.




Image: The Generic H24-2201-B computer desk in walnut finish, featuring two white drawers and sturdy black metal legs. This image provides an overall view of the desk's design and dimensions.

## SAFETY INFORMATION

---

It is crucial to follow all safety guidelines to prevent injury or damage to the product. Please observe the following:

- Always assemble the desk according to the provided instructions.
- Do not exceed the weight limit of **88 lb (40 kg)**. Overloading can compromise the desk's stability and structural integrity.
- Ensure the desk is placed on a stable, level surface to prevent tipping.
- Keep the desk away from direct heat sources, open flames, and excessive moisture.
- Avoid placing heavy objects on the edges of the desk to prevent damage or instability.
- Periodically check all fasteners to ensure they remain tight.

## PACKAGE CONTENTS

---

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x Desk Top (with integrated USB charger)
- 2 x Drawer Units
- 2 x Metal Leg Frames
- 1 x Back Panel
- Assembly Hardware (screws, bolts, Allen wrench, etc.)
- Instruction Manual

*Note: All necessary assembly tools are included.*

## SETUP AND ASSEMBLY

---

Assembly is required for this desk. It is recommended that **two people** assemble the desk to ensure stability and ease of construction. Please follow the steps below carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches.
2. **Attach Leg Frames:** Secure the metal leg frames to the underside of the desk top using the provided screws and Allen wrench. Ensure all connections are tight.
3. **Install Drawers:** Assemble the two drawer units according to their individual instructions. Once assembled, slide them into the designated slots under the desk top. Ensure the smooth sliding rails are properly aligned.
4. **Attach Back Panel:** Secure the back panel to the rear of the desk structure. This adds stability and finishes the desk's appearance.
5. **Final Check:** Once assembled, gently lift and move the desk to its desired location. Verify that all screws are tightened and the desk is stable.



Image: An assembled view of the computer desk, highlighting the integration of the desk top, drawers, and metal leg structure. This image can serve as a visual reference during assembly.

## OPERATING INSTRUCTIONS

---

### Using the USB Charging Port

Your desk is equipped with a built-in USB charging port for convenient device charging.

1. **Connect Power:** Ensure the desk's power cord (if applicable, usually from the USB hub) is securely plugged into a functional wall outlet.
2. **Plug in Devices:** Connect your USB-compatible devices (e.g., smartphones, tablets, smartwatches) to the USB ports located on the desk surface.
3. **Charging Indication:** Your device should indicate that it is charging. If not, check the power connection and the USB cable.




Image: A detailed view of the circular USB charging hub embedded in the desk's surface. It features three USB ports, allowing multiple devices to be charged simultaneously.

## Using the Storage Drawers

The two integrated drawers provide convenient storage for your office supplies and personal items.

- **Opening/Closing:** Gently pull the drawer handle to open and push to close. The smooth sliding rails ensure easy operation.
- **Weight Limit:** Avoid overloading the drawers to ensure smooth operation and prevent damage to the drawer slides.

## MAINTENANCE

---

Proper care will extend the life and maintain the appearance of your desk.

- **Cleaning:** Wipe clean with a damp cloth. For stubborn marks, use a mild soap solution and immediately dry with a clean cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong detergents, or solvents, as these can damage the wood grain laminate finish.
- **Spills:** Promptly wipe up any spills to prevent water damage or staining. The scratch-resistant and waterproof finish offers protection, but immediate cleaning is recommended.
- **Fasteners:** Periodically check and tighten all screws and bolts to ensure the desk remains stable.

## TROUBLESHOOTING

---

If you encounter any issues with your desk, refer to the following common problems and solutions:

- **Desk is Wobbly:**

- Ensure all assembly screws and bolts are securely tightened.
  - Verify the desk is placed on a level surface. Adjust floor glides if present, or use shims if necessary.
- **Drawers Do Not Slide Smoothly:**
    - Check for obstructions in the drawer slides.
    - Ensure the drawers are not overloaded.
    - Verify that the drawer slides were installed correctly during assembly.
- **USB Ports Not Charging:**
    - Confirm the desk's power cord (for the USB hub) is firmly plugged into a working electrical outlet.
    - Try a different USB cable or device to rule out cable/device issues.
    - Ensure the USB hub connection within the desk is secure (if accessible).

## SPECIFICATIONS

---

<b>Model Number</b>	H24-2201-B
<b>Brand</b>	Generic
<b>Dimensions (D x W x H)</b>	48D x 100W x 76H Centimetres (18.9"D x 39.4"W x 29.9"H)
<b>Weight</b>	37.4 Pounds (17 kg)
<b>Material</b>	MDF, PB, Metal
<b>Finish Type</b>	Wood Grain Laminate
<b>Color</b>	Walnut (with white drawers)
<b>Maximum Weight Capacity</b>	88 Pounds (40 kg)
<b>Number of Drawers</b>	2
<b>Special Features</b>	Built-in USB Charging Port, Scratch-Resistant & Waterproof Surface, Smooth Drawer Operation, Space-Saving Design
<b>Assembly Required</b>	Yes (Recommended 2 people)
<b>Included Assembly Tools</b>	Yes

## WARRANTY AND SUPPORT

---

**Warranty Information:** Warranty is not included with this product. Please contact the seller directly for any warranty-related inquiries or support.

**Customer Support:** For any questions, missing parts, or assistance with assembly or operation, please contact the seller directly via Amazon messaging. Provide your order number and a detailed description of the issue for prompt assistance.

*Manufacturer Contact Information: Not applicable. Please contact the seller directly via Amazon messaging.*

