

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [jiteentarou](#) /

> [jiteentarou Farmhouse TV Stand NSFDSG463 Instruction Manual](#)

## jiteentarou NSFDSG463

# jiteentarou Farmhouse TV Stand NSFDSG463 Instruction Manual

Brand: jiteentarou | Model: NSFDSG463

## 1. PRODUCT OVERVIEW

The jiteentarou Farmhouse TV Stand is a versatile entertainment center designed to accommodate TVs up to 85 inches. It features a classic modern farmhouse style with barn doors and integrated RGB LED lighting. The stand offers ample and flexible storage solutions, including an open-top compartment for soundbars or DVDs, and two barn door cabinets with adjustable shelves. Built with engineered wood, it ensures stability and durability for long-term use. Overall dimensions: 15.7"D x 68.9"W x 31.5"H.

## 2. SAFETY INFORMATION

**WARNING: To prevent serious injury, always use the provided wall mount anchors to secure the cabinet to the wall.**

- Never attempt to move or adjust the cabinet when it is fully assembled to avoid potential tip-over or pinch point injuries.
- Be cautious when handling the cabinet to prevent scratches or other damage during assembly and use.
- Always follow the assembly instructions carefully to ensure the safety and stability of the cabinet.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.

## 3. PACKAGE CONTENTS

Before beginning assembly, ensure all components are present and undamaged. The package includes:

- TV stand components (engineered wood panels)
- LED light strip with remote control
- Assembly manual
- Hardware kit (screws, dowels, cam locks, wall anchors, etc.)

## 4. ASSEMBLY INSTRUCTIONS

Assembly requires careful attention to detail. It is recommended to have two people for certain steps. Lay out all components on a soft, clean surface to prevent scratches. Refer to the included manual for detailed diagrams and

step-by-step instructions.

## Assembly Overview Video

Your browser does not support the video tag. Please update your browser to view this content.

This video provides a comprehensive guide to assembling your Farmhouse TV Stand. Follow the visual instructions carefully for each step.

## Key Assembly Steps

Below are visual aids for critical assembly features. Always refer to the detailed manual for complete instructions.



**Product Dimensions:** Overall size: 15.7"D x 68.9"W x 31.5"H. Fits TVs up to 85 inches. Ensure you have adequate space before assembly.



**Ample Storage:** The design includes an open top shelf for soundbars or media devices, and barn door cabinets with adjustable shelves for flexible storage.

Ensure shelves are installed at desired heights.



**Stable Base & Wire Management:** The 2.8-inch high wooden support base ensures stability. Utilize the three cable management cutouts on the back panel to organize wires and cables.

## 5. OPERATING INSTRUCTIONS (LED LIGHT)

Your TV stand includes an RGB LED light strip for enhanced ambiance. The LED light is controlled via a remote control.

- **Power On/Off:** Use the 'On' and 'Off' buttons on the remote to power the LED lights.
- **Color Selection:** Choose from hundreds of colors using the color palette buttons on the remote.
- **Dynamic Modes:** Select from 25 dynamic modes, including options that fluctuate with music or offer timing functions.
- **Brightness Adjustment:** Adjust the brightness of the lights using the dimmer buttons.



## TWO WAY CONTROL

No worry about missing controller



Hundreds of Colors



Fluctuates with music



Timing function



25 Dynamic Modes



**LED Light Control:** Use the provided remote to customize colors, modes, and brightness of the integrated LED lighting.

## 6. MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the engineered wood.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading of the finish.
- **Heat:** Do not place hot items directly on the surface without protective pads.

## 7. TROUBLESHOOTING

- **Wobbling:** Ensure all cam locks and screws are fully tightened. Check that the stand is on a level surface.
- **LED Lights Not Working:** Verify the USB power cable is securely plugged into a working power source. Check the remote control battery.
- **Missing Parts:** If any parts are missing or damaged, contact customer support immediately for replacements.

## 8. SPECIFICATIONS

Feature	Detail
Brand	jiteentarou
Model Name	NSFDSG463
Product Dimensions	15.7"D x 68.9"W x 31.5"H
Material	Engineered Wood
Color	White
Item Weight	114 Pounds
Special Feature	Adjustable Shelf, Scratch Resistant, LED Light
Assembly Required	Yes

## 9. WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product issues, please refer to the contact information provided in your purchase documentation or contact the seller directly. Keep your purchase receipt for warranty claims.