

[Manuals.plus](#) /

› [Loowoko](#) /

› Loowoko Heated Hoodie User Manual (2025 Model SK-5148)

Loowoko 2025 Model (SK-5148)

Loowoko Heated Hoodie User Manual

Model: 2025 Model (SK-5148)

1. INTRODUCTION

Thank you for choosing the Loowoko Heated Hoodie. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your heated garment. Please read this manual thoroughly before first use and retain it for future reference.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety guidelines:

- Always remove the power bank before washing the hoodie.
- Do not use the heated hoodie if you have a pacemaker, are pregnant, or have any medical condition that makes you sensitive to heat. Consult a physician before use if you have concerns.
- Avoid prolonged direct contact with the heating elements on high settings to prevent skin irritation or burns.
- Do not puncture, cut, or modify the heating elements or wiring.
- Keep the power bank away from water and extreme temperatures.
- The power bank contains built-in protection systems against overcurrent, overheating, and overcharging. Do not attempt to bypass these safety features.
- When traveling by air, ensure the power bank is stored in your carry-on luggage, not checked luggage, in accordance with airline regulations.
- This product is not a medical device and is not intended to diagnose, treat, cure, or prevent any disease.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Loowoko Heated Hoodie
- 1 x 10000 mAh Power Bank
- 1 x USB Cable

- 1 x User Manual (this document)

4. PRODUCT OVERVIEW

The Loowoko Heated Hoodie is designed to provide warmth and comfort in cold conditions. It features multiple heating zones and adjustable temperature settings for personalized warmth.



Image 1: Front view of the Loowoko Heated Hoodie, illustrating the internal heating elements.

6

HEATING ZONES

Ultimate Comfort In Cold Winter



3 Temperature Control



High-Red LED

149°F/65°C



Medium-White LED

131°F/55°C



Low-Blue LED

113°F/45°C

Image 2: Diagram showing the six heating zones located in the chest, back, neck, and hood, along with the three temperature settings.

10000 MAH LARGE CAPACITY BATTERY

Battery Size

30%
Smaller

Run Time

7
Hours



10000 mAh
Large Capacity



Long Lasting



3 Hours Fast
Charging




TSA
Friendly

Image 3: The included 10000 mAh power bank, which powers the heating system.

FEATURED DETAILS




Elastic Cuffs



Large Pocket



Durable Zipper



Soft Fleece Lining

Image 4: Close-up details of the hoodie, including elastic cuffs, large pockets, durable zipper, and soft fleece lining.

5. SETUP

Follow these steps to prepare your heated hoodie for use:

1. **Charge the Power Bank:** Before first use, fully charge the 10000 mAh power bank using the provided USB cable and a compatible power adapter (not included). The indicator lights on the power bank will show the charging status.
2. **Locate the Internal Pocket:** Inside the hoodie, locate the zippered pocket designed to hold the power bank.
3. **Connect the Power Bank:** Connect the USB cable from the hoodie's internal wiring to the output port of the fully charged power bank. Place the power bank securely inside the pocket and zip it closed.

Your browser does not support the video tag.

Video 1: This video demonstrates how to connect the power bank to the Loowoko Heated Hoodie and activate the heating function.

6. OPERATING INSTRUCTIONS

The Loowoko Heated Hoodie features dual control for the hood and vest heating zones, allowing independent temperature adjustment.

1. **Power On:** Press and hold the power button on the hoodie's chest for approximately 3 seconds until the indicator light illuminates.
2. **Adjust Temperature:** Short press the power button to cycle through the three temperature settings:
 - **High (Red LED):** Approximately 50-55°C (122-131°F)
 - **Medium (White LED):** Approximately 45-50°C (113-122°F)
 - **Low (Blue LED):** Approximately 40-45°C (104-113°F)
3. **Dual Control:** The hoodie features separate control buttons for the hood and vest heating zones. Press the respective button to activate and adjust the heat for each area independently.
4. **Power Off:** Press and hold the power button for approximately 3 seconds until the indicator light turns off. Disconnect the power bank when not in use for extended periods.

The power bank provides approximately 7-8 hours of continuous heat, depending on the selected temperature setting and usage.

7. MAINTENANCE

Proper care will extend the life of your heated hoodie:

- **Washing:** The hoodie is both machine and hand washable. Before washing, always remove the power bank from its pocket and zip the pocket closed. For machine washing, place the hoodie in a laundry bag to protect the internal wiring and heating elements. Use cold water and a gentle cycle.
- **Drying:** Do not tumble dry. Air dry the hoodie completely before reconnecting the power bank or storing.
- **Storage:** Store the hoodie in a cool, dry place when not in use. Ensure the power bank is disconnected.
- **Cleaning the Power Bank:** Wipe the power bank with a dry cloth. Do not immerse it in water.

8. TROUBLESHOOTING

If you encounter issues with your Loowoko Heated Hoodie, refer to the following common solutions:

Problem	Possible Cause	Solution
Hoodie does not heat up.	Power bank is not connected or is depleted.	Ensure the power bank is fully charged and securely connected to the hoodie's USB cable.
Indicator light is off.	Hoodie is off or power bank is depleted.	Press and hold the power button to turn on. Check power bank charge level.
Heat is inconsistent or weak.	Low power bank charge or incorrect setting.	Recharge the power bank. Adjust to a higher temperature setting. Ensure the hoodie fits snugly to maximize heat transfer.
Hoodie turns off automatically.	Power bank safety feature or depletion.	The power bank may have shut off due to low battery or a safety trigger. Recharge the power bank.

If the problem persists after attempting these solutions, please contact customer support.

9. SPECIFICATIONS

- **Model:** 2025 Model (SK-5148)
- **Material:** Cotton, Polyester
- **Heating Zones:** 6 (Chest, Back, Neck, Hood)
- **Temperature Levels:** 3 (High, Medium, Low)
- **High Temperature:** 50-55°C (122-131°F)
- **Medium Temperature:** 45-50°C (113-122°F)
- **Low Temperature:** 40-45°C (104-113°F)
- **Power Bank:** 10000 mAh, 5V 2A Output
- **Run Time:** Up to 7-8 hours (depending on setting)
- **Care Instructions:** Machine Washable (remove power bank)

10. WARRANTY AND SUPPORT

Your Loowoko Heated Hoodie comes with a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact your retailer. If you have any questions, require technical assistance, or need to report an issue, please do not hesitate to contact our customer support team. Contact information can typically be found on the product packaging or the official Loowoko website.