

[manuals.plus](#) /

› [SZHKHXD](#) /

› **SZHKHXD Remote Control User Manual for Teco Portable Air Conditioners (Models TPO35CFWCT, TPO41CFWCT, TPO35HFWCT, TPO41HFWCT)**

SZHKHXD TPO35CFWCT, TPO41CFWCT, TPO35HFWCT, TPO41HFWCT

SZHKHXD Remote Control User Manual

For Teco Portable Air Conditioners (Models TPO35CFWCT, TPO41CFWCT, TPO35HFWCT, TPO41HFWCT)

1. INTRODUCTION

This document provides essential instructions for the operation and maintenance of your SZHKHXD replacement remote control. This remote is designed to be compatible with specific Teco Portable Window Air Conditioner models: TPO35CFWCT, TPO41CFWCT, TPO35HFWCT, and TPO41HFWCT. Please ensure your original remote control matches the appearance of this unit for proper functionality.



Figure 1: Front view of the SZHKHXD replacement remote control, showing the display screen and various control buttons.

2. SETUP

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.



Figure 2: Back view of the remote control with the battery cover removed, illustrating the battery compartment for AAA batteries.

2.2 Initial Use

This remote control is an infrared replacement unit and typically requires **no programming**. Once batteries are correctly installed, it should function directly with compatible Teco Portable Air Conditioner models. Point the remote directly at the air conditioner's infrared receiver.

3. OPERATING INSTRUCTIONS

The remote control features various buttons for controlling your Teco Portable Air Conditioner. Refer to the button descriptions below:

- **Power Button ()**: Turns the air conditioner ON or OFF.
- **Mode Button (MODE)**: Cycles through operating modes such as Cool, Dry, Fan, and Heat (if applicable to your AC model).
- **Temperature Adjustment Buttons (▲ / ▼)**: Increases or decreases the set temperature.
- **Fan Speed Button (FAN SPEED)**: Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Timer Button (TIMER)**: Sets the timer for automatic ON/OFF operation. Refer to your air conditioner's manual for specific timer settings.
- **Sleep Button (SLEEP)**: Activates or deactivates the sleep mode, which adjusts temperature for

comfortable sleep.

- **Swing Button (SWING):** Controls the louver swing function for air direction.
- **°C/°F Button:** Toggles the temperature display between Celsius and Fahrenheit.
- **Favorite/Star Button (★):** May be used to set or recall a preferred operating setting. Consult your air conditioner's manual for details.

4. MAINTENANCE

4.1 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's finish or internal components.

4.2 Battery Replacement

Replace batteries when the remote's range decreases or if the display becomes dim or unresponsive. Always replace both batteries simultaneously with new AAA batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.

5. TROUBLESHOOTING

• Remote not responding:

- Check if the batteries are inserted correctly and are not depleted. Replace if necessary.
- Ensure there are no obstructions between the remote control and the air conditioner's infrared receiver.
- Confirm that the remote is pointed directly at the air conditioner.

• Incorrect functionality:

- Verify that your air conditioner model is listed as compatible with this remote control. This remote is specifically designed for Teco models TPO35CFWCT, TPO41CFWCT, TPO35HFWCT, and TPO41HFWCT.
- If your air conditioner model is not listed, this remote may not be compatible.

6. SPECIFICATIONS

- **Product Dimensions:** 3 x 2 x 4 inches
- **Item Weight:** 2.29 ounces
- **Batteries Required:** 2 x AAA (not included)
- **Connectivity Technology:** Infrared
- **Special Feature:** Ergonomic, No Programming Required
- **Max Number of Supported Devices:** 1
- **Compatible Devices:** Teco Portable Window Air Conditioners (TPO35CFWCT, TPO41CFWCT, TPO35HFWCT, TPO41HFWCT)
- **Manufacturer:** SZHKHDX

7. WARRANTY AND SUPPORT

This product is manufactured by SZHKHXD. For support or inquiries regarding this replacement remote control, please contact the seller or manufacturer directly through your purchase platform. Please note that specific warranty details may vary and are typically provided at the point of purchase.

© 2025 SZHKHXD. All rights reserved.

Documents - SZHKHXD – TPO35CFWCT,TPO41CFWCT,TPO35HFWCT,TPO41HFWCT
no relevant documents