

PRETZI PB70-8COL-BLK

PRETZI 70" Fireplace TV Stand with 23" Electric Fireplace

Model: PB70-8COL-BLK

INTRODUCTION

Thank you for purchasing the PRETZI 70" Fireplace TV Stand. This versatile entertainment center combines a modern TV stand with a 23" electric fireplace, offering both media storage and a cozy ambiance. This manual provides essential information for safe assembly, operation, and maintenance of your new product.

SAFETY INFORMATION

- **Important Note:** Your order arrives in two separate boxes (one for the TV stand components and one for the fireplace unit). These may be delivered on different days. Please ensure all packages are received before beginning assembly.
- Always place the TV stand on a flat, stable surface.
- Do not overload shelves or the top surface. The TV stand is designed for TVs up to 80 inches.
- The electric fireplace is equipped with an overheat protection feature for extra safety. Do not block the air vents of the fireplace.
- Keep flammable materials away from the fireplace unit.
- Ensure all electrical connections are secure and follow local electrical codes.

PACKAGE CONTENTS

Before assembly, verify that all components listed in your product's detailed instructions are present. The package includes:

- TV Stand wooden panels and hardware (screws, dowels, cam locks, etc.)
- 23" Electric Fireplace unit
- LED lighting kit with remote control
- Fireplace remote control
- Glass shelves for side cabinets


Refer to the included assembly manual for a complete list of parts and hardware.

SETUP & ASSEMBLY

Assembly is required. It is recommended to have two people for quicker and safer assembly. A power drill may be helpful for some steps.


1. **Unpack and Organize:** Carefully unpack all components from both boxes. Lay out and organize all wooden panels, hardware, and the fireplace unit. Identify each part using the labels in your instruction manual.
2. **Assemble Base and Frame:** Follow the step-by-step diagrams in your manual to connect the base panels and side supports of the TV stand using the provided screws and cam locks.
3. **Install Fireplace Unit:** Once the central compartment of the TV stand is assembled, carefully slide the 23" electric fireplace unit into its designated slot. Secure it according to the manual's instructions.
4. **Attach Side Panels and Doors:** Continue assembling the side cabinets, attaching the doors using the provided hinges.
5. **Insert Glass Shelves:** Place the glass shelves into the adjustable supports within the side cabinets.
6. **Install LED Lighting:** Affix the LED light strips to the designated areas within the open shelves and cabinets. Connect the power supply for the LED lights.
7. **Final Touches:** Ensure all screws are tightened and the unit is stable. Connect the power cord for the electric fireplace to a suitable outlet.

PACKAGE 1



***SHIPPED BY 2 BOXES SAME TIME,
DELIVERY TIME MAY BE DIFFERENT DAY**

PACKAGE 2



**DELIVERY IN
2 BOXES**



TV STAND

FIREPLACE

Figure 1: Product dimensions and packaging details. The TV stand and fireplace ship in two separate boxes.



Figure 2: Overview of the assembled TV stand, highlighting storage cabinets and structural features.

OPERATING INSTRUCTIONS

Electric Fireplace Operation

The 23" electric fireplace can be operated using the control panel on the unit or the included remote control.

- **Power:** Press the power button to turn the fireplace ON or OFF.
- **Flame Colors:** Cycle through 7 realistic flame color options to suit your mood.
- **Heat Settings:** Adjust the 1500W heater output to warm rooms up to 400 sq. ft.
- **Timer:** Set the automatic shut-off timer for 0 to 8 hours.
- **Brightness:** Adjust the brightness of the flame effect.



7 FLAME COLORS ADJUSTABLE





Figure 3: The electric fireplace offers 7 adjustable flame colors to customize your ambiance.

PACKAGE 1



PACKAGE 2




Figure 4: Fireplace remote control functions, including timer, heat settings, and flame color adjustments.

LED Lighting Kit Operation

The integrated LED lighting kit enhances the atmosphere of your entertainment center.

- **Colors:** Choose from 15 changeable static colors.
- **Control:** Use the dedicated remote control to select colors, adjust brightness, and activate various lighting modes.



Figure 5: The LED lighting kit offers 15 static colors and various adjustable controls via remote.

MAINTENANCE

- **Cleaning Surfaces:** Wipe the TV stand surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals that could damage the finish.
- **Fireplace Unit:** Ensure the air intake and exhaust vents of the electric fireplace remain clear of dust and debris to maintain optimal performance and prevent overheating.
- **Glass Shelves:** Clean glass shelves with a glass cleaner and a soft cloth.

TROUBLESHOOTING

- **Fireplace not turning on:** Check if the power cord is securely plugged into a working outlet. Ensure the power button on the unit or remote is pressed.
- **Heater not producing heat:** Verify that the heater function is activated via the control panel or remote. Check for any obstructions around the air vents.
- **LED lights not working/changing:** Ensure the LED light kit's power supply is connected. Check the remote control battery and ensure it's pointed directly at the receiver.
- **Overheating:** If the fireplace automatically shuts off, it may be due to overheating. Unplug the unit, allow it to cool down, and ensure vents are clear before restarting.

SPECIFICATIONS

- **Brand:** PRETZI
- **Model Name:** PB70-8COL-BLK
- **Product Dimensions:** 13.8"D x 70"W x 24.3"H
- **Material:** Wood
- **Color:** Black
- **Power Source:** Corded Electric
- **Heat Output:** 1500 Watts
- **Special Feature:** Adjustable Flame
- **Installation Type:** Freestanding
- **Item Weight:** 76.7 Pounds
- **TV Size Compatibility:** Up to 80 inches

SUPPORT

For any questions or assistance, 24/7 customer support is available to help you.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question