

HOUROM 9-Drawer Dresser

HOUROM 9-Drawer Dresser Instruction Manual

Model: 9-Drawer Dresser (ASIN: B0FVLMMVSZ)

1. INTRODUCTION

Thank you for choosing the HOUROM 9-Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

Important Safety Information

To prevent serious injury, always follow the assembly instructions and safety guidelines. This dresser must be securely anchored to a wall using the provided anti-tipping hardware. Failure to do so can result in furniture tip-over, leading to severe or fatal injuries.

2. SETUP AND ASSEMBLY

The HOUROM 9-Drawer Dresser requires assembly. Please ensure all parts are present before you begin. An electronic screwdriver can expedite the assembly process, but all necessary tools are included.

Assembly Steps (General Guidelines)

- Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the parts list (not provided in this document, refer to your product's included manual) to identify each piece.
- Assemble the Frame:** Follow the step-by-step diagrams in your product manual to construct the main frame of the dresser. Ensure all connections are secure.
- Attach Legs:** Secure the four solid wood legs to the base of the dresser. These legs are designed for stability and durability.
- Install Drawer Slides:** Attach the buffer track drawer slides to the dresser frame according to the instructions.
- Assemble Drawers:** Construct each of the nine drawers. Ensure the bottom panels are correctly inserted and secured.
- Insert Drawers:** Carefully slide the assembled drawers into their respective tracks.
- Install Anti-Tipping Hardware:** This is a critical safety step. Securely attach the anti-tipping hardware to the back of

the dresser and to a wall stud using appropriate fasteners. This prevents the dresser from accidentally tipping over.

PRODUCT SIZE



Image: Product dimensions (63"W x 15.7"D x 30.7"H) and individual drawer capacity (40 lbs, 19.9"L x 12.6"W x 7.5"H).




Image: Illustrates the durable solid wood legs of the HOUROM dresser compared to engineered wood legs found in other products.

3. OPERATING INSTRUCTIONS

The HOUROM 9-Drawer Dresser is designed for convenient and silent operation, providing ample storage for your bedroom or other living spaces.

Drawer Operation

Each drawer features a buffer track system for smooth and silent operation. To open a drawer, gently pull it forward. The buffer track ensures a quiet glide. To close, push the drawer gently until it retracts fully and silently. The concealed handle design minimizes external protrusions, contributing to a sleek aesthetic and reducing the risk of accidental bumps.

9 SPACIOUS DRAWERS

Perfect for Storage & Organization



Large 63"
Dresser



9 Drawers



Smooth



Durable

SMOOTH SLIDES

Smooth-Glide Metal Rails

Image: Demonstrates the nine spacious drawers and the smooth-glide metal rails for effortless opening and closing.

Storage Capacity

With nine large drawers, this dresser offers expansive storage. The deep drawers are suitable for accommodating various items such as sweaters, bedding sets, clothing, and accessories, helping to maintain an organized living space.

Video: An official HOUROM video showcasing the dresser's features and smooth drawer operation.

4. MAINTENANCE

Proper care will ensure the longevity and appearance of your HOUROM dresser.

Cleaning

The dresser features a water-resistant surface, making it easy to clean. Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish. Dry immediately with a clean,

soft cloth.

General Care

- Avoid placing hot items directly on the surface. Use coasters or protective pads.
- Protect from direct sunlight and extreme temperature changes to prevent warping or fading.
- Periodically check all screws and fasteners to ensure they are tight. Retighten as necessary.



Image: Highlights the water-resistant surface for easy cleaning and the anti-tip safety mechanism.

5. TROUBLESHOOTING

If you encounter any issues with your dresser, please refer to the following common solutions:

Drawer Not Sliding Smoothly

- Check if the drawer is properly aligned on its tracks.

- Ensure no objects are obstructing the drawer slides.
- Verify that all screws securing the drawer slides to both the drawer and the dresser frame are tight.

Dresser Appears Unstable

- Confirm that the dresser is placed on a level surface.
- Check that all leg attachments are secure.
- Ensure the anti-tipping hardware is correctly installed and securely fastened to both the dresser and the wall.

If problems persist, please contact HOUROM customer support for assistance.

6. SPECIFICATIONS

Feature	Detail
Brand	HOUROM
Material	Engineered Wood
Finish Type	Painted
Product Dimensions (D x W x H)	63" x 15.7" x 30.7"
Number of Drawers	9
Mounting Type	Floor Mount
Required Assembly	Yes

7. WARRANTY AND SUPPORT

Warranty Information

HOUROM is committed to providing quality products. While specific warranty details are provided with your purchase, generally, our products are covered against manufacturing defects for a limited period from the date of purchase. Please refer to the warranty card included in your packaging for full terms and conditions.

Customer Support

Should you have any questions regarding assembly, parts, operation, or require assistance with your HOUROM 9-Drawer Dresser, please do not hesitate to contact our customer support team. We are dedicated to providing sincere and effective service.

Contact Information:

Please refer to the contact details provided in your product packaging or visit the official HOUROM website for support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question