



[Manuals.plus](#) /

› [SICOTAS](#) /

› SICOTAS 6-Drawer Dresser (Model DR116A1XWTY1354) User Manual

SICOTAS DR116A1XWTY1354

SICOTAS 6-Drawer Dresser (Model DR116A1XWTY1354) User Manual

Model: DR116A1XWTY1354 | Brand: SICOTAS

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your SICOTAS 6-Drawer Dresser. Please read all instructions carefully before assembly and use to ensure safe and proper functionality. Keep this manual for future reference.

SAFETY INFORMATION

- **Anti-Tip Kit:** Always install the included anti-tip wall anchor to prevent serious injury from tipping furniture. This is especially important in homes with children or pets.
- **Weight Limits:** Do not exceed the maximum weight capacity for the top surface (77 lbs) or individual drawers (16 lbs). Overloading can cause structural damage or tipping.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all parts are correctly aligned and fasteners are tightened securely. Do not overtighten screws.
- **Placement:** Place the dresser on a level surface to ensure stability. Uneven surfaces can cause drawers to malfunction or the unit to become unstable.
- **Children:** Do not allow children to climb on or play with the dresser. Keep small parts away from children during assembly.

PARTS LIST

Your SICOTAS 6-Drawer Dresser includes various components for assembly. Please verify all parts are present and undamaged before beginning. Refer to the separate assembly guide for a detailed list of hardware and panels. Included Components: 56.4" Extra-Wide Dresser, assembly hardware, and anti-tip kit.

SETUP AND ASSEMBLY

Assembly is required for this dresser. Follow the step-by-step instructions provided in the separate assembly manual. Ensure you have adequate space and the necessary tools (usually a screwdriver and hammer, often included).

Drawer Slide Installation Tip:

Proper installation of drawer slides is crucial for smooth operation. If a drawer does not slide smoothly, it may be due to incorrect alignment or ball bearings falling out. Refer to the video below for guidance on proper drawer slide installation and troubleshooting.

Your browser does not support the video tag.

Video Description: This video demonstrates how to properly install drawer slides and provides a quick fix guide for drawers that are not sliding smoothly. It covers steps like sliding the inner rail forward, placing the drawer level and straight, aligning one side first, and how to remove the drawer by pulling down or up on the release lever if realignment is needed. This helps prevent ball bearings from falling out and damaging the slide.

For visual assistance with assembly steps, please refer to the images below which illustrate the product's design and features.



Image Description: A full view of the SICOTAS 6-Drawer Dresser in Grey White Oak, featuring six drawers with gold-colored handles, placed in a bedroom setting with a lamp and decorative items on top.

Large Size & Ample Space



Max Load

Top: 77 lbs | Drawer: 16 lbs

Drawer Dimensions

24.1" (W) X 13.2" (D) X 5.8" (H)

Image Description: An illustration detailing the dimensions of the SICOTAS 6-Drawer Dresser. The overall dimensions are 56.4" W x 16.9" D x 31.3" H. Individual drawer dimensions are 24.1" W x 13.2" D x 5.8" H. The maximum load for the top is 77 lbs, and for each drawer is 16 lbs.



❶ 3D Design



❷ Metal Handle



❸ Sturdy Wood



❹ Raised Edge

Image Description: A composite image showing close-up details of the dresser. It highlights the 3D design on the drawer fronts, the metal handles, the sturdy wood construction, and the raised edge on the top surface.

OPERATING INSTRUCTIONS

- **Opening/Closing Drawers:** Use the provided handles to gently pull and push the drawers. Avoid forcing drawers, especially if they feel stiff.
- **Weight Distribution:** Distribute items evenly within the drawers to prevent strain on the slides and maintain balance.
- **Top Surface Use:** The top surface can hold items up to 77 lbs. Ensure any items placed on top are stable and do not overhang excessively.

6-Drawer Storage with Spacious Capacity



Image Description: An overhead view of the SICOTAS 6-Drawer Dresser with several drawers partially open, revealing neatly organized clothing and other items, demonstrating its storage capacity.

MAINTENANCE

- **Cleaning:** Wipe the dresser with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the wood grain finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage to the engineered wood.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure the dresser remains stable.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the finish.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Drawer does not slide smoothly.	Misaligned drawer slides or dislodged ball bearings.	Gently remove the drawer by pulling down on the release lever (or up, depending on the slide mechanism), realign the slides, and reinsert. Refer to the "Drawer Not Sliding? Quick Fix Guide" video in the Setup section.
Dresser feels unstable or wobbly.	Loose fasteners or uneven placement.	Ensure all assembly screws are tightened. Adjust the feet if present, or place shims under the base to level the dresser on an uneven floor. Confirm the anti-tip kit is securely installed.
Parts missing or damaged upon arrival.	Shipping damage or packaging error.	Contact SICOTAS customer service immediately for assistance and replacement parts.

SPECIFICATIONS

- **Brand:** SICOTAS
- **Model Name:** Dresser
- **Model Number:** DR116A1XWTY1354
- **Material:** Engineered Wood
- **Finish Type:** Wood Grain
- **Color:** Grey White Oak
- **Product Dimensions (D x W x H):** 16.93" x 56.42" x 31.3"
- **Number of Drawers:** 6
- **Drawer Type:** Ball Bearing Slide
- **Item Weight:** 59.2 Kilograms
- **Max Load (Top):** 77 lbs
- **Max Load (Drawer):** 16 lbs
- **Assembly Required:** Yes
- **GTIN:** 635508493049

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact SICOTAS customer service. SICOTAS provides customer service seven days a week to assist with any questions or concerns regarding your product.

If you encounter any issues or require assistance, please contact SICOTAS customer support through the retailer where the product was purchased or visit the official SICOTAS website for contact details.