

## JVC HAS59WA

# JVC HAS59WA Wireless Headphones Instruction Manual

Model: HAS59WA

## INTRODUCTION

---

Thank you for choosing JVC HAS59WA Wireless Headphones. These headphones are designed to provide pleasant sound quality and extended battery life in a comfortable, foldable design. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your headphones to ensure optimal performance.



*Front view of JVC HAS59WA Wireless Headphones in Retro Blue.*

## SETUP

---

### 1. Initial Charging

Before first use, fully charge your JVC HAS59WA headphones. A full charge takes approximately 2 hours and provides up to 50 hours of playback time.

1. Connect the provided USB charging cable to the charging port on the headphones.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging and turn off once fully charged.



*Close-up of the charging port and other connections on the JVC HAS59WA headphones.*

## 2. Bluetooth Pairing

The headphones support Bluetooth 5.3 for stable wireless connection and multipoint connectivity for seamless switching between two devices.

1. **Power On:** Press and hold the Power button on the headphones until the indicator light flashes blue and red, indicating pairing mode.
2. **Enable Bluetooth:** On your device (smartphone, tablet, laptop), enable Bluetooth.
3. **Select Device:** Search for 'JVC HAS59WA' in the list of available Bluetooth devices and select it to pair.
4. **Confirmation:** Once paired, the indicator light will flash blue slowly, and you may hear an audible confirmation.
5. **Multipoint Connection:** To connect a second device, disable Bluetooth on the first device temporarily, put the headphones back into pairing mode, and connect to the second device. Then, re-enable Bluetooth on the first device. The headphones will maintain connection with both.

# JVC

for your

*Own Style*



## WIRELESS / SANS FIL

WIRELESS HEADPHONES  
CASQUE SANS FIL  
CUFFIE SENZA FILI  
AURICULARES INALÁMBRICOS  
KABELLOSER KOPFHÖRER

# HA-S59W

*Diagram illustrating multipoint connection feature, connecting to a phone and a laptop simultaneously.*

### 3. App Equalizer (EQ) Setup

Customize your audio experience using the JVC Headphones app.

1. Download the 'JVC Headphones' app from your device's app store.
2. Ensure your headphones are connected via Bluetooth to your device.

3. Open the app and follow the on-screen instructions to connect to your HAS59WA headphones.
4. Use the app's equalizer to fine-tune the audio to your preferred sound profile.



*Screenshot of the JVC Headphones app interface showing equalizer settings.*

## OPERATING INSTRUCTIONS

### 1. Basic Controls

The headphones feature intuitive touch controls for managing audio playback and calls.

- **Power On/Off:** Press and hold the Power button.
- **Play/Pause:** Single tap the multi-function button.
- **Volume Up/Down:** Use the dedicated volume buttons.
- **Next/Previous Track:** Double-tap or triple-tap the multi-function button (refer to specific model instructions for exact sequence).
- **Answer/End Call:** Single tap the multi-function button during an incoming call.
- **Reject Call:** Press and hold the multi-function button during an incoming call.



*Side view of JVC HAS59WA Wireless Headphones, showing control buttons and ports.*

## **2. Wired Connection**

For situations where wireless connection is not preferred or battery is low, you can use the included 3.5mm audio cable.

1. Plug one end of the 3.5mm audio cable into the headphone's audio jack.
2. Plug the other end into your audio source's 3.5mm jack.
3. The headphones will automatically switch to wired mode.



*Image illustrating wired connection support, app EQ, and multipoint connection.*

### 3. Hands-Free Calls

The built-in microphone allows for clear, hands-free calls when connected via Bluetooth.

- Ensure your headphones are paired with your phone.
- Use the multi-function button to answer or end calls as described in the 'Basic Controls' section.

## MAINTENANCE

---

### 1. Cleaning

To maintain the condition and hygiene of your headphones:

- Wipe the ear cushions and headband with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water and a mild soap solution, then wipe dry immediately.
- Avoid using harsh chemicals, solvents, or abrasive cleaners.
- Do not immerse the headphones in water.

### 2. Storage

The flat-foldable design allows for convenient storage and portability.

- Fold the earcups flat to reduce the headphone's profile.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid placing heavy objects on the headphones during storage.



Diagram illustrating the foldable design and comfort features.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully (approx. 2 hours).
Cannot pair via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; too many paired devices.	Ensure headphones are in pairing mode (flashing blue/red). Turn device Bluetooth off/on. Forget previous pairings on your device and try again.
No sound or poor sound quality.	Volume too low; incorrect audio source; EQ settings.	Increase volume on headphones and device. Ensure correct audio output is selected on your device. Adjust EQ settings via the JVC Headphones app.
Intermittent Bluetooth connection.	Distance from device; interference; low battery.	Reduce distance between headphones and device. Avoid areas with strong Wi-Fi or other wireless interference. Charge headphones.
Microphone not working during calls.	Incorrect audio input selected on device; headphones not fully connected.	Ensure 'JVC HAS59WA' is selected as the audio input/output device on your phone/computer. Re-pair headphones.

## SPECIFICATIONS

Feature	Detail
Brand	JVC
Model Number	HAS59WA
Ear Placement	On Ear
Connectivity Technology	Bluetooth, Wireless
Bluetooth Version	5.3
Additional Features	Multipoint Pairing, Built-in Mic, App EQ
Battery Life	Up to 50 Hours
Battery Charge Time	2 Hours
Headphone Jack	3.5 mm Jack (for wired connection)
Control Type	Volume Control, Touch
Audio Driver Type	Dynamic Driver (30mm)
Frequency Range	20 Hz - 20,000 Hz
Weight	3.2 ounces
Material	Fabric, Silicone
Included Components	Headband, Cable, User Manual

## WARRANTY INFORMATION

---

The JVC HAS59WA Wireless Headphones come with a **1-Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty card included in your product packaging or visit the official JVC website.

## SUPPORT

---

For further assistance, product registration, or to explore other JVC products, please visit the official JVC website or contact customer support.

- **Official JVC Store:** [Visit the JVC Store on Amazon](#)
- **Customer Service:** Refer to your product packaging for regional contact information or visit the JVC global support page.

## Official Product Video

Your browser does not support the video tag.

*Official product video demonstrating the features and design of the JVC HAS59WA On-Ear Wireless Headphones.*

© 2026 JVC. All rights reserved.