

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Homsee](#) /

› [Homsee 12-Drawer Solid Wood Baby Changing Table Dresser Instruction Manual](#)

## Homsee XQ-KF330183-01 H

# Homsee 12-Drawer Solid Wood Baby Changing Table Dresser Instruction Manual

Model: XQ-KF330183-01 H

[Introduction](#)   [Safety Information](#)   [Package](#)  
[Contents](#)   [Assembly](#)   [Operation](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Support](#)

## 1. INTRODUCTION

Thank you for choosing the Homsee 12-Drawer Solid Wood Baby Changing Table Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference. This product is designed to provide a secure and organized space for infant care and storage.


## 2. SAFETY INFORMATION

Your child's safety is our top priority. Please adhere to the following safety guidelines:

- **Anti-Tip Kit:** Always install the provided anti-tip kits to securely anchor the dresser to the wall. This prevents accidental tipping, which can cause serious injury or death.
- **Supervision:** Never leave an infant unattended on the changing table, even for a moment. Always keep a hand on your child while they are on the changing surface.
- **Changing Pad:** Ensure any changing pad used fits securely within the changing tray and has safety straps. (Changing pad/mattress is not included with this product).
- **Weight Limits:** Do not exceed the recommended weight limits for the top surface or drawers. Refer to the 'Specifications' section for details.
- **Assembly:** Ensure all parts are correctly assembled and all fasteners are tightened before use. Periodically check all connections for tightness.
- **Hazardous Items:** Keep all cords, strings, and small objects away from the changing area to prevent choking or strangulation hazards.
- **Material Safety:** This dresser is constructed from 100% solid pine wood and finished with child-safe varnish, ensuring a healthier environment for your child.

# Anti-tipping Device

Enhances safety, prevents tipping accidents, secures stability, promotes household peace of mind.



**Figure 2.1: Anti-Tipping Device.** This image illustrates the anti-tipping device, showing how it secures the dresser to the wall to prevent accidents. It highlights the difference between a secured dresser and one that is not, emphasizing the importance of installation.

## 3. PACKAGE CONTENTS

Before assembly, please verify that all components are present and undamaged. Refer to the detailed parts list included in your assembly guide for a complete inventory. If any parts are missing or damaged, please contact customer support immediately.

## 4. ASSEMBLY INSTRUCTIONS

Assembly of this dresser requires careful attention to detail. We recommend having two people for safer and easier installation due to the item's size and weight.

1. **Unpack and Inspect:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Check against the parts list in your separate assembly manual to ensure everything is present and undamaged.
2. **Follow Step-by-Step Guide:** Refer to the dedicated step-by-step assembly guide provided in the packaging. Each step is illustrated to assist you.
3. **Frame Assembly:** Begin by assembling the main frame of the dresser, ensuring all connections are tight

and secure.

4. **Drawer Assembly:** Assemble each of the 12 drawers according to the instructions. Ensure drawer slides are installed correctly for smooth operation.
5. **Changing Tray Installation:** Attach the removable changing tray to the top of the dresser. Ensure it is securely fastened and stable.
6. **Install Anti-Tip Kit:** As a crucial safety measure, install the anti-tip kit (refer to Figure 2.1 in the Safety Information section) to anchor the dresser to a wall stud.
7. **Final Check:** Once assembled, gently shake the dresser to ensure stability. Re-tighten any loose fasteners.



**Figure 4.1: Overall Dimensions.** This diagram provides detailed measurements of the dresser and its components, useful for planning placement and understanding the scale during assembly.

## 5. OPERATING INSTRUCTIONS

---

This Homsee dresser is designed for versatile use in a nursery or child's room.

- **Changing Station:** The top surface with the removable tray serves as a dedicated changing station. Place a suitable changing pad (not included) within the tray. Always keep essential changing supplies within easy reach but out of the infant's grasp.
- **Drawer Storage:** The 12 spacious drawers provide ample storage for baby essentials such as diapers, wipes, clothing, and toiletries. Organize items logically for quick access.

- **Removable Tray:** The changing tray can be removed as your child grows, converting the unit into a standard dresser for long-term use.



**Figure 5.1: Drawer Storage.** This image demonstrates the ample storage capacity of the 12 drawers, showing various baby items neatly organized within.



**Figure 5.2: Changing Tray Detail.** A close-up view of the removable changing tray, highlighting its design and secure placement on the dresser top.

## 6. MAINTENANCE

---

Proper care will ensure the longevity and safety of your Homsee dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the wood finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood.
- **Fastener Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Drawer Slides:** If drawers become stiff, clean the tracks and apply a small amount of silicone-based lubricant if needed.
- **Environmental Conditions:** Avoid placing the dresser in direct sunlight or near heat sources, which can cause wood to dry out, crack, or warp. Maintain a stable room temperature and humidity.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your dresser, refer to the following common solutions:

Problem	Possible Cause	Solution
Drawers do not close smoothly or are misaligned.	Incorrect drawer slide installation; loose fasteners; uneven assembly.	Check that drawer slides are installed correctly and are free of obstructions. Ensure all drawer and frame fasteners are tight. Disassemble and reassemble the affected drawer if necessary, ensuring square alignment.
Dresser feels wobbly or unstable.	Loose frame fasteners; anti-tip kit not installed or improperly installed.	Ensure all frame screws and bolts are fully tightened. Verify the anti-tip kit is securely anchored to a wall stud.
Missing parts or damaged components upon arrival.	Shipping damage; packaging error.	Do not proceed with assembly. Contact Homsee customer support immediately for replacement parts.

## 8. PRODUCT SPECIFICATIONS

---

**Model Number:** XQ-KF330183-01 H

**Material Type:** 100% Solid Pine Wood

**Overall Dimensions:** 59.9"W x 18.9"D x 40.2"H (with changing tray)

**Top Weight Capacity:** 132 lbs

**Drawer Weight Capacity:** 22 lbs per drawer

**Number of Drawers:** 12

**Color:** Nature Color

## 9. WARRANTY AND CUSTOMER SUPPORT

---

Homsee is committed to providing high-quality products and customer satisfaction. While specific warranty details are provided with your purchase documentation, our support team is always ready to help with any questions or concerns you may have regarding assembly, parts, or product functionality.

For assistance, please refer to the contact information provided in your purchase documentation or visit the official Homsee website.