

[manuals.plus](#) /› [Boytond](#) /› [Boytond S30i Ultra Open Ear Earbuds User Manual](#)**Boytond S30i**

Boytond S30i Ultra Open Ear Earbuds User Manual

Model: S30i

1. INTRODUCTION

Thank you for choosing the Boytond S30i Ultra Open Ear Earbuds. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new earbuds. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

2. PRODUCT OVERVIEW

The Boytond S30i earbuds feature an innovative open-ear, clip-on design, providing comfort and situational awareness. They utilize Bluetooth 5.3 for stable wireless connectivity and are designed to be waterproof, making them suitable for various activities including sports and travel. Please note that while some descriptions may refer to 'bone conduction technology', these earbuds function as open-ear headphones that deliver sound through dynamic drivers positioned near the ear canal, rather than directly vibrating the bone.



Image 2.1: Boytond S30i Ultra Open Ear Earbuds. This image displays the sleek, black, ergonomic design of the earbuds, highlighting the clip-on structure and the placement of the control buttons.

Package Contents:

- Boytond S30i Ultra Open Ear Earbuds
- Charging Case
- USB Charging Cable
- User Manual (this document)

3. SETUP

3.1 Charging the Earbuds and Case

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the charging case to a power source using the provided USB charging cable.
3. The digital display on the charging case will indicate the battery level. Allow approximately 10 hours for a full charge of the case and earbuds.
4. Once fully charged, disconnect the charging cable.

3.2 Pairing with a Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED light (refer to product for specific LED indicator behavior).
3. On your smartphone, tablet, laptop, or other compatible device, navigate to the Bluetooth settings.
4. Search for available devices and select "Boytond S30i" from the list.
5. Once connected, the LED indicator on the earbuds will stop flashing, and your device will confirm the connection.
6. The earbuds will automatically reconnect to the last paired device when removed from the case and within range.

3.3 Wearing the Earbuds

- Identify the left (L) and right (R) earbuds.
- Gently clip the earbuds onto your ears, positioning them comfortably so the sound drivers are directed towards your ear canals.
- Adjust for a secure yet comfortable fit. The open-ear design allows for ambient sound awareness.

4. OPERATING INSTRUCTIONS

The Boytond S30i earbuds feature intuitive controls, often managed via physical buttons on the earbuds or through a dedicated application on your smartphone.

4.1 Power On/Off

- **Power On:** Open the charging case, or press and hold the control button on each earbud for approximately 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or press and hold the control button on each earbud for approximately 5 seconds.

4.2 Music Playback

- **Play/Pause:** Single press the control button on either earbud.
- **Next Track:** Double press the control button on the right earbud.
- **Previous Track:** Double press the control button on the left earbud.
- **Volume Up:** Triple press the control button on the right earbud.
- **Volume Down:** Triple press the control button on the left earbud.

4.3 Call Management

- **Answer/End Call:** Single press the control button on either earbud during an incoming call or an active call.
- **Reject Call:** Press and hold the control button on either earbud for 2 seconds during an incoming call.

4.4 Voice Assistant

- **Activate Voice Assistant:** Press and hold the control button on either earbud for 2 seconds (when not on a call).

4.5 App Control

The Boytond S30i earbuds support control via a dedicated application. Please refer to the product packaging or manufacturer's website for information on downloading and using the official Boytond app for additional features and customization.

5. MAINTENANCE

5.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Ensure charging contacts are free of dust and debris.

5.2 Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place, away from extreme temperatures and direct sunlight.

5.3 Battery Care

- To preserve battery life, fully charge the earbuds and case at least once every three months if not used regularly.
- Avoid completely draining the battery frequently.

6. TROUBLESHOOTING

Problem	Solution
Earbuds do not power on.	Ensure the earbuds and charging case are fully charged.
Earbuds do not pair with device.	<ol style="list-style-type: none">1. Ensure Bluetooth is enabled on your device.2. Make sure earbuds are in pairing mode.3. Forget "Boytond S30i" from your device's Bluetooth list and try pairing again.4. Ensure earbuds are within 10 meters of your device.
No sound or low volume.	<ol style="list-style-type: none">1. Check the volume levels on both the earbuds and your connected device.2. Ensure earbuds are properly seated on your ears.3. Reconnect the earbuds to your device.
Intermittent connection.	<ol style="list-style-type: none">1. Ensure there are no obstructions between the earbuds and your device.2. Move closer to your device (within 10 meters).3. Avoid environments with strong Wi-Fi or other wireless interference.
Charging case not charging.	<ol style="list-style-type: none">1. Check the USB cable and power adapter for damage.2. Ensure the charging cable is securely connected to both the case and the power source.3. Try a different charging cable or power adapter.

7. SPECIFICATIONS

Feature	Detail
Model Name	S30i
Brand	Boytond
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	10 Meters
Ear Placement	Open Ear, Clip-On
Audio Driver Type	Dynamic Driver
Water Resistance Level	Waterproof
Charging Time	10 Hours (for case and earbuds)
Compatible Devices	Smartphones, Tablets, Laptops, Desktops, Smart Speakers
Control Method	App, Physical Buttons
Item Weight	3.84 ounces
Noise Control	None

8. WARRANTY AND SUPPORT

Boytond products are designed for reliability and performance. For specific warranty information, please refer to the warranty card included with your product or visit the official Boytond website. If you encounter any issues or have questions not covered in this manual, please contact Boytond customer support through the contact information provided on the product packaging or the official website.

- **Online Support:** Visit the Boytond official website for FAQs and support resources.
- **Email Support:** Refer to your product packaging for customer service email.