

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [ELEMARA](#) /

> [ELEMARA Licensed Mercedes-Benz AMG G63 Electric Ride-On Car User Manual](#)

ELEMARA S306

ELEMARA Licensed Mercedes-Benz AMG G63 Electric Ride-On Car User Manual

Model: S306

INTRODUCTION

Thank you for choosing the ELEMARA Licensed Mercedes-Benz AMG G63 Electric Ride-On Car. This manual provides essential information for the safe assembly, operation, and maintenance of your new ride-on toy. Please read it thoroughly before use and retain it for future reference.

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not suitable for children under 36 months. The product contains small parts; keep children away when assembling.

- Always supervise children while they are using the ride-on toy.
- Ensure the child is within the recommended age range of 36 months to 6 years.
- Do not exceed the maximum weight capacity of 66 lbs (30 kg).
- Use the ride-on toy on flat, dry surfaces away from traffic, pools, or steep inclines.
- Always ensure the seat belt is securely fastened before operation.
- Keep hands, hair, and loose clothing away from moving parts.
- Only use the provided charger and battery. Do not use other chargers or batteries.
- The parental remote control should be used for younger children or when direct supervision is required.

PRODUCT OVERVIEW

The ELEMARA Mercedes-Benz AMG G63 Electric Ride-On Car is designed to provide an engaging driving experience for children. It features a realistic design, parental remote control, spring suspension, and multimedia functions.

Key Features:

- **1:1 Real AMG G63 Replica:** Meticulously crafted to reflect the iconic Mercedes-AMG G63 design.
- **Dual Control Modes:** Child-operated via foot pedal and steering wheel, or parental remote control.

- **Spring Suspension:** Provides a smooth and comfortable ride.
- **Multimedia Functions:** Built-in music, Bluetooth connectivity, horn, and LED lights.
- **Safety Features:** Seat belt, soft start function, and emergency brake button on remote.

Product Dimensions and Weight:

- **Product Dimensions:** 40.7 x 24.4 x 20.5 inches
- **Item Weight:** 34.3 pounds
- **Maximum Weight Capacity:** 66 lbs
- **Recommended Age:** 36 months - 6 years



Image: Side view of the ELEMARA Mercedes-Benz AMG G63 Electric Ride-On Car in white, showcasing its realistic design.

SETUP AND ASSEMBLY

The ride-on car requires assembly before first use. Please follow the instructions carefully. A detailed assembly video is also available for visual guidance.

Unboxing and Parts Check:

Upon opening the package, ensure all components listed in the manual are present. The package includes: Ride On Car*1, Remote Control*1, Manual*1.

Your browser does not support the video tag.

Video: Detailed assembly instructions for the ELEMARA Mercedes-Benz AMG G63 Electric Ride-On Car. This video guides you through each step of the assembly process.

Assembly Steps:

1. Remove the ride-on toy from its packaging and lay out all components.
2. Assemble the dashboard by connecting the wiring and securing it with screws.
3. Attach the front bracket to the chassis.
4. Install the foot pedals (left/right) and secure them.
5. Assemble the rear axle and motors, ensuring proper connection.
6. Attach the front and rear wheels, securing them with gaskets and nuts.
7. Connect all internal wiring, including the battery.
8. Assemble the steering wheel, ensuring it is securely attached and connected.
9. Attach the tailstock to the rear of the vehicle.
10. Install the windshield and secure it with screws.
11. Assemble the seat and fasten it into the chassis.
12. Attach the side mirrors and car windows (left/right).

OPERATING INSTRUCTIONS

Charging the Battery:

Before first use, fully charge the 12V rechargeable battery for 8-12 hours. Subsequent charges should be 8-12 hours. The car is protected while charging and cannot be started.

12V BATTERY




Image: Interior view of the ride-on car, showing the dashboard and seating area. The charging port is typically located near the dashboard or under the seat.

Parental Remote Control Mode:

For younger children, the parental remote control offers full control over speed and direction.

1. Press the 'ON/OFF' button on both the remote and the toy to activate.
2. Use the remote to control speed (low/medium/high) and direction (forward/reverse/left/right).
3. The remote also features an emergency stop button for immediate halting of the vehicle.



Image: The parental remote control for the ride-on car, showing buttons for speed, direction, and emergency stop.

Manual Driving Mode:

For older children, the car can be driven manually.

1. Press the 'ON/OFF' button on the toy.
2. Use the foot pedal for acceleration and the steering wheel for direction.
3. The gear shifter allows selection between forward and reverse.

Lights and Multimedia:

- **LED Headlights:** Press the light button on the toy or remote once for steady light, and twice for flashing light.
- **Bluetooth:** Pair the toy with your mobile phone to play music through the built-in speakers.

- **Horn:** Press the horn button on the steering wheel for sound.




Image: Front view of the ride-on car with its bright LED headlights illuminated.

MAINTENANCE

- Regularly check all screws, nuts, and connections to ensure they are tight.
- Keep the ride-on car clean by wiping it with a damp cloth. Avoid using harsh chemicals.
- Store the vehicle in a dry, cool place away from direct sunlight when not in use.
- Charge the battery at least once a month, even if not in use, to prolong its lifespan.
- Do not expose the battery to extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Car does not move.	Battery is low or not connected.	Charge the battery. Check battery connections.
Remote control not working.	Remote batteries are dead or not paired.	Replace remote batteries. Re-pair remote with car (refer to remote control section in full manual).
Lights not working.	Loose wire connection or faulty LED.	Check wiring connections to the lights. Contact customer support if issue persists.
Car moves slowly.	Low battery, overloaded, or rough terrain.	Charge battery fully. Reduce load. Use on smoother surfaces.

SPECIFICATIONS

- **Model Number:** S306
- **Battery:** 1 x 12V (included)
- **Manufacturer Recommended Age:** 36 months - 6 years
- **Product Dimensions:** 40.7 x 24.4 x 20.5 inches
- **Item Weight:** 34.3 pounds
- **Max Speed:** 3 mph (5 km/h)
- **Max Weight Capacity:** 66 lbs

WARRANTY AND SUPPORT

For warranty information, replacement parts, or technical support, please refer to the contact details provided in your product packaging or visit the official ELEMARA website. Keep your purchase receipt as proof of purchase.



Image: A selection of replaceable parts for the ELEMARA ride-on car, such as switches, charger, power button, motors, and battery. More details can be found in the full manual.