

## Ninja FS300

# Ninja FS300 SLUSHi Frozen Drink & Slushie Machine User Manual

Model: FS300

## 1. INTRODUCTION

The Ninja SLUSHi is a high-performance machine designed to create frozen drinks and slushies without the need for ice. It utilizes RapidChill Technology to freeze liquids evenly, producing smooth and flavorful results. The machine offers multiple preset settings for various drink types and allows for customization of thickness and texture. With a 72-oz. capacity, it is suitable for preparing multiple servings. The unit is designed for easy cleanup with dishwasher-safe components and a built-in rinse cycle.



Figure 1: Ninja SLUSHi Frozen Drink & Slushie Machine

## 2. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury. Read all instructions before using this appliance.

- Ensure the appliance is unplugged from the outlet when not in use and before cleaning.
- Do not immerse the appliance base in water or other liquids.
- Keep hands and utensils out of the vessel during operation to prevent injury.
- Do not operate any appliance with a damaged cord or plug.
- Use only attachments and accessories recommended by the manufacturer.
- This appliance is for household use only.
- Do not use the appliance for anything other than its intended use.
- Always ensure the vessel is properly assembled and secured before operation.

- Do not add hot ingredients or carbonated liquids to the vessel.
- Ensure liquids contain sufficient sugar (at least 4%) for proper freezing.

### 3. COMPONENTS

---

The Ninja SLUSHi machine includes the following components:

- Ninja SLUSHi 72oz. Frozen Drink & Slushie Machine Base
- 72oz. Vessel with Comfort Handle and Anti-Drip Spout
- Condensation Catch
- Auger
- 2-Part Drip Tray
- Removable Spout Shroud
- Inspiration Guide with 10 Recipes
- Ninja SLUSHi Travel Party Tote (included in this bundle)

### 4. SETUP

---

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the 72oz. vessel, auger, condensation catch, 2-part drip tray, and removable spout shroud with warm, soapy water. Rinse thoroughly and dry.
3. **Assemble Drip Tray:** Place the 2-part drip tray onto the machine base.
4. **Install Auger:** Insert the auger into the vessel, ensuring it is securely seated.
5. **Attach Vessel:** Place the vessel onto the machine base, aligning it properly until it clicks into place.
6. **Connect Power:** Plug the power cord into a standard electrical outlet.



## RapidChill Technology

Liquid is rotated 360° around a chilling cylinder to maintain the ideal temperature and texture.

Figure 2: Easy-fill vessel for convenient liquid addition.

### 5. OPERATING INSTRUCTIONS

The Ninja SLUSHi machine uses RapidChill Technology to transform liquids into frozen drinks. For optimal results, ensure your liquid contains at least 4% sugar. Sugar-free recipes can be made using recommended sugar substitutes.

#### 5.1. Preparing a Drink

1. **Add Liquid:** Pour your desired liquid into the 72oz. vessel. Ensure the liquid level is between the MIN FILL and MAX FILL lines.
2. **Select Program:** Choose one of the preset programs on the control panel:
  - **SLUSH:** For standard frozen drinks.
  - **SPIKED SLUSH:** Optimized for alcoholic frozen drinks.
  - **FRAPPÉ:** For coffee-shop style frozen beverages.
  - **MILKSHAKE:** For creamy, frozen milk-based drinks.

- **FROZEN JUICE:** For naturally sweetened frozen purees.
3. **Adjust Texture (Optional):** Use the temperature control buttons (up/down arrows) to customize the thickness or thinness of your drink.
  4. **Start:** Press the selected program button to begin the freezing process. The machine will automatically run until the desired consistency is achieved (typically 15 to 60 minutes, depending on ingredients).
  5. **Dispense:** Once complete, place a cup under the spout and pull the handle to dispense your frozen drink.



Figure 3: Control panel with one-touch preset settings.



## Easy-fill vessel

Easy to fill up, top off, and remove for cleaning.

Figure 4: Dispensing a frozen drink using the self-serve handle.

### 5.2. RapidChill Technology

The RapidChill Technology employs a two-part system where the auger spins around a cooling cylinder. This process freezes liquids quickly and evenly, eliminating the need for pre-chilling or adding ice, and prevents dilution. The machine can maintain drinks in a frozen state for up to 12 hours.



## One-touch frozen drinks

3 preset settings: Slush, Spiked Slush, Milkshake.

Figure 5: RapidChill Technology for efficient freezing.

## 6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your Ninja SLUSHi machine.

### 6.1. Daily Cleaning

1. **Rinse Cycle:** After each use, pour water into the vessel up to the MIN FILL line and press the "RINSE" button on the control panel. This will circulate water to clean the internal components.
2. **Disassemble:** Unplug the machine. Remove the vessel, auger, condensation catch, 2-part drip tray, and spout shroud.
3. **Wash:** All removable parts are dishwasher-safe. Alternatively, wash them by hand with warm, soapy water.
4. **Wipe Base:** Wipe the machine base with a damp cloth. Do not immerse the base in water.
5. **Dry and Reassemble:** Ensure all parts are completely dry before reassembling or storing the machine.

## 7. TROUBLESHOOTING

| Problem                          | Possible Cause                            | Solution                                                                               |
|----------------------------------|-------------------------------------------|----------------------------------------------------------------------------------------|
| Liquid not freezing properly.    | Insufficient sugar content in the liquid. | Ensure liquid contains at least 4% sugar. Add sugar or a recommended sugar substitute. |
| Machine not turning on.          | Not properly plugged in or power issue.   | Check power connection. Ensure the vessel is correctly assembled and secured.          |
| Dispensing is slow or blocked.   | Spout is clogged or drink is too thick.   | Clean the spout shroud. Adjust temperature settings for a thinner consistency.         |
| Unusual noises during operation. | Vessel or auger not correctly installed.  | Ensure all components are securely in place. Refer to the setup section.               |

## 8. SPECIFICATIONS

| Feature                        | Detail                                                                                                                  |
|--------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| Brand                          | Ninja                                                                                                                   |
| Model Number                   | FS300 (CRTE6NJFS300RB)                                                                                                  |
| Capacity                       | 72 Fluid Ounces                                                                                                         |
| Product Dimensions (D x W x H) | 16.3"D x 6.54"W x 16.93"H                                                                                               |
| Item Weight                    | 29.74 Pounds                                                                                                            |
| Color                          | Artic Blue and Gray                                                                                                     |
| Material                       | Plastic, Stainless Steel (Blade)                                                                                        |
| Power Source                   | Corded Electric                                                                                                         |
| Wattage                        | 200 watts                                                                                                               |
| Voltage                        | 120V                                                                                                                    |
| Number of Automatic Programs   | 5 (Slush, Spiked Slush, Frappé, Milkshake, Frozen Juice)                                                                |
| Special Features               | RapidChill Technology, 3 Preset Settings, Temperature Control, Easy to clean with dishwasher-safe parts and Rinse Cycle |
| Dishwasher Safe Parts          | Yes                                                                                                                     |

## 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Ninja website. Keep your purchase receipt as proof of purchase for any warranty claims. Online resources and FAQs may also be available on the manufacturer's website to assist with common questions and

issues.

**ASK A QUESTION ABOUT THIS MANUAL**

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question