

Manuals.plus /

› LEDIARY /

› LEDIARY 23-Inch Caged Flush Mount Ceiling Fan with Lights and Remote Control User Manual

LEDIARY 23 Inch Caged Flush Mount Ceiling Fan

LEDIARY 23-Inch Caged Flush Mount Ceiling Fan with Lights and Remote Control User Manual

Model: B0FVSLPJXX

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient installation, operation, and maintenance of your LEDIARY 23-inch Caged Flush Mount Ceiling Fan with Lights. Please read all instructions carefully before beginning installation and retain this manual for future reference.

PRODUCT OVERVIEW

The LEDIARY 23-inch Caged Flush Mount Ceiling Fan is designed to provide both illumination and air circulation in various indoor spaces. Its low-profile, caged design with a decorative pattern integrates seamlessly into farmhouse and modern aesthetics. The fan features a powerful yet quiet DC motor, offering six wind speed levels, timer settings, and a reversible motor for year-round comfort. Control is convenient via an included remote or a dedicated mobile application.




Image: Overview of the LEDIARY Caged Ceiling Fan highlighting remote control, quiet operation, easy installation, and strong

motor.



Quiet and Comfortable



6 Fan Speeds



1/2/4H Timing



Powerful Motor



Quiet Operation



0dB
Mute



15dB
Library



<35dB
Our Ceiling Fan



40-60dB
Chat



60-80dB
Meeting



Image: Features of the LEDIARY Caged Ceiling Fan, including 6 fan speeds, timer settings, powerful motor, and quiet operation (below 35dB).

WHAT'S INCLUDED

Verify that all components are present before beginning installation. If any parts are missing or damaged, contact customer support.

- Ceiling Fan Motor Host with Light Sockets
- Outer Caged Frame (multiple sections for assembly)
- Fan Blades (pre-installed or separate, refer to installation steps)
- Mounting Bracket
- Remote Control with Wall Plate and Battery
- Hardware Kit (screws, wire nuts, safety rope)
- User Manual

Note: 4 x E26 light bulbs are NOT included and must be purchased separately. Recommended bulbs: A19 ST19 T45, Incandescent (Max 60W), LED (Max 10W).



23" Ceiling Fan



E26*4 (Not Included)

Recommended bulbs :



LED Edison Bulb A19



LED Bulb ST19



LED Bulb A19



LED Edison Bulb ST19



Edison LED Bulb T14



E26 Medium Base

LED Light Bulb - Max 10W

Image: Fan dimensions and recommended E26 bulb types.

SETUP & INSTALLATION

Safety Precautions

- Always turn off power at the circuit breaker before installation.
- Consult a qualified electrician if you are unsure about wiring procedures.
- Wear appropriate safety gear, including gloves and eye protection.

Tools Required (Not Included)

- Phillips Head Screwdriver
- Wire Strippers
- Electrical Tape
- Ladder

Installation Steps

1. **Unbox and Inventory:** Carefully remove all components from the packaging. Refer to the 'What's Included' section to ensure all parts are present and undamaged.
2. **Assemble Outer Caged Frame:** Assemble the 6 frame parts in clockwise order (1-2-3-4-5-6) using screws. Ensure the 'UP' marking on each part faces upward.
3. **Assemble Base Trim:** Align base trim A and base trim B, securing them with screws. Fix the decorative cover and base trim with lock nut H.
4. **Install Fan Blades:** Remove the pin from the motor core shaft. Align and press the fan blades into the blade body slot until it clicks. Ensure the 'UP' mark and fan clips face upward. Insert the pin and tighten the blade cap by rotating it.
5. **Attach Motor Host to Frame:** Fix the motor host into the assembled outer frame using screws G and nuts F.
6. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling junction box using appropriate screws.
7. **Wiring Connections:** Hang the lamp body using the pre-installed safety rope. Connect the 'Live' wire (typically black), 'Neutral' wire (typically white), and 'Ground' wire (typically green or bare copper) from the ceiling to the corresponding wires on the fan. Use wire nuts to secure connections and electrical tape for added insulation.
8. **Final Assembly:** Rotate the fan to align with the mounting bracket and tighten with screws.
9. **Install Light Bulbs:** Screw the recommended E26 bulbs into the sockets from the back.

Your browser does not support the video tag.

Video: Detailed installation guide for the LEDIARY 23-inch Caged Ceiling Fan.

OPERATING INSTRUCTIONS

Your LEDIARY ceiling fan can be operated using the included remote control or the dedicated mobile application.

Remote Control Functions

- **Power Button:** Turns the fan and light on/off.
- **Light On/Off:** Controls the light independently.
- **Fan On/Off:** Controls the fan independently.
- **Speed Settings (1-6):** Adjusts fan speed from soft wind (1-2) to cool wind (5-6).
- **Forward/Reverse (F/R):** Changes the direction of fan rotation for seasonal use.
- **Timer (1H/2H/4H):** Sets the fan to automatically turn off after 1, 2, or 4 hours.

Quiet and Powerful



Image: Remote control layout and functions.

Your browser does not support the video tag.

Video: Demonstration of the LEDIARY Caged Ceiling Fan's remote control functions.

Mobile App Control

- Download the "FanLampPro" app from Google Play or Apple App Store.
- Pair the app with your fan during the first use following the in-app instructions.
- Control light, fan speed, timing, and forward/reverse functions directly from your smartphone.

Easy To Use Remote Control




Image: Mobile app interface for fan control.

Seasonal Operation

- **Summer Mode (Downward Airflow):** The fan blades rotate counter-clockwise, pushing cool air down to create a refreshing breeze.
- **Winter Mode (Upward Airflow):** The fan blades rotate clockwise, drawing cool air up and pushing warm air down from the ceiling, helping to distribute heat evenly.



Image: Seasonal airflow modes.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

Cleaning

- Before cleaning, ensure the power is turned off at the circuit breaker.
- Use a soft, damp cloth to wipe down the fan blades and outer frame. Avoid abrasive cleaners or solvents that

may damage the finish.

- Periodically check for dust accumulation on the fan blades and motor housing to maintain efficient airflow.

Bulb Replacement

- Ensure the power is off and bulbs have cooled before attempting replacement.
- Unscrew old bulbs and replace with new E26 base bulbs.
- Refer to the 'What's Included' section for recommended bulb types and maximum wattage.

TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on	No power supply; Loose wiring; Remote battery dead	Check circuit breaker; Verify wiring connections; Replace remote battery.
Lights do not work	Bulbs faulty or loose; Wiring issue; Remote battery dead	Replace or tighten bulbs; Check wiring; Replace remote battery.
Remote not responding	Battery dead or incorrectly inserted; Interference; Not paired with fan	Replace battery; Ensure no obstructions; Re-pair remote with fan (refer to app instructions).
Fan makes excessive noise	Loose screws; Unbalanced blades; Obstruction	Tighten all screws; Check for balanced blade installation; Remove any obstructions.

SPECIFICATIONS

Feature	Detail
Brand	LEDIARY
Model	23 Inch Caged Flush Mount Ceiling Fan
Material	Iron
Style	Farmhouse
Mounting Type	Flush Mount
Dimensions (L x W x H)	17.5"L x 13.4"W x 7.7"H (Approximate, for Extra Large variant)
Power Source	DC Motor
Control Method	App, Remote Control
Fan Speeds	6 Levels
Timer Settings	1H, 2H, 4H
Light Bulb Type	E26 (4 bulbs required, not included)
Max Bulb Wattage	Incandescent: 60W, LED: 10W
Indoor/Outdoor Usage	Indoor

WARRANTY & SUPPORT

LEDIARY stands by the quality of its products. This ceiling fan comes with a **5-year motor support** and **2-year support on other parts**. For any questions, technical assistance, or warranty claims, please contact LEDIARY customer service. Refer to the product packaging or the official LEDIARY website for contact details.