

Casfuy W8

Casfuy W8 & W7 Pet Water Fountain Replacement Filters & Sponges User Manual

INTRODUCTION

This manual provides instructions for the proper use and maintenance of Casfuy W8 & W7 Pet Water Fountain Replacement Filters and Sponges. These filters are designed to ensure your pet has access to clean, fresh water by effectively removing impurities.

SETUP INSTRUCTIONS

Follow these steps to prepare and install your new replacement filter and sponge:

1. **Rinse the Filter:** Before first use, thoroughly rinse the filter under running water for 3 to 5 minutes. This process removes any charcoal dust and activates the resin for optimal performance.
2. **Install the Filter:** Place the filter into the designated slot in your pet water fountain with the flat side facing upwards. Ensure it is seated correctly to prevent water bypass.
3. **Install the Sponge:** Place the sponge in its designated area, typically around the pump, to catch larger debris and hair.

Rinse Filters Before Use



Image: Hands rinsing a Casfuy pet water fountain filter under a faucet to remove charcoal dust.

Installation Instructions



Image: Diagram illustrating the correct installation of the filter with the flat side up, and an incorrect installation example.

OPERATING THE FILTERS

These replacement filters are compatible with Casfuy W8 and W7 pet water fountains, as well as other similar-sized models. Once installed, the filtration system will begin purifying the water as the fountain operates.

Compatible Perfectly with These Cat Fountains



Image: Various Casfuy pet water fountain models shown to be compatible with these replacement filters.



Image: A cat drinking from a pet water fountain, demonstrating the product in use.

MAINTENANCE

Regular replacement of filters and sponges is crucial for maintaining water quality and fountain hygiene.

- **Replacement Frequency:** Replace the filter and sponge every 1 to 2 weeks, or more frequently if you have multiple pets or notice reduced water flow or increased debris.
- **Filtration System:** The filters utilize a 4-stage filtration process:
 - **Non-woven fabric:** Traps large residue.
 - **Microporous cotton filter:** Removes hair and debris.
 - **Coconut shell activated carbon:** Absorbs odors and impurities.
 - **Ion exchange resin:** Softens water.

4-Stage Circulating Filtration System




Image: Detailed diagram of the 4-stage filtration system, showing how each layer purifies the water.

TROUBLESHOOTING

If you encounter issues with your pet water fountain's filtration, consider the following:

- **Reduced Water Flow:** Check if the filter or sponge is clogged with debris. Replace if necessary.
- **Unpleasant Odor/Taste:** This indicates the filter's activated carbon is saturated. Replace the filter immediately.
- **Visible Impurities:** Ensure the filter is installed correctly and replace it if impurities persist.

SPECIFICATIONS

Key specifications for the Casfuy W8 & W7 Pet Water Fountain Replacement Filters:

- **Product Dimensions:** 0.39 x 0.39 x 0.39 inches
- **Item Weight:** 0.17 Pounds (2.72 ounces)
- **Material:** Plastic, Polypropylene (PP)
- **Color:** White
- **Included Components:** 4 Filters, 4 Sponges

- **Model Compatibility:** Casfuy W8, W7, and similar filter-sized fountains
- **UPC:** 769044607407

Confirm Size Before Purchase



Image: Dimensions of the filter, indicating a 4.13-inch diameter and a 1.18-inch center hole.

WARRANTY INFORMATION

Casfuy provides a **1-Year Warranty** for these replacement filters and sponges. Please retain your proof of purchase for warranty claims. For details, refer to the official Casfuy website or contact customer support.

CUSTOMER SUPPORT

For further assistance, questions, or concerns regarding your Casfuy replacement filters, please contact Casfuy customer support through the retailer's platform or visit the official Casfuy website.