

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Jocoevol](#) /

> [Jocoevol Bubble Wall Waterfall Fountain Instruction Manual](#)

Jocoevol B0FVT2SXG7

Jocoevol Bubble Wall Waterfall Fountain Instruction Manual

Model: B0FVT2SXG7 | Brand: Jocoevol

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for purchasing the Jocoevol Bubble Wall Waterfall Fountain. This elegant indoor water feature is designed to enhance the ambiance of any space with its captivating bubble display and customizable LED lighting. This manual provides essential information for safe setup, operation, and maintenance to ensure long-lasting enjoyment of your fountain.

2. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the fountain is placed on a stable, level surface to prevent tipping.
- Keep electrical cords away from water and high-traffic areas.
- Only use the provided power adapter.
- Do not operate the fountain if any part is damaged, especially the power cord or pump.
- Unplug the fountain from the power outlet before performing any maintenance, cleaning, or when adding/removing water.
- Keep out of reach of children and pets.
- Do not overfill the water reservoir; always adhere to the MAX fill line.
- Use distilled water to prevent mineral buildup and maintain optimal performance.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with assembly:

- Bubble Wall Waterfall Fountain Unit (Acrylic Panel with Stainless Steel Base)
- Remote Control
- PVC Water Pipe
- Air Pump
- Power Supply (Adapter)
- Decorative Rocks (Black Pebbles)
- LED Strip



Image: All components included in the Jocoevol Bubble Wall Waterfall Fountain package.

4. SETUP INSTRUCTIONS

Follow these steps to assemble and set up your bubble wall fountain:

1. **Place Metal Base:** Position the stainless steel base on a level surface at your desired location.
2. **Install Acrylic Panel:** Carefully slide the acrylic panel into the base. Ensure it is seated correctly and tighten

the screws to secure the panel in an upright position.

3. **Connect Air Pump:** Connect the air pump to the blue valve located at the bottom of the acrylic panel. Place the air pump inside the base.
4. **Connect Power:** Connect the transformer cord to the controller connector, which is attached to the bottom of the acrylic panel. Join the pump cable to another connector coming from the controller. Ensure the power cable is passed through the designated hole behind the base.
5. **Add Decorative Rocks:** Place the metal tray onto the reservoir inside the base and arrange the decorative rocks as desired.
6. **Fill with Water:** Carefully add distilled water through the top of the panel until it reaches the MAX level mark. Do not overfill.
7. **Secure Top Cover:** Place the metal top cover onto the acrylic panel.
8. **Power On:** Plug the transformer into a mains power supply. Use the remote control to turn on the fountain and adjust settings.
9. **Adjust Bubble Density:** If desired, adjust the bubble density using the air valve at the bottom of the acrylic panel. Turn clockwise for more bubbles, counter-clockwise to reduce or stop.

Your browser does not support the video tag.

Video: Step-by-step assembly and initial setup of the Jocoevol Bubble Wall Waterfall Fountain.

5. OPERATING INSTRUCTIONS

Your Jocoevol Bubble Wall Waterfall Fountain comes with a remote control for easy operation:

- **Power Button:** Turn the fountain ON or OFF.
- **MODE:** Select from various lighting modes (e.g., Single Color Slow Flashing, Slow Fading Mode, Quick Flashing Mode, 3 Colors Flashing Mode).
- **SPEED +/-:** Adjust the speed of the light effects.
- **COLOR:** Select from 16 static colors.
- **BRIGHT +/-:** Adjust the brightness of the LED lights.
- **DEMO:** Activates a demonstration mode that cycles through various colors and effects.

Dynamic Multi-colored LED Lights

Lighting mode Light color Remote control Replaceable



Image: The bubble wall fountain showcasing dynamic multi-colored LED lights.

The remote allows you to customize the visual experience to match your mood or decor, creating a personalized oasis.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your fountain:

- **Water Changes:** Change the water every 2-4 weeks, or more frequently if the water appears cloudy. Always use distilled water to prevent mineral buildup.
- **Cleaning Acrylic Panels:** Gently wipe the acrylic panels with a soft, damp cloth. Avoid abrasive cleaners that can scratch the surface. For stubborn mineral deposits, use a mild vinegar solution.
- **Pump Cleaning:** Periodically clean the air pump to ensure efficient bubble production. Disconnect the pump, rinse it under clean water, and remove any debris.
- **Reservoir Cleaning:** When changing water, clean the reservoir to prevent algae growth.
- **Dusting:** Regularly dust the exterior of the fountain and base with a soft, dry cloth.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No bubbles or weak bubbles	Air pump clogged or not connected; air valve closed; insufficient water level.	Check air pump connection and clean if necessary. Open the air valve (clockwise). Ensure water is at the MAX level.
LED lights not working or flickering	Loose power connection; faulty LED strip; remote control battery low.	Check all power connections. Replace remote control battery. Contact support if LED strip is faulty.
Fountain is noisy	Air pump vibration; water level too low.	Ensure the air pump is properly cushioned (e.g., with the provided foam). Check and adjust water level.
Water leakage	Acrylic panel not properly sealed; overfilling.	Ensure the acrylic panel screws are tightened. Do not fill water above the MAX line.

8. SPECIFICATIONS

- **Model:** B0FVT2SXG7
- **Brand:** Jocoevol
- **Dimensions (L x W x H):** 19" x 13" x 64"
- **Material:** Acrylic (panels), Stainless Steel (base)
- **Power Source:** Electric
- **Special Feature:** UV Resistant
- **Color:** Bubble Wall

9. WARRANTY & SUPPORT

For warranty information or technical support, please contact Jocoevol customer service. Keep your purchase receipt as proof of purchase. Our support team is available to assist with any questions or concerns regarding your bubble wall fountain.