

Sokany SK-1934

Sokany SK-1934 Hot Air Styling Brush User Manual

Model: SK-1934 | Brand: Sokany

INTRODUCTION

This manual provides essential information for the safe and effective use of your Sokany SK-1934 Hot Air Styling Brush. Please read all instructions carefully before use and retain this manual for future reference. This innovative hot air styling brush combines the power of a hair dryer with the precision of a styling brush, designed to simplify your hair styling routine.

IMPORTANT SAFETY INFORMATION

To reduce the risk of electric shock, burns, fire, or injury, always follow these basic safety precautions:

- Keep out of reach of children.
- Do not use this appliance near water, such as in a bathtub, shower, or sink.
- Never immerse the appliance in water or any other liquid.
- Handle with care to prevent burns, as the brush heads can become very hot during use.
- Always unplug the appliance immediately after use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.

PACKAGE CONTENTS

Your Sokany SK-1934 Hot Air Styling Brush package includes the following items:

- 1 x Hot Air Styling Brush Main Unit
- 1 x Round Brush Attachment
- 1 x Flat Brush Attachment



Image: The Sokany SK-1934 Hot Air Styling Brush main unit with a round brush head attached, and two additional interchangeable attachments (a flat brush head and a concentrator nozzle) displayed separately.

PRODUCT FEATURES

- **Powerful 1600W Motor:** Provides strong airflow for quick drying and efficient styling.
- **3 Heat Settings:** Low, Medium, and High temperature options for precise control suitable for various hair types and styling needs.
- **Interchangeable Brush Heads:** Includes a round brush and a flat brush attachment for versatile styling,

such as straightening, adding volume, or creating waves.

- **Ceramic Heating Technology:** Ensures even heat distribution, promoting effective styling while minimizing heat damage to hair.
- **Ergonomic Design:** Features a comfortable grip and lightweight body for easy handling during styling sessions.
- **Integrated Drying and Brushing:** Saves time by allowing you to dry and style your hair simultaneously.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Choose Attachment:** Select the desired brush head (round or flat) based on your styling preference.
3. **Attach Head:** Align the chosen brush head with the main unit and push it firmly until it clicks securely into place.
4. **Connect Power:** Plug the device into a standard 220V electrical outlet. Ensure the outlet is compatible with the device's voltage.

OPERATING INSTRUCTIONS

Follow these steps for optimal styling results:

1. **Prepare Hair:** Ensure your hair is towel-dried and detangled before use. The brush works best on damp hair.
2. **Select Heat Setting:** Turn the control switch on the handle to select your desired heat setting: Low, Medium, or High. Start with a lower setting for fine or damaged hair, and increase as needed.
3. **Section Hair:** Divide your hair into manageable sections using clips.
4. **Style:** Place the brush near the roots of a hair section and gently glide it down towards the ends. For added volume, lift the brush at the roots. For curls or waves, wrap the hair section around the round brush and hold for a few seconds before releasing.
5. **Repeat:** Continue styling section by section until your desired look is achieved.
6. **Finish:** Once styling is complete, turn off the device and unplug it from the power outlet.

MAINTENANCE AND CARE

Proper care ensures the longevity and performance of your styling brush:

- **Cleaning:** Always unplug the device and allow it to cool completely before cleaning. Wipe the main unit with a soft, damp cloth.
- **Brush Head Cleaning:** Remove any hair tangled in the brush bristles using a comb or your fingers. The brush heads can be detached for easier cleaning.
- **Avoid Water:** Do not immerse the device or its attachments in water or other liquids.
- **Storage:** Store the hot air styling brush in a cool, dry place, away from direct sunlight and moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Not properly plugged in; power outlet issue.	Ensure the power cord is securely plugged into a working 220V outlet. Check the circuit breaker.

Problem	Possible Cause	Solution
Insufficient heat or airflow.	Heat setting too low; air vents blocked.	Increase the heat setting. Check and clear any obstructions from the air intake and exhaust vents.
Hair gets tangled in the brush.	Too much hair per section; hair not detangled.	Work with smaller sections of hair. Ensure hair is thoroughly detangled before styling.
Brush head is loose.	Attachment not secured properly.	Ensure the brush head is firmly pushed onto the main unit until it clicks into place.

TECHNICAL SPECIFICATIONS

Feature	Specification
Model Name	SK-1934
Brand	Sokany
Power	1600W
Voltage	220V
Heat Settings	3 (Low, Medium, High)
Number of Speeds	3
Maximum Temperature	200°C
Drying Technology	Ceramic Heating
Materials	Plastic, Ceramic
Color	Black
Power Source	Corded Electric
Included Components	Hot Air Brush, Round Brush Attachment, Flat Brush Attachment
Recommended Uses	Drying, Hair Styling, Hair Volumizing, Hair Straightening
Product Dimensions (L x W x H)	2 x 2 x 5 cm
Item Weight	20 grams

WARRANTY AND CUSTOMER SUPPORT

This product comes with a standard manufacturer's warranty. For warranty claims, technical support, or any inquiries regarding your Sokany SK-1934 Hot Air Styling Brush, please contact your retailer or the manufacturer directly. Please retain your proof of purchase for any warranty-related services.

