Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WIWB wwr7mid

WIWB Gaming PC Desktop User Manual

Model: wwr7mid

Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new WIWB Gaming PC Desktop. Please read this guide thoroughly before using your computer to ensure optimal performance and longevity.



Figure 1: WIWB Gaming PC Desktop, front view with internal RGB lighting.

Package Contents

Verify that all items are present in the package:

- One computer tower
- Power cord
- Signal receiver

Setup Guide

1. Unpacking and Placement

- Carefully remove the PC from its packaging.

- Place the computer tower on a stable, flat surface with adequate ventilation. Ensure no vents are obstructed.

2. Connecting Peripherals

Refer to the back panel diagram below for port identification.




Figure 2: Rear panel connectivity ports, including USB, audio, and video outputs.

- **Monitor:** Connect your monitor to the graphics card's video output ports (DisplayPort or HDMI). The motherboard's video ports are automatically disabled when a dedicated GPU is present. This PC features 3x DisplayPort and 1x HDMI.
- **Keyboard and Mouse:** Connect your keyboard and mouse to any available USB ports. The PC has 3x USB 3.0 and 8x USB 2.0 ports.
- **Audio:** Connect speakers or headphones to the audio output jack on the rear panel. A microphone can be connected to the microphone input jack.
- **Network:** For wired internet, connect an Ethernet cable to the network port. This PC also supports Wi-Fi 6 for wireless connectivity.
- **Power:** Connect the provided power cord to the PC's power input and then to a grounded electrical outlet.



Figure 3: Example of a fully connected WIWB Gaming PC Desktop setup.

3. Initial Power-On

- After connecting all peripherals and power, press the power button located on the top of the computer tower.
- The system will boot up, and the operating system (Windows) will load. Follow any on-screen instructions for initial setup.

Operating Instructions

Powering On/Off

- **To Power On:** Press the power button on the top of the tower.
- **To Shut Down:** Use the operating system's shutdown function (Start Menu > Power > Shut down). Avoid direct power-off unless necessary to prevent data loss.

RGB Lighting Control

The PC features customizable RGB fans. Lighting effects can be controlled via a dedicated button on the top of the tower or through compatible motherboard software (e.g., ASUS Aura, MSI Mystic Light) if connected.

Operating System

Your WIWB Gaming PC Desktop comes with Windows pre-installed. Ensure you complete the initial Windows setup process, including creating a user account and connecting to the internet.




Figure 4: The WIWB Gaming PC Desktop is suitable for gaming, content creation, and everyday use.

Maintenance

Cleaning

- Regularly clean the exterior of the PC with a soft, dry cloth.
- Use compressed air to clear dust from vents and fans periodically (every 3-6 months) to maintain optimal airflow and cooling. Ensure the PC is powered off and unplugged before cleaning internal components.

Ventilation

Ensure the PC is placed in an area with good airflow. Avoid placing it in enclosed spaces or directly against walls that could block vents. Proper ventilation is crucial for preventing overheating and maintaining component lifespan.

Software Updates

Keep your operating system, drivers (especially graphics drivers), and applications updated to ensure security, stability, and performance. Windows Update and your graphics card manufacturer's software can assist with this.

Troubleshooting

No Display on Monitor

- Check that the monitor is powered on and correctly connected to the graphics card's video output (DisplayPort or HDMI).
- Ensure the correct input source is selected on your monitor.
- Try a different video cable or monitor if available.

PC Not Powering On

- Verify the power cord is securely connected to both the PC and the electrical outlet.
- Check if the power supply switch on the back of the PC is in the 'On' position.

- Test the outlet with another device to ensure it has power.

Peripherals Not Responding

- Ensure USB devices (keyboard, mouse) are securely plugged into the correct ports.
- Try connecting the device to a different USB port.
- Restart the computer.

System Performance Issues

- Close unnecessary background applications.
- Ensure drivers and operating system are up to date.
- Check for malware or viruses.
- Monitor system temperatures to ensure the PC is not overheating.

Product Specifications

Detailed technical specifications for your WIWB Gaming PC Desktop.



Figure 5: Internal components, showcasing RAM and SSD.

Feature	Specification
Brand	WIWB
Model Number	wwr7mid
Operating System	Windows
CPU Model	AMD Ryzen 7 5700X
CPU Speed	3.4 GHz (Max 4.6 GHz)
Processor Cores	8
Graphics Card	NVIDIA GeForce RTX 5060 (8GB GDDR5)
RAM Memory	16 GB DDR4 (Max 128 GB)

Feature	Specification
Storage	1 TB NVMe SSD
Connectivity	Wi-Fi 6, Ethernet
Video Output	3x DisplayPort, 1x HDMI
USB Ports	3x USB 3.0, 8x USB 2.0 (Total 11)
Cooling Method	Air Cooling (4x customizable RGB fans)
Item Weight	8.87 Kilograms
Color	Black

Warranty Information

Your WIWB Gaming PC Desktop comes with a manufacturer's warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the documentation included with your product or contact WIWB customer support directly. Keep your proof of purchase for warranty claims.

Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact WIWB customer support. You can typically find contact information on the manufacturer's official website or through your retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FW3KPB87

More documents and user manuals: **https://manuals.plus/**