

TABWEE W90

TABWEE W90 Android 16 Tablet User Manual


Model: W90

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your TABWEE W90 Android 16 Tablet. Please read it thoroughly to ensure proper use and to maximize your device's performance and longevity.

2. WHAT'S IN THE BOX

- TABWEE W90 Android 16 Tablet
- 18W Power Adapter
- USB-C Cable
- User Manual (this document)
- After-sales Card



What's Inside the Box



1. 18W Power Adapter
2. USB-C Cable
3. User Manual
4. After-sales Card

Image: Contents of the TABWEE W90 Tablet box.

3. DEVICE OVERVIEW

Familiarize yourself with the physical components of your TABWEE W90 tablet.



Image: Front view of the TABWEE W90 Android 16 Tablet.

- **Power Button:** Located on the side, used to power on/off or wake/sleep the device.

- **Volume Buttons:** Adjust audio levels.
- **Front Camera:** For video calls and selfies.
- **Rear Cameras:** For high-resolution photography and video recording.
- **3.5mm Headphone Jack:** For connecting wired headphones.
- **Card Slot:** For inserting a TF (microSD) card for expanded storage.
- **Type-C Port:** For charging and data transfer.
- **Speakers:** For audio output.

4. SETUP

4.1 Initial Power On and Setup

1. **Charge the Tablet:** Connect the 18W power adapter and USB-C cable to the tablet and a power outlet. Allow the tablet to charge for at least 30 minutes before first use.
2. **Power On:** Press and hold the Power Button until the TABWEE logo appears.
3. **Follow On-Screen Prompts:** The tablet will guide you through initial setup, including language selection, Wi-Fi connection, Google account login, and security settings.

4.2 Expanding Storage (TF Card)

The TABWEE W90 supports up to 2TB TF card expansion.

1. Locate the card slot on the side of the tablet.
2. Gently insert the TF card into the slot until it clicks into place.
3. The tablet will detect the new storage. You may be prompted to format the card for optimal use with the device.

**Up to 24GB RAM,
256GB ROM,
and 2TB Expansion**

Run More Smoothly, Store More Freely

256GB ROM + 2TB TF Expansion

≈303K
Photos

≈796K
Songs

≈5.1K
Short Videos

30% Faster Response Speed

AnTuTu
257708

Image: Memory and storage expansion capabilities.

4.3 Connecting a Bluetooth Keyboard (K1 Keyboard Tutorial)

To connect a Bluetooth keyboard, such as the K1, follow these steps:

1. Ensure the keyboard is charged and powered on.
2. On your tablet, navigate to **Settings > Connected devices > Bluetooth**.

3. Enable Bluetooth if it is not already on.
4. On the keyboard, press and hold the **Fn + C** keys for 3 seconds to enter pairing mode. The Bluetooth indicator light on the keyboard will flash.
5. On the tablet, select 'Pair new device' or wait for 'Blackview K1 Keyboard' to appear in the list of available devices.
6. Tap on 'Blackview K1 Keyboard' to initiate pairing. Confirm any pairing requests on both devices.

Your browser does not support the video tag.

Video: Tutorial on how to link the K1 Bluetooth keyboard to your tablet.

5. OPERATING INSTRUCTIONS

5.1 Display Features

The TABWEE W90 features an 11-inch FHD (1920x1200) eye-care display with Widevine L1 certification for 1080P HD streaming. It is TÜV certified to reduce harmful blue light by 45%, enhancing eye comfort.

11-inch Immersive FHD Display

See More, Do More, Enjoy More



NETFLIX

prime video

You Tube

hulu

HBO



TÜV Rheinland Low Blue Light Certification

More Eye-friendly 

11-inch
Screen Size

1920*1200
Resolution

84.9%
Screen-to-body
Ratio

350 nits
Brightness

Image: The 11-inch FHD display with TÜV Rheinland Low Blue Light Certification.

5.2 Performance and Memory

Equipped with a Unisoc T615 Octa-Core chipset, the tablet offers smooth multitasking. It comes with 24GB RAM (8GB actual + 16GB expansion) and 256GB ROM, expandable up to 2TB via TF card.

Robust Octa-core Unisoc T615 Chipset

Smooth Multitasking and Exceptional Performance, as Always



2 x A75@2.2GHz +
6 x A55@1.8GHz



Mali-G57@
850MHz



LPDDR4+
UFS




Image: Robust Octa-core Unisoc T615 Chipset.

5.3 Camera Functions

The tablet features a 16MP rear camera and an 8MP front camera. Integrated Google Lens allows for real-time object recognition and enhanced photography with AI features like AI Magic Eraser, AI Photo Unblur, AI Sky Replacement, AI Portrait Unblur, and AI Portrait Light.

8MP Front+16MP Rear AI Cameras

Ace the Shot, Anytime, Anywhere



Face
Unlock



Smart Google Lens
Scan, Search, Explore

AI Algorithms

20% Better Photos 



Image: 8MP Front + 16MP Rear AI Cameras.

AI Magic: Bring Out the Best of Every Moment

Every Click, Pure Beauty




Image: AI Magic features for photo enhancement.

5.4 Connectivity

The device supports dual-band 5G Wi-Fi for fast internet speeds and Bluetooth 5.0 for stable wireless connections with accessories.



Image: Lightning Fast 5G WiFi.

Lightning Fast 5G WiFi

Seamless Streaming and
Lightning-fast Downloads, Always

25% Quicker
Download Speed 




Image: Advanced Bluetooth 5.0.

Advanced Bluetooth 5.0

20% Faster Data Transfer Speed 

5.5 Battery and Charging

The 8000mAh battery provides extended usage, with up to 12 hours of video playback. The tablet supports 18W fast charging, allowing it to reach 50% charge in approximately 40 minutes.

Up to 24GB RAM, 256GB ROM, and 2TB Expansion

Run More Smoothly, Store More Freely




Up to 24GB RAM=
8GB+16GB Expansion



256GB+
2TB Expansion

30% 
Faster Response
Speed



256GB ROM + 2TB TF Expansion



AnTuTu
257708



≈303K
Photos



≈796K
Songs



≈5.1K
Short Videos

Image: 8000mAh Mega Battery with 18W Fast Charging.

5.6 Android 16 and AI Integration

The tablet runs on Android 16, offering enhanced privacy and cross-device collaboration. It integrates with Google Gemini AI for intelligent resource scheduling and voice interaction.




Image: Android 16 features for easier work and life.

5.7 Using App Split-Screen

To use the split-screen feature for multitasking:

1. Open the first application you wish to use.
2. Swipe up from the bottom of the screen and hold to access the recent apps view.
3. Tap the app icon at the top of the first app's card and select 'Split screen'.
4. Choose a second application from the recent apps list or the app drawer to open it in the other half of the screen.

Your browser does not support the video tag.

Video: Instructions on how to use the app split-screen feature on your device.

6. MAINTENANCE

6.1 Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials that could damage the surface.

6.2 Software Updates

Ensure your device is connected to a stable network and has at least 30% battery. When an Android 16 system update is available, you will receive a notification. Click 'Update Now' to start the process. The device will automatically complete the installation and restart. All existing data will be retained after the update.

8000mAh Mega Battery with 18W Fast Charging

From Dawn to Dusk, Power Through Your Day



5.5hrs
Video



5hrs
Game



5hrs
Website



27hrs
Music



1080hrs
Standby

Image: Android 16 system update process.

7. TROUBLESHOOTING

7.1 Wi-Fi Not Connecting or Keeps Dropping

If you experience issues with Wi-Fi connectivity, try resetting your network settings:

1. Go to **Settings > System > Reset options**.
2. Select **Reset Bluetooth & Wi-Fi**.
3. Confirm the reset. This will reset all Wi-Fi and Bluetooth settings.

Your browser does not support the video tag.

Video: Guide to troubleshooting Wi-Fi connection issues by resetting network settings.

7.2 Device Lagging or Freezing

If your tablet is experiencing lag or freezing, consider the following steps:

- 1. **Close Background Apps:** Swipe up from the bottom of the screen and hold to access recent apps. Swipe up on individual app cards or tap 'Clear all' to close them.
- 2. **Uninstall Unused Apps:** Long-press on an app icon, then drag it to 'Uninstall' or select 'Uninstall app' from the menu.
- 3. **Restart the Device:** Press and hold the Power Button, then select 'Restart'. If unresponsive, press and hold the Power Button for more than 10 seconds to force a reboot.

Your browser does not support the video tag.

Video: Solutions for device lagging or freezing, including closing apps, uninstalling, and restarting.

8. SPECIFICATIONS

Feature	Specification
Brand	TABWEE
Model Name	W90
Operating System	Android 16
Processor	Unisoc T615 Octa-Core
RAM Memory	24 GB (8GB actual + 16GB expansion)
Storage Capacity	256 GB ROM, expandable up to 2TB TF
Screen Size	11 Inches
Display Resolution	1920 x 1200 Pixels (FHD)
Display Type	LCD
Maximum Display Brightness	389 Nits
Rear Camera	16 MP
Front Camera	8 MP
Wireless Technology	5G Wi-Fi (802.11ac), Bluetooth 5.0
Battery Capacity	8000 mAh
Charging	18W Fast Charging
Item Weight	395 Grams
Item Dimensions (L x W x Thickness)	9.7"L x 7.5"W x 0.6"Th
Human-Interface Input	Touchscreen with Stylus Support
UPC	810199725215

9. WARRANTY AND SUPPORT

The TABWEE W90 tablet comes with a standard 2-year manufacturer's warranty. You can also enjoy a 30-day free return and exchange policy. For any questions or support needs, please contact us through your order page or official channels. We aim to respond within 12 hours.



Image: After-sales service and support information.

For more information on returns and refunds, please visit: <https://www.aftersales.store/refund/>