

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [NEBZHASK](#) /

› [NEBZHASK 98-inch Farmhouse TV Stand Instruction Manual](#)

NEBZHASK B0FW4LD2VC

NEBZHASK 98-inch Farmhouse TV Stand Instruction Manual

Model: B0FW4LD2VC

[Safety](#) [Contents](#) [Assembly](#) [Features](#) [Usage](#) [Care](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 200 pounds (90.7 kg) for the TV stand.
- **Stability:** Ensure the TV stand is placed on a flat, level surface to prevent tipping.
- **Children Safety:** Keep small parts away from children during assembly. Do not allow children to climb on or play with the TV stand.
- **Tools:** Use appropriate tools for assembly as specified in the instructions.
- **Two-Person Assembly:** Assembly may require two people for safety and ease.
- **Ventilation:** Ensure adequate ventilation around electronic devices placed on or within the TV stand.

2. PACKAGE CONTENTS

The NEBZHASK 98-inch Farmhouse TV Stand is shipped in two separate packages. Please ensure both packages (labeled A and B) have been received before beginning assembly.




Image: Illustration showing two packages (A and B) being delivered, emphasizing that both are required for assembly.

Refer to the included parts list in your physical manual to verify all components are present before starting assembly.

3. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your NEBZHASK 98-inch Farmhouse TV Stand. It is recommended to have a second person assist with assembly.

3.1. Video Installation Guide

For a visual guide, please watch the official installation video:

Your browser does not support the video tag.

Video: Detailed step-by-step animated guide for assembling the NEBZHASK Farmhouse TV Stand.

3.2. Step-by-Step Assembly Overview

The assembly process involves constructing the main cabinet, the two side cabinets, and the drawers, then integrating the sliding barn doors.

- 1. Prepare Components:** Unpack all components and verify against the parts list. Separate hardware into labeled bags if provided.
- 2. Assemble Side Cabinets:** Construct the two smaller side cabinets first. These units can also function as separate bedside tables.
- 3. Assemble Main Cabinet Base:** Build the central 59-inch TV cabinet base structure.
- 4. Attach Top Panel:** Secure the rustic brown top panel to the assembled cabinet structures.
- 5. Install Drawer Slides:** Attach the drawer slides to the interior panels of the main cabinet.
- 6. Assemble Drawers:** Construct the drawers and install their handles.
- 7. Insert Drawers:** Slide the assembled drawers into their respective compartments.
- 8. Install Barn Doors:** Attach the sliding barn door hardware and hang the doors. Ensure they slide smoothly.
- 9. Attach Cabinet Doors:** Install the hinged cabinet doors on the side units.

For detailed diagrams and specific hardware usage for each step, please refer to the printed instruction manual included in your package.

4. PRODUCT FEATURES

The NEBZHASK Farmhouse TV Stand offers a blend of style and functionality:

- **Convertible Design:** This 98-inch TV stand can be used as a single large unit or easily disassembled into a 59-inch TV cabinet and two separate bedside tables. This allows for flexible placement and use in various room configurations.
- **Generous Storage Capacity:** The unit provides ample storage with multiple drawers and cabinets, ideal for organizing electronics, media, and other household items. When separated, the bedside tables offer convenient storage for personal accessories.
- **Durable and Stable Construction:** Crafted from high-quality materials, the TV stand features a robust structure capable of supporting large televisions up to 100 inches and heavy items, with a weight capacity of up to 200 pounds.
- **Sleek Farmhouse Design:** The clean lines and rustic white finish with a contrasting wood-grain top complement modern and farmhouse-style interiors.
- **Cable Management:** Integrated cable holes help manage and conceal wires for a tidy appearance.
- **Smooth Sliding Barn Doors:** The central barn doors operate on a silky-smooth track, allowing easy access to the central compartments.
- **Anti-slip Protection:** Includes anti-slip stickers to protect floors and enhance stability.

4.1. Feature Highlights




Image: Details of the barn doors, cable management hole, and durable particle board construction.



Image: Demonstrates the mobile barn door and the 2-in-1 detachable storage cabinet functionality.

Tip: The product will be shipped in two separate packages. Please follow the installation instructions once both packages have been received.



Image: Highlights the cable hole for wire management, metal handles, and anti-slip stickers for floor protection.

5. USAGE INSTRUCTIONS

This TV stand is designed for versatile use in your living space.

- **Television Placement:** Place your television centrally on the top surface. The stand is suitable for TVs up to 100 inches. Ensure the TV base fits securely within the dimensions of the stand.
- **Storage Organization:** Utilize the drawers for smaller items like remote controls, cables, or personal accessories. The cabinets and open shelves are suitable for media players, gaming consoles, books, or decorative items.
- **Cable Management:** Route power cords and signal cables through the designated cable holes at the back of the unit to maintain a neat and organized appearance.
- **Convertible Configuration:** If desired, the two end sections can be detached and used as independent bedside tables or end tables, leaving a 59-inch central TV cabinet. This conversion should be performed carefully, following the reverse of the assembly steps for detachment.



Image: The TV stand integrated into a living room, showcasing its capacity for a large television and storage.

6. CARE AND MAINTENANCE

Proper care will help maintain the appearance and longevity of your TV stand:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.

- **Spills:** Clean up spills immediately to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the finish.
- **Heat and Moisture:** Keep the TV stand away from excessive heat sources and areas with high humidity. Use coasters under drinks to protect the top surface.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common solutions:

Problem	Possible Cause	Solution
Stand is wobbly/unstable.	Uneven floor; loose fasteners; incorrect assembly.	Ensure the stand is on a level surface. Check and tighten all screws and bolts. Review assembly steps.
Drawers do not slide smoothly.	Drawer slides not aligned; debris in tracks; incorrect installation of slides.	Check alignment of drawer slides. Clean tracks. Ensure slides are installed correctly and securely.
Barn doors are stiff or stuck.	Track obstruction; rollers not properly seated; track not level.	Clear any debris from the track. Ensure rollers are correctly engaged. Verify the track is level.
Missing parts or damaged components.	Shipping error; manufacturing defect.	Contact customer service immediately with your model number and a description of the issue.

If you are unable to resolve an issue, please contact NEBZHASK customer service for assistance.

8. SPECIFICATIONS

- **Brand:** NEBZHASK
- **Model:** B0FW4LD2VC
- **Color:** Rustic White
- **Material:** High-quality Particle Board
- **Overall Dimensions (Approximate):** 98.43 inches (Length) x 15.35 inches (Depth) x 24.01 inches (Height)
- **Drawer Interior Dimensions (Approximate):** 11.81 inches (Length) x 3.15 inches (Height)
- **Weight Capacity:** Up to 200 lbs (90.7 kg)
- **TV Size Compatibility:** Up to 100 inches
- **Assembly Required:** Yes




Image: Dimensional diagram of the TV stand, including overall length, height, depth, and drawer dimensions.

9. WARRANTY AND CUSTOMER SUPPORT

NEBZHASK is committed to providing quality products and customer satisfaction.

- **Customer Service:** If you have any questions during assembly, require replacement parts, or encounter any issues with your product, please contact our customer service team. We guarantee a response within 24 hours to promptly resolve any concerns.
- **Contact Information:** Refer to the contact details provided in your product packaging or on the official NEBZHASK website.

Please retain your purchase receipt for any warranty claims or support inquiries.

