

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Kikkerland](#) /

› KIKKERLAND Mini Keyring Knife Cut It Out! KR109 Instruction Manual

Kikkerland KR109

KIKKERLAND Mini Keyring Knife Cut It Out! KR109 Instruction Manual

Model: KR109

INTRODUCTION

This manual provides essential information for the safe and effective use of your KIKKERLAND Mini Keyring Knife, model KR109. Please read these instructions carefully before use and retain them for future reference.

CUT IT OUT!

Coupe-Le !

KIKKERLAND®



- Rust-Free
Ceramic Blade
- Precision Cut
- Durable &
lightweight



Image: KIKKERLAND Mini Keyring Knife in its retail packaging, highlighting key features.

This portable mini ceramic knife, designed as a keyring type, offers exceptional sharpness in a compact form. It is suitable for opening packages and mail, outdoor activities, and as an emergency disaster preparedness tool. The knife can be safely and smartly carried on bags or keyrings, stored within its aluminum alloy case. It is a convenient portable tool for everyday use and emergency preparedness.

SAFETY INFORMATION

- This product contains a sharp ceramic blade. Handle with extreme care.
- Keep out of reach of children.
- Always ensure the blade is fully retracted into its case when not in use.
- Do not use for prying or tasks beyond its intended cutting purpose.
- Avoid direct contact with the blade edge.

PACKAGE CONTENTS

- 1 x KIKKERLAND Mini Keyring Knife (Model KR109)

SETUP

The KIKKERLAND Mini Keyring Knife comes pre-assembled. To attach it to a keyring, simply thread your existing keyring through the integrated keyring loop on the knife's case.



Image: The KIKKERLAND Mini Keyring Knife shown attached to a set of keys, demonstrating its portability.

OPERATING INSTRUCTIONS

1. **To deploy the blade:** Hold the main body of the knife. Gently twist the upper knurled section counter-clockwise to reveal the ceramic blade. Continue twisting until the blade is fully extended and stable.
2. **To retract the blade:** Twist the upper knurled section clockwise until the blade is fully enclosed within the aluminum alloy case. Ensure it is securely closed before carrying.
3. **For cutting:** Use the ceramic blade for light cutting tasks such as opening packages, letters, or tape. Apply gentle, controlled pressure.



Image: Multiple views of the knife, illustrating the closed state, the case separated, and the blade extended for use.

MAINTENANCE

- **Cleaning:** Wipe the ceramic blade and aluminum case with a dry or slightly damp cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** Always store the knife with the blade fully retracted in its case. Keep it in a dry place.
- **Blade Care:** The ceramic blade is rust-free. Avoid dropping the knife, as ceramic can be brittle and may chip or break upon impact.





Image: A detailed view of the KIKKERLAND Mini Keyring Knife in its fully closed and secure state.

TROUBLESHOOTING

- **Blade does not extend/retract smoothly:** Check for any debris obstructing the mechanism. Ensure the twisting motion is firm but not forced.

- **Blade appears dull:** Ceramic blades retain sharpness for a long time. If cutting performance degrades, inspect the blade for damage or chips. Replacement blades are not typically user-replaceable for this model.

SPECIFICATIONS

Model Number	KR109
Dimensions (L x W x H)	7 cm x 2.5 cm x 1 cm (approx. 2.76 in x 0.98 in x 0.39 in)
Materials	Aluminum Alloy, Iron, Ceramic
UPC	612615129108
Country of Origin	China

WARRANTY AND SUPPORT

For warranty information or support, please contact your retailer or visit the official Kikkerland website. Keep your proof of purchase for any warranty claims.