

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Samsung](#) /

› [Samsung Galaxy Watch 8 \(SM-L335\) User Manual](#)

Samsung SM-L335

Samsung Galaxy Watch 8 (SM-L335) User Manual

Comprehensive instructions for your smartwatch

1. INTRODUCTION

This manual provides detailed instructions for the use and maintenance of your Samsung Galaxy Watch 8 (SM-L335). Please read this manual carefully to ensure proper operation and to maximize the lifespan of your device.



Image 1.1: Samsung Galaxy Watch 8 44mm in Graphite. This image shows the smartwatch from a slight angle, highlighting its round display and the graphite band.

What's in the Box

- Samsung Galaxy Watch 8 (SM-L335)
- Watch Band
- Watch charging cord
- Quick Start Guide (may vary)

2. SETUP

2.1 Charging the Device

Before initial use, fully charge your Galaxy Watch 8. Connect the charging cord to the watch and a compatible power adapter. The watch display will indicate charging status.

2.2 Powering On/Off

- **To Power On:** Press and hold the Home key (bottom button) until the Samsung logo appears.
- **To Power Off:** Press and hold the Home key, then tap "Power off" on the screen.

2.3 Pairing with a Smartphone

1. Ensure your smartphone is running Android and has Bluetooth enabled.
2. Download and install the **Galaxy Wearable** app from the Google Play Store.
3. Open the Galaxy Wearable app on your smartphone.
4. Follow the on-screen prompts to connect your Galaxy Watch 8.
5. Confirm the passkey displayed on both devices.

2.4 Carrier Activation (LTE + Wi-Fi Models)

For LTE connectivity, your Galaxy Watch 8 must be activated with a compatible carrier plan. This process is typically managed through the Galaxy Wearable app after initial pairing. Contact your mobile carrier for specific activation steps and plan details.

3. OPERATING YOUR GALAXY WATCH 8

3.1 Navigation

- **Touchscreen:** Swipe left/right to navigate tiles, swipe up/down for notifications/quick panel. Tap to select.
- **Home Key (bottom button):** Press to go to the Watch face or App screen. Double-press for a customizable shortcut. Press and hold for Power options or Bixby.
- **Back Key (top button):** Press to go back to the previous screen.

3.2 Key Features

- **Health Tracking:** Monitor heart rate, track steps, sleep patterns, and various workouts. Access data via Samsung Health app.
- **Notifications:** Receive alerts from your paired smartphone directly on your watch.
- **Voice Call:** Make and receive calls directly from your watch using its built-in speaker and microphone (requires LTE activation or Bluetooth connection to phone).
- **GPS:** Utilize built-in GPS for accurate location tracking during outdoor activities.

3.3 Customizing Watch Faces

To change your watch face, press and hold the current watch face on the screen. Swipe left or right to browse available faces, then tap to select. More options are available in the Galaxy Wearable app.

3.4 Using Applications

Access your installed applications by pressing the Home key from the watch face. Swipe through the app list and tap an icon to open. New apps can be downloaded via the Galaxy Wearable app.



Video 3.1: Overview of Samsung Galaxy Watch 8 features. This video demonstrates various functionalities of the smartwatch, including navigation, health tracking, and notification management.

4. MAINTENANCE

4.1 Cleaning Your Watch

Wipe the watch and band with a soft, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials. Ensure the watch is dry before charging.

4.2 Battery Care

- Avoid extreme temperatures, which can degrade battery life.
- Do not leave the watch fully discharged for extended periods.
- Use only the provided charging cord.

4.3 Software Updates

Regularly check for and install software updates via the Galaxy Wearable app. Updates provide new features, performance improvements, and security enhancements.

5. TROUBLESHOOTING

Problem	Solution
Watch does not power on	Ensure the watch is fully charged. Press and hold the Home key for at least 10 seconds to force restart.
Cannot pair with smartphone	Check if Bluetooth is enabled on your phone. Ensure the Galaxy Wearable app is installed and updated. Restart both devices.
LTE connectivity issues	Verify carrier activation. Check signal strength. Contact your mobile carrier for assistance.
Apps are slow or unresponsive	Close background apps. Restart the watch. Ensure software is up to date.

5.1 Resetting the Device

If issues persist, you may need to reset your watch. Go to **Settings > General > Reset** on your watch. This will erase all data and restore factory settings. Back up important data before proceeding.

6. SPECIFICATIONS

Feature	Detail
Model Name	Galaxy Watch 8 44mm
Model Number	SM-L335
Brand	Samsung
Screen Size	44 Millimeters
Operating System	Wear OS
Connectivity Technology	Cellular (LTE), Wi-Fi
Battery Capacity	435 Milliamp Hours
Battery Cell Composition	Lithium Ion
Special Feature	Voice Call, Built-in GPS
Item Weight	8.1 ounces
Package Dimensions	7.05 x 2.72 x 2.13 inches

7. WARRANTY AND SUPPORT

7.1 Product Condition and Warranty

This Samsung Galaxy Watch 8 is a renewed product. Renewed devices are retested to ensure 100% functionality and come in great cosmetic condition. Please refer to your purchase documentation for specific warranty details provided by the seller. Standard manufacturer warranties may not apply to renewed products.

7.2 Customer Support

For technical assistance, troubleshooting, or further information, please visit the official Samsung support website or contact your product retailer. You can find detailed support resources, FAQs, and contact options on their respective platforms.

- **Samsung Support:** www.samsung.com/us/support/
- **Retailer Support:** Refer to your purchase invoice or retailer's website for contact information.