

IDEALHOUSE vintage tv stand

# IDEALHOUSE Farmhouse TV Stand Instruction Manual

Model: vintage tv stand

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your IDEALHOUSE Farmhouse TV Stand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

## SAFETY INFORMATION

**Always assemble the product with care, following the provided instructions. Keep the product away from children and pets. Be cautious of sharp edges and pinch points, especially when using the cable management system. Do not overload the cabinet beyond its weight capacity.**

The TV stand is designed to support a maximum weight of 500 lbs on the top surface. Each side storage compartment can hold up to 30 lbs, and the bottom shelves can hold up to 50 lbs. Ensure these limits are not exceeded to prevent damage or injury.

## PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- TV Stand components (engineered wood panels, metal frames, mesh doors)
- Hardware kit (screws, dowels, hinges, handles)
- Installation Tool (Allen wrench, screwdriver)
- User Manual (this document)

## SPECIFICATIONS

| Feature | Detail |
|---------|--------|
|---------|--------|

|                                |                                                |
|--------------------------------|------------------------------------------------|
| Brand                          | IDEALHOUSE                                     |
| Model Number                   | vintage tv stand                               |
| Color                          | Farmhouse Vintage                              |
| Material                       | FSC-Certified Wood, Metal                      |
| Product Dimensions (L x W x H) | 63" x 18.3" x 25"                              |
| Item Weight                    | 84.9 pounds                                    |
| Max. Load Capacity (Top)       | 500 lbs                                        |
| Max. Load Capacity (Storage)   | 30 lbs (side shelves), 50 lbs (bottom shelves) |
| Recommended TV Size            | Up to 75 inches                                |
| Storage Options                | 6 compartments, 3 shelves, 2 mesh doors        |
| Mounting Type                  | Floor Mount                                    |

# Product Dimension



Vintage



Rustic Oak



Grey



**Max. Load**

Top 500Lbs | Storage 30/50Lbs

Image: Detailed product dimensions and maximum load capacities for the TV stand.




Ample Storage



Iron Crossbar for Enhanced Durability



Sturdy Metal Frame Design



Cable Management


Image: Illustration showing the TV stand is suitable for TVs up to 75 inches.

## SETUP AND ASSEMBLY

The IDEALHOUSE Farmhouse TV Stand is designed for straightforward assembly. All necessary parts are numbered, and clear instructions are provided in the included assembly guide. It is recommended to have a second person assist with assembly for ease and safety.

### General Assembly Tips:

- Unpack all components and lay them out on a clean, soft surface to prevent scratches.
- Identify all parts using the provided labels and the assembly diagram.
- Use the included installation tool. For better leverage, a personal screwdriver may be preferred for certain steps.
- Do not overtighten screws during initial assembly; tighten fully once the structure is stable.
- Ensure all connections are secure before placing items on the stand.



# Thickened Board

Iron Crossbar for Enhanced Durability



Image: Close-up of the thickened board and iron crossbar, highlighting enhanced durability.



# Stable Structure

Metal Round Tube & Legs Provide Stability & Durability



Image: View of the stable structure, featuring metal round tubes and legs for support.

## Assembly Video:

Your browser does not support the video tag.

Video: An official overview of the IDEALHOUSE Industrial TV Stand, demonstrating its features and potentially assembly steps.

## OPERATING INSTRUCTIONS

Your TV stand is designed to be a functional and aesthetic addition to your living space. Utilize the various compartments for organizing media devices, books, and decorative items.

### Storage and Organization:

- The central cabinet features two mesh doors, allowing you to conceal or display items as desired.
- The open side shelves provide easy access and display opportunities for frequently used items or decor.
- Distribute weight evenly across the shelves and top surface to maintain stability.




# Mesh Doors

Smooth Access with Metal Exquisite Handles



Image: Close-up of the mesh doors and metal handles, showcasing smooth access.



# Ample Storage Space

Offers Spacious Storage for Electronics and Everyday Items



Image: Interior view of the TV stand, demonstrating ample storage space for electronics and everyday items.

## Cable Management:

The back panel of the central cabinet includes pre-drilled holes to facilitate organized cable routing for your electronic devices. This helps maintain a tidy appearance and prevents cable clutter.

# Suitable for TV size up to 75"



Image: A collage highlighting key features including ample storage, iron crossbar for durability, sturdy metal frame design, and integrated cable management.

## MAINTENANCE

Proper care will ensure the longevity and appearance of your IDEALHOUSE Farmhouse TV Stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Spills:** Clean spills immediately to prevent staining.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Hardware:** Periodically check and tighten all hardware connections to ensure stability.

## TROUBLESHOOTING

If you encounter issues with your TV stand, refer to the following common solutions:

- **Wobbling/Instability:** Ensure all screws and fasteners are securely tightened. Verify that the stand is placed on a level surface. Adjust foot pads if present.
- **Missing Parts:** If parts are missing upon unboxing, refer to the package contents list and contact customer support with the specific part numbers.
- **Difficulty with Assembly:** Re-read the assembly instructions carefully. Sometimes, a small detail can be overlooked. Ensure components are oriented correctly.
- **Damaged Components:** If any component arrived damaged, do not proceed with assembly. Contact customer support for replacement parts.

## WARRANTY AND SUPPORT

IDEALHOUSE products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or visit the official IDEALHOUSE website.

For customer support, including assistance with assembly, missing parts, or product inquiries, please contact IDEALHOUSE customer service through the retailer where the product was purchased or via the contact information provided on the IDEALHOUSE brand store page.

This product is eligible for 30-day easy returns through Amazon.com.

**Manufacturer:** IDEALHOUSE

© 2026 IDEALHOUSE. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

