Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM IT83B-554V00ND0631

HOMCOM TV Stand with Swivel Wheels and Adjustable Shelves - Model IT83B-554V00ND0631

User Manual

1. Introduction

Thank you for choosing the HOMCOM TV Stand. This versatile media console is designed to accommodate televisions up to 42 inches and offers convenient storage solutions for your living space. It features smooth-gliding swivel wheels with brakes for easy mobility, adjustable shelves to customize storage, and two drawers for discreet organization. Please read this manual carefully before assembly and use to ensure proper installation and safe operation.



Image 1.1: The HOMCOM TV Stand, showcasing its design and functionality in a typical home environment.

2. Safety Information

To prevent injury or damage to the product, please observe the following safety precautions:

- **Read all instructions:** Ensure you understand all assembly and usage instructions before proceeding.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 50 kg (110 lbs) for the top surface. Overloading can cause the unit to collapse, resulting in injury or damage.
- **TV Size:** This stand is suitable for TVs up to 42 inches. Ensure your TV's base fits within the top surface dimensions.
- **Stable Placement:** Always place the TV stand on a flat, level, and stable surface.
- **Children Safety:** Keep small parts and packaging materials away from children. Do not allow children to climb on or play with the TV stand.
- **Proper Assembly:** Ensure all screws and fasteners are securely tightened before use. Periodically check and re-

tighten as necessary.

- **Moving the Unit:** When moving the TV stand, ensure the brakes on the wheels are disengaged. Move slowly and carefully, especially if a TV or other items are on the stand. Engage brakes once in desired position.

3. Package Contents

Before beginning assembly, please verify that all parts listed in the assembly diagram are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

4. Assembly Instructions

Assembly of this TV stand is required. Please follow the detailed instructions and diagrams provided in the separate assembly guide included with your product. Typically, assembly involves:

1. **Unpacking:** Carefully unpack all components and hardware.
2. **Hardware Identification:** Identify all screws, dowels, and other fasteners.
3. **Frame Construction:** Assemble the main frame of the TV stand.
4. **Drawer Assembly:** Construct the two storage drawers.
5. **Shelf Installation:** Install the fixed and adjustable shelves.
6. **Wheel Attachment:** Securely attach the swivel wheels to the base of the unit.
7. **Final Checks:** Ensure all connections are tight and the unit is stable before placing any items on it.

Tools required for assembly are typically a screwdriver and possibly a hammer (not included).

5. Operating Instructions

5.1. Swivel Wheels with Brakes

The TV stand is equipped with five 360-degree swivel wheels, allowing for easy movement and repositioning. Each wheel includes a brake mechanism to secure the stand in place.

- **To Move:** Push the brake lever on each wheel upwards to disengage the brake. The stand can then be freely rolled to the desired location.
- **To Secure:** Once the stand is in its desired position, push the brake lever on each wheel downwards to engage the brake. This will lock the wheels and prevent unintended movement.



Image 5.1: Illustration of the swivel wheels and their brake function for easy mobility and stability.

5.2. Adjustable Shelves

The side shelves of the TV stand are adjustable to three different height levels, providing flexibility to accommodate various media devices, books, or decorative items.

- **To Adjust:** Remove any items from the shelf. Carefully lift the shelf and reposition the shelf pins (or similar support mechanism) into the desired holes on the side panels. Ensure the shelf is level and securely seated on all four pins before placing items back on it.



Image 5.2: Visual guide for adjusting the side shelves to customize storage space.

5.3. Storage Drawers

The two integrated drawers provide concealed storage for accessories, remote controls, or other items, helping to keep your entertainment area tidy.

- **To Use:** Simply pull the drawer handle to open and push to close. Avoid overloading the drawers to ensure smooth operation and prevent damage.



Image 5.3: The TV stand's drawers offer convenient and discreet storage solutions.

6. Maintenance

To maintain the appearance and longevity of your HOMCOM TV stand, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. For general cleaning, use a dry cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent moisture damage.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as needed to maintain stability.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.

7. Troubleshooting

If you encounter any issues with your HOMCOM TV stand, please refer to the following common solutions:

- **Wobbly Stand:** Ensure all assembly screws are fully tightened. Check that the stand is placed on a level surface. Adjust the wheels if necessary to ensure even contact with the floor.
- **Drawers Not Sliding Smoothly:** Check for any obstructions in the drawer slides. Ensure the drawer runners are correctly aligned and free of debris.
- **Missing Parts:** If you find any parts missing during assembly, do not attempt to force assembly. Contact customer support immediately for assistance.

8. Specifications

Feature	Detail
Model Number	IT83B-554V00ND0631
Overall Dimensions (L x W x H)	102 x 34.5 x 48.5 cm (40.2 x 13.6 x 19.1 inches)
Material	Engineered Wood
Color	Natural Wood
Weight Capacity (Top Surface)	50 kg (110 lbs)
Maximum TV Size	42 inches
Number of Drawers	2
Number of Shelves	5 (including top surface and adjustable side shelves)
Special Features	Adjustable shelves, 360° Swivel wheels with brake
Item Weight	20 kg (44 lbs)



Image 8.1: The TV stand is designed to support televisions up to 42 inches.



Image 8.2: Dimensional overview of the TV stand, including length, width, height, and drawer measurements.

9. Warranty Information

This HOMCOM product is covered by a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase or contact your retailer for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

10. Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact HOMCOM customer support. Contact information can typically be found on the product packaging, the retailer's website, or by visiting the official HOMCOM website.

We are committed to providing you with a high-quality product and excellent service.

© 2026 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FWBD1Y1F

More documents and user manuals: **https://manuals.plus/**