

[Manuals.plus](#) /

› [YEAUPE PRO](#) /

› YEAUPE Pro Vertical Outdoor Awning 100 x 300 cm, Dark Grey - Instruction Manual

YEAUPE PRO klemmmarkise

YEAUPE Pro Vertical Outdoor Awning 100 x 300 cm, Dark Grey - Instruction Manual

Model: klemmmarkise | Brand: YEAUPE PRO

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your YEAUPE Pro Vertical Outdoor Awning. Designed for easy, no-drilling installation, this awning offers effective sun, wind, and privacy protection for your balcony, terrace, or garden. Please read these instructions carefully before installation and use to ensure safe and optimal performance.

SAFETY INFORMATION

- Ensure the awning is securely clamped between stable surfaces (floor and ceiling/balcony overhang).
- Do not use the awning in strong winds or severe weather conditions. Retract the awning fully to prevent damage.
- Keep children and pets away from the awning during operation to prevent accidents.
- Regularly check all connections and components for tightness and wear.
- Do not hang heavy objects on the awning structure.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. Refer to the diagram below for component identification.




Figure 1: Key components of the YEAUPE Pro Vertical Outdoor Awning. This image shows the telescopic pole with height adjustment holes, the smooth winding mechanism, stable adjustable feet for tension mounting, and the easy-to-use crank operation.

- Telescopic Poles (2x)
- Awning Fabric (1x) - 100x300cm, Dark Grey Polyester
- Upper and Lower Crossbars (2x)
- Crank Handle (1x)
- Adjustable Feet/Clamping Mechanisms (2x sets)
- Assembly Hardware (screws, bolts, etc.)
- Instruction Manual (this document)

SETUP INSTRUCTIONS (NO DRILLING INSTALLATION)

The YEAUPE Pro Vertical Outdoor Awning features a pre-installed telescopic mechanism for easy, no-drilling setup. Two people are recommended for assembly.

1. **Prepare the Installation Area:** Ensure the floor and ceiling/overhang where the awning will be installed are clean, stable, and capable of withstanding pressure. Measure the height of your installation area. The telescopic poles extend up to 300cm.
2. **Assemble the Poles:** Attach the adjustable feet to the bottom of the telescopic poles. Insert the upper crossbar into the designated slots on the telescopic poles.
3. **Attach the Awning Fabric:** Slide the awning fabric onto the upper and lower crossbars. Ensure the fabric is correctly oriented.
4. **Position the Awning:** Carefully position the assembled awning in the desired location. Extend the telescopic poles until they make contact with the ceiling/overhang and the floor.
5. **Secure the Awning:** Use the clamping mechanisms on the adjustable feet to apply tension, securing the awning firmly in place between the floor and ceiling/overhang. Ensure the poles are vertical and stable. No drilling is required; the tension mechanism holds the awning.
6. **Install the Crank Handle:** Attach the crank handle to the winding mechanism on the side of the awning.



Figure 2: Illustration of the simple clamp installation method, highlighting the no-drilling requirement and the top clamping mechanism.

YEAUPE PRO

Comprehensive Protection

All-round protection from sun, wind, rain, and curious eyes



Figure 3: Examples of the awning installed in various outdoor settings, providing comprehensive protection.

OPERATING INSTRUCTIONS

The awning is operated manually using the provided crank handle.

1. **Extend the Awning:** Turn the crank handle clockwise to lower and extend the awning fabric.
2. **Retract the Awning:** Turn the crank handle counter-clockwise to raise and retract the awning fabric.
3. **Adjust Height:** The height of the awning can be adjusted by extending or retracting the telescopic poles. For fine adjustments, use the holes on the pole or rotate the handle on the clamping mechanism. This allows you to optimize the shaded area based on sun position.



Figure 4: The awning in use, demonstrating its effectiveness in creating a comfortable outdoor space.

MAINTENANCE


- **Cleaning the Fabric:** The high-density polyester fabric is easy to clean. Use a mild soap solution and a soft brush or cloth. Rinse thoroughly with water and allow to air dry completely before retracting. Do not use harsh chemicals or abrasive cleaners.
- **Frame Maintenance:** The powder-coated aluminum casing and galvanized iron components are corrosion-resistant. Wipe down the frame with a damp cloth periodically to remove dirt and debris.
- **Seasonal Storage:** For prolonged periods of non-use or during winter months, it is recommended to retract the awning fully and, if possible, store it in a dry, protected area to extend its lifespan.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Awning does not extend/retract smoothly.	Obstruction in the mechanism; fabric misalignment; dirt/debris in the winding mechanism.	Check for obstructions. Ensure fabric is aligned correctly on the bars. Clean the winding mechanism.
Awning feels unstable after installation.	Insufficient tension from clamping mechanism; poles not vertical.	Re-adjust the telescopic poles and tighten the clamping mechanisms to ensure maximum tension. Verify poles are perfectly vertical.
Fabric appears wrinkled or not taut.	Initial packaging creases; uneven tension during extension.	Creases from packaging will naturally reduce over time with use. Ensure even extension and retraction.

SPECIFICATIONS



Product Specifications

Bracket height	Fabric size 1	Fabric size 2	Fabric size 3	Fabric size 4
220-300cm	100*270cm	120*270cm	150*270cm	200*270cm

Figure 5: Product dimensions and available fabric sizes for the YEAUPE Pro Vertical Outdoor Awning.

Model: klemmmarkise

Dimensions (Fabric): 100 x 300 cm (Width x Height)

Adjustable Height (Poles): 220 - 300 cm

Color: Dark Grey

Material: 180 g/m² Polyester with PU coating

Frame Material: Powder-coated Aluminum (main bar), Galvanized Iron (components)

Operation: Manual crank

Assembly: Required, no drilling

Weather Resistance: Water-resistant, UV ray blocking, wind protection

WARRANTY INFORMATION

Specific warranty details for the YEAUPE Pro Vertical Outdoor Awning may vary by region and retailer. Please retain your proof of purchase. For information regarding warranty coverage and claims, refer to the documentation provided at the time of purchase or contact your retailer directly.

CUSTOMER SUPPORT

If you encounter any issues or have questions not covered in this manual, please contact YEAUPE PRO customer service. You can typically find contact information on the product packaging or through the retailer where you purchased the awning. For online support, visit the [YEAUPE PRO Brand Store](#).

ADDITIONAL INFORMATION

No official product videos from the seller were found to be relevant for embedding in this instruction manual.

© 2026 YEAUPE PRO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FWBHN8X7>

More documents and user manuals: <https://manuals.plus/>