Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OYLUS DL16F#EH-0101

OYLUS 1500W Electric Fireplace Baseboard Heater

Model: DL16F#EH-0101

1. Important Safety Instructions

Please read this entire instruction manual before installing or using this electric fireplace baseboard heater. Failure to follow these instructions may result in fire, electric shock, serious injury, or property damage. Keep this manual for future reference.

General Safety Precautions:

- Ensure the heater is plugged into a properly grounded 120V AC outlet.
- Do not operate the heater with a damaged cord or plug.
- Keep combustible materials (furniture, bedding, papers, clothes, curtains) at least 3 feet (0.9 meters) from the front, sides, and rear of the heater.
- Do not use the heater in bathrooms, laundry areas, or similar indoor locations where it may come into contact with water.
- Never block air openings or place the heater on a soft surface where openings may be blocked.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- Close supervision is necessary when any heater is used by or near children or individuals with reduced physical, sensory, or mental capabilities.
- Do not cover the heater.

Integrated Safety Features:

- **Tip-Over Protection:** The heater automatically shuts off if it is accidentally tipped over.
- **Overheat Protection:** The heater will automatically shut off if it detects overheating.
- **Flame-Retardant Materials:** Constructed with materials designed to resist flame.
- **Enhanced Safety Plug:** Designed for secure and safe electrical connection.



Image: Overview of the heater's safety features, including automatic shut-off for tip-over and overheating, flame-retardant materials, and an enhanced safety plug.

2. Product Overview

The OYLUS Electric Fireplace Baseboard Heater combines efficient heating with a realistic 3D flame effect. This 2-in-1 unit is designed to provide warmth and ambiance to your living space. It features an adjustable thermostat, multiple heat settings, and a convenient timer function.

Key Features:

- **Dual Heating Modes:** Offers 750W for energy-efficient warmth and 1500W for rapid heating.
- **Realistic 3D Flame Effect:** Provides visual ambiance that can be operated independently of the heat.
- **Adjustable Thermostat:** Allows temperature control from 59°F to 99°F (15°C to 37°C).
- **1-12 Hour Timer:** For scheduled operation and energy saving.
- **Quiet Operation:** Designed to operate at a low noise level, suitable for bedrooms and offices.

- **Compact and Portable Design:** Easy to move and fits well in various spaces.



Image: The OYLUS baseboard heater showcasing its realistic flame effect in a home environment.

Your browser does not support the video tag.

Video: An overview of the OYLUS Baseboard Heater with Fireplace, demonstrating its features and compact design.

3. Setup

The OYLUS Electric Fireplace Baseboard Heater requires no complex installation. It is designed for immediate use upon unboxing.

Initial Placement:

1. Unpack the heater and remove all packaging materials.
2. Place the heater on a firm, level surface. Ensure there is adequate clearance from walls, furniture, and other objects to allow for proper airflow and prevent fire hazards. Maintain at least 3 feet (0.9 meters) of clearance around the heater.
3. Plug the power cord into a standard 120V AC electrical outlet. Ensure the outlet is in good condition and not overloaded.



Image: The compact dimensions of the OYLUS heater, illustrating its space-saving design.

4. Operating Instructions

The heater can be operated using the control panel on the unit or the included remote control.

Control Panel Functions:



Image: Detailed view of the LED touch screen control panel on the heater.

- **ON/OFF Button:** Press to turn the heater on or off.
- **FLAME Button:** Activates or deactivates the 3D flame effect. The flame can be used independently without heat.
- **MODE Button:** Cycles through heat settings (750W, 1500W, or Flame & Heat combined).
- **TIMER Button:** Sets the auto-off timer from 1 to 12 hours.

Remote Control:

The remote control provides convenient access to all functions from a distance.



Image: Remote control in use, demonstrating temperature adjustment.

- **TEMP UP/DOWN:** Adjusts the desired temperature (59-99°F).
- **ON/OFF:** Powers the unit on or off.
- **MODE:** Selects heating power (750W or 1500W).
- **FLAME:** Controls the flame effect.
- **TIMER:** Sets the auto-off timer.

Heat Settings:

- **750W Setting:** Provides energy-efficient warmth, ideal for maintaining comfort in smaller spaces or for extended use.
- **1500W Setting:** Delivers rapid heating for quickly warming larger rooms or when immediate warmth is desired.



Image: Visual representation of the two heat output settings (750W and 1500W).

Flame Effect Operation:

The realistic 3D flame effect can be activated with or without the heating function, allowing you to enjoy the ambiance year-round.

Timer Function:

Set the auto-off timer for up to 12 hours. This feature is useful for ensuring the heater turns off automatically, promoting energy efficiency and peace of mind.

Your browser does not support the video tag.

Video: Demonstration of the OYLUS Baseboard Heater's 3D flame effect and control panel functions.

5. Maintenance

Regular maintenance helps ensure the longevity and efficient operation of your OYLUS heater.

Cleaning:

- Always unplug the heater from the power outlet and allow it to cool completely before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Gently vacuum or wipe any dust from the air intake and exhaust vents.
- Do not immerse the heater in water or spray water directly onto it.

Storage:

When not in use, store the heater in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

6. Troubleshooting

If you experience issues with your OYLUS heater, refer to the following common troubleshooting steps:

- **Heater not turning on:** Check if the power cord is securely plugged into a working outlet. Ensure the ON/OFF button is pressed.
- **No heat output:** Verify that a heat mode (750W or 1500W) is selected. Check if the thermostat setting is higher than

the current room temperature.

- **Flame effect not working:** Press the FLAME button to activate the flame effect.
- **Heater shuts off unexpectedly:** This may be due to the tip-over or overheat protection. Ensure the heater is on a stable surface and not covered. Unplug the unit, wait a few minutes, and then plug it back in.
- **Remote control not working:** Check the batteries in the remote control and replace if necessary. Ensure there are no obstructions between the remote and the heater.

If the problem persists after trying these steps, please contact customer support.

7. Specifications

Feature	Specification
Brand	OYLUS
Model Name	baseboard heater with fireplace
Item Model Number	DL16F#EH-0101
Power Source	AC
Heat Output	1500 Watts
Product Dimensions	5.9"D x 33.3"W x 8.5"H
Item Weight	8.8 Pounds
Material	Plastic
Installation Type	Freestanding
Color	Classic Black
Room Type	Bedroom, Dining Room, Home Office, Kitchen, Living Room
Included Components	Heater Body, Remote Control, User Manual
UPC	607609477600

8. Warranty and Support

Limited Warranty:

This OYLUS product comes with a limited warranty. Please refer to the warranty card included in your packaging for specific terms and conditions. Keep your purchase receipt as proof of purchase.

Customer Support:

For technical assistance, troubleshooting, or warranty claims, please contact OYLUS customer support through the retailer where the product was purchased or refer to the contact information provided on the product packaging or the official OYLUS website.

© 2025 OYLUS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FWBQB3ZM

More documents and user manuals: **https://manuals.plus/**