

OLIXIS CAB-7BC-PK

OLIXIS 7-Drawer Fabric Dresser User Manual

Model: CAB-7BC-PK

Brand: OLIXIS

1. INTRODUCTION

Thank you for choosing the OLIXIS 7-Drawer Fabric Dresser. This versatile storage tower is designed to provide ample and organized storage for your bedroom, living room, or entryway. Featuring a sturdy steel frame, a durable wooden top, and easy-pull fabric bins, this dresser combines functionality with a modern aesthetic. Please read this manual carefully before assembly and use to ensure proper setup and longevity of your product.



Image 1: The OLIXIS 7-Drawer Fabric Dresser in Pink, showcasing its design and multiple drawers.

2. COMPONENTS OVERVIEW

Before beginning assembly, please ensure all parts listed below are present and undamaged. Refer to the included parts list in your packaging for specific quantities and identification.

- **Steel Frame:** Provides the main structural support for the dresser.
- **MDF Wooden Top:** A durable surface for displaying items or additional storage.
- **Fabric Drawers:** Seven non-woven fabric bins (three smaller, four larger) with breathable synthetic fiber structure.
- **Handles:** Easy-pull plastic handles for each drawer.
- **Adjustable Feet:** For stability on uneven floors.
- **Reinforced Crossbars:** For enhanced structural integrity.
- **Anti-Tip Kit:** For securing the dresser to a wall, ensuring safety.
- **Assembly Tools:** Necessary tools for assembly are included.

3. SETUP AND ASSEMBLY

The OLIXIS 7-Drawer Fabric Dresser is designed for hassle-free assembly, typically taking around 20 minutes. Follow the step-by-step instructions provided in your package. An installation video is also available to guide you through the process.

3.1 Assembly Steps

1. Unpack all components and verify against the parts list.
2. Assemble the steel frame using the provided tools and screws.
3. Attach the MDF wooden top securely to the assembled frame.
4. Insert the fabric drawers into their designated slots.
5. Install the easy-pull handles onto each fabric drawer.
6. Adjust the feet to ensure the dresser is stable and level on your floor.
7. For added safety, install the anti-tip kit to secure the dresser to a wall.

3.2 Assembly Video

Your browser does not support the video tag.

Video 1: A user demonstrating the quick and easy assembly of a similar OLIXIS dresser, highlighting its simple setup.

4. OPERATING INSTRUCTIONS

The OLIXIS 7-Drawer Fabric Dresser is designed for convenient and versatile storage. Its multiple drawers provide ample space for various items.

4.1 Drawer Usage

- Use the easy-pull handles to smoothly open and close the fabric drawers.
- The dresser features three smaller drawers and four larger drawers, allowing for organized storage of different-sized items.
- The wooden top provides an additional surface for decor or frequently accessed items.

4.2 Weight Capacity

The unit is built with a strong steel frame and reinforced crossbars, supporting a maximum load capacity of **66 lbs (30 kg)**. Avoid exceeding this weight limit to ensure stability and prevent damage.



Size Information

Maximum load capacity 66 Lbs




Image 2: An illustration detailing the approximate weight capacity and storage volume for both medium (7 lbs) and large (11 lbs) drawers.

4.3 Versatile Placement

This dresser is suitable for various rooms and purposes:

- **Bedroom:** Ideal for clothes, linens, and personal items.
- **Nursery:** Perfect for baby clothes, blankets, and diapers.
- **Living Room/Entryway:** Great for organizing daily essentials, accessories, or small household items.

Your browser does not support the video tag.

Video 2: A video showcasing the dresser's use as an organizer in a bedroom or closet, highlighting its practical storage.

5. MAINTENANCE AND CARE

To keep your OLIXIS dresser in optimal condition, follow these simple maintenance guidelines:

- **Cleaning:** The non-woven fabric drawers are easy to clean. Simply wipe them with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Frame Care:** Wipe the steel frame and wooden top with a soft, dry cloth to remove dust.
- **Drawer Integrity:** Ensure drawers are not overloaded to maintain their shape and functionality.

Durable & Breathable






Image 3: Close-up of the durable and breathable fabric material of the drawers, highlighting the plastic handles and construction.

6. TROUBLESHOOTING

If you encounter any issues with your dresser, please refer to the following common solutions:

- **Unstable Dresser:** Check that all screws are tightened. Adjust the leveling feet to ensure the dresser sits evenly on the floor.


- **Drawer Not Sliding Smoothly:** Ensure the drawer is correctly aligned within its slot. Check for any obstructions.
- **Missing or Damaged Parts:** If any parts are missing or damaged upon arrival, please contact our customer support immediately for assistance.

7. SPECIFICATIONS


Feature	Detail
Brand	OLIXIS
Model Name	CAB-7BC-PK
Product Dimensions (D x W x H)	11.8"D x 39.4"W x 30"H
Number of Drawers	7
Material	Fabric, Wood (MDF top), Steel (frame)
Color	Pink
Item Weight	25.7 Pounds
Maximum Load Capacity	66 lbs
Assembly Required	Yes

Studay Structure

No Deformation



Anti-Tilt Device



Cross Support
for Stability



Image 4: Detailed size information for the dresser, including depth, width, and height.

8. WARRANTY AND SUPPORT

OLIXIS is committed to providing high-quality products and excellent customer service. If you have any questions, concerns, or require assistance with your dresser, please do not hesitate to contact our friendly support team. We aim to respond to all inquiries within 24 hours.

For support, please visit the [OLIXIS Store on Amazon](#) or refer to the contact information provided in your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question