

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Teamson Home](#) /

› [Teamson Home Modern Oval Outdoor Water Fountain \(Model FT4324GRR\) Instruction Manual](#)

## Teamson Home FT4324GRR

# Teamson Home Modern Oval Outdoor Water Fountain

Model: FT4324GRR

## PRODUCT OVERVIEW

---

The Teamson Home Modern Oval Outdoor Water Fountain is designed to enhance your outdoor or indoor space with its contemporary oval design and soothing water flow. Crafted from durable polyresin, stone powder, and fiberglass, this weather-resistant fountain features a dual water flow system and integrated LED lighting for an elegant ambiance. It operates with an electric pump, providing a continuous, calming water sound.

- **Sculptural Design:** A sleek gray oval design with cascading water and built-in LED lighting creates a calming, elegant ambiance.
- **Durable Construction:** Made from polyresin, stone powder, and fiberglass for long-lasting outdoor use.
- **Compact Size:** Measures 15.75" L x 9.84" W x 31.3" H, making it suitable for various spaces without overwhelming them.
- **Easy Setup:** Simple assembly and operation with a single plug-in.

Designed for Everyday Living

---

For **Indoor & Outdoor Use**



Front view of the Teamson Home Modern Oval Outdoor Water Fountain, showcasing its design and water flow.

## SAFETY INFORMATION

---

- Always place the fountain on a firm, level surface to prevent tipping.
- Ensure the power cord is connected to a Ground Fault Circuit Interrupter (GFCI) outlet for electrical safety.
- Keep children and pets away from the fountain during operation to prevent accidents.
- Do not operate the pump without sufficient water, as this can damage the pump.
- Disconnect the power supply before performing any maintenance or cleaning.
- Do not use the fountain in freezing temperatures. Drain and store indoors during winter.

## PACKAGE CONTENTS

---

Please check to ensure all components are present and undamaged:

- Fountain Body (1)

- Electric Water Pump (1)
- Power Adapter (1)
- LED Light (pre-installed or separate) (1)
- Instruction Manual (1)

## SETUP INSTRUCTIONS

---

Follow these steps for proper assembly and initial setup:

1. **Unpack:** Carefully remove all components from the packaging and place them on a soft, clean surface.
2. **Position the Fountain:** Place the fountain body on a stable, level surface in your desired indoor or outdoor location. Ensure it is near a GFCI-protected electrical outlet.
3. **Install the Pump:** Submerge the electric pump completely in the water reservoir at the base of the fountain. Connect the pump's tubing to the water inlet on the fountain body.
4. **Connect LED Light:** If the LED light is separate, connect its cable to the corresponding connector from the pump or power adapter. Ensure all connections are secure.
5. **Fill with Water:** Fill the fountain reservoir with distilled or filtered water until the pump is fully submerged. Do not overfill.
6. **Connect Power:** Plug the power adapter into the GFCI-protected electrical outlet. The fountain should begin operating immediately.



The fountain positioned in an indoor setting, ready for operation.

## Setup Video Guide

Your browser does not support the video tag.

This video demonstrates the visual features and operation of the Teamson Home Modern Oval Outdoor Water Fountain, providing a helpful guide for understanding its setup and function.

## OPERATING INSTRUCTIONS

- **Power On/Off:** To start the fountain, plug the power adapter into a working GFCI outlet. To turn it off, simply unplug the adapter.
- **Water Flow Adjustment:** Some pumps may have an adjustable flow control switch. If present, rotate the switch on the pump to increase or decrease the water flow to your preference.
- **LED Light:** The integrated LED light will illuminate automatically when the fountain is powered on.



A close-up view illustrating the dual water flow and the warm ambient LED lighting.

## MAINTENANCE

---

Regular maintenance ensures optimal performance and longevity of your fountain.

- **Water Level:** Check the water level daily and refill every few days to ensure the pump remains fully submerged. Low water levels can cause pump damage.
- **Water Quality:** Use distilled or filtered water to minimize mineral buildup and algae growth.
- **Cleaning:** Clean the fountain monthly. Disconnect power, drain the water, and wipe down surfaces with a soft cloth and mild soap. Rinse thoroughly. Clean the pump filter regularly to prevent blockages.
- **Algae Control:** If algae is an issue, use an algaecide specifically designed for fountains (follow product instructions).
- **Winterization:** Before the first freeze, drain all water from the fountain and pump. Clean and dry all components. Store the fountain and pump indoors in a dry, protected area to prevent damage from ice expansion.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Fountain does not operate	No power; Pump clogged; Insufficient water.	Check power connection and GFCI outlet; Clean pump and filter; Add water to reservoir.
Water flow is weak	Low water level; Clogged pump/tubing; Pump flow control set too low.	Add water; Clean pump and tubing; Adjust pump flow control.
Excessive pump noise	Pump not fully submerged; Debris in pump; Pump vibrating against fountain.	Add water; Clean pump impeller; Adjust pump position to prevent contact.
Algae growth	Sunlight exposure; Untreated water.	Clean fountain regularly; Use algaecide; Change water frequently.

## SPECIFICATIONS

Feature	Detail
Model Number	FT4324GRR
Color	Gray
Material	Polyresin (50%), Stone Powder (15%), Paint (10%), Fiberglass (10%), Electrical Components (15%)
Product Dimensions	15.75" L x 9.84" W x 31.3" H
Item Weight	20.94 Pounds
Power Source	Corded Electric
Special Feature	Weather Resistant
UPC	810136546811

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Teamson Home website. Keep your purchase receipt as proof of purchase for any warranty claims.