

[Manuals.plus](#) /

› [REVOTRA](#) /

› REVOTRA Single Serve Coffee Maker Instruction Manual

REVOTRA CM9429B-UL

REVOTRA Single Serve Coffee Maker Instruction Manual

Model: CM9429B-UL

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the REVOTRA Single Serve Coffee Maker. Keep this manual for future reference.

- Ensure the coffee maker is placed on a stable, level surface away from the edge of the countertop.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the coffee maker from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only.
- Always ensure the water reservoir is filled to the appropriate level before brewing.
- Exercise caution when handling hot liquids and steam.

IMPORTANT



Please remove the red silicone from the water tank before using the coffee maker.

Important Note: Before initial use, locate and remove the red silicone plug from the bottom of the water tank. Failure to do so will prevent water from flowing into the machine.

PRODUCT OVERVIEW

The REVOTRA Single Serve Coffee Maker is designed for convenience and versatility, allowing you to brew coffee from both pods and ground coffee. Its compact design makes it suitable for various spaces, and the removable water reservoir simplifies refilling.

Key Features:

- **Dual Compatibility:** Brews with K-Cup pods and ground coffee.
- **Multiple Brew Sizes:** Offers 6, 8, 10, 12, and 14 oz options.
- **Strong Brew Option:** For a richer, bolder coffee flavor.
- **Fast Brewing:** Rapid heating technology for quick coffee preparation.
- **Compact Design:** Space-saving footprint for kitchens, offices, dorms, and RVs.
- **Removable 40 oz Water Reservoir:** Large capacity for multiple brews and easy refilling.
- **Travel Mug Friendly:** Drip tray can be removed to accommodate taller travel mugs.
- **Auto Shut-Off:** Automatically powers down after 5 minutes of standby for safety and energy efficiency.
- **BPA-Free Materials:** Constructed with safe, food-grade materials.

5 Cup Sizes

6, 8, 10, 12 and 14oz



The REVOTRA coffee maker offers five different brew sizes, from 6 to 14 ounces, to suit your preference.



3-in-1 Brewing

This coffee maker supports 3-in-1 brewing, accommodating K-Cup capsules, ground coffee, and loose leaf tea.

Removable 40 oz Water Tank

Large capacity water tank for easy refilling and cleaning



The removable 40 oz water tank allows for easy refilling and cleaning, minimizing the need for frequent water additions.

SETUP

Follow these steps to set up your REVOTRA Single Serve Coffee Maker for the first time.

1. **Unpack the Coffee Maker:** Carefully remove all packaging materials from the box.
2. **Remove Red Silicone Plug:** Locate the red silicone plug at the bottom of the removable water tank and remove it. This is crucial for water flow.
3. **Place Drip Tray:** Ensure the removable drip tray is securely in place at the base of the coffee maker.
4. **Clean Components:** Wash the water reservoir, pod holder, and reusable filter in warm, soapy water. Rinse thoroughly and dry.
5. **Fill Water Reservoir:** Fill the removable water reservoir with fresh, cold water up to the 'MAX' line (40 oz). Place it back onto the coffee maker.
6. **First Cleanse Brew:** Before brewing coffee, perform a cleansing cycle. Place an empty mug on the drip tray, close the lid, select the largest cup size (14 oz), and press the 'Regular' brew button. Discard the hot water. This cleans

the internal components.

Your browser does not support the video tag.

Watch this video for a visual guide on unboxing and initial setup of your REVOTRA Single Serve Coffee Maker.

OPERATING INSTRUCTIONS


Brewing your favorite beverage is simple with the REVOTRA coffee maker. Ensure the water reservoir is filled before starting.

Brewing with K-Cup Pods:

1. Lift the lid of the coffee maker.
2. Insert a K-Cup pod into the pod holder. Ensure it is seated correctly.
3. Close the lid firmly.
4. Place your mug on the drip tray. For taller mugs, remove the drip tray.
5. Select your desired cup size (6, 8, 10, 12, or 14 oz) using the 'Cup Size' button.
6. Choose your brew strength: press 'Regular' for a standard brew or 'Strong' for a bolder flavor.
7. The machine will begin brewing. Wait for the brewing cycle to complete.

Brewing with Ground Coffee or Loose Leaf Tea:

1. Lift the lid of the coffee maker.
2. Remove the K-Cup pod holder if it's in place.
3. Insert the reusable filter into the brewing chamber.
4. Add your desired amount of ground coffee or loose leaf tea into the reusable filter. Do not overfill.
5. Close the lid firmly.
6. Place your mug on the drip tray.
7. Select your desired cup size and brew strength as described above.
8. The machine will begin brewing.



A visual representation of the simple 6-step brewing process.



The coffee maker in action, dispensing a fresh cup of coffee.

MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your coffee maker.

Daily Cleaning:

- **Water Reservoir:** Empty any remaining water and rinse the reservoir with fresh water daily.
- **Pod Holder/Reusable Filter:** After each use, remove and rinse the pod holder or reusable filter. Wash with warm, soapy water as needed.
- **Drip Tray:** Empty and rinse the drip tray daily to prevent overflow and residue buildup.
- **Exterior:** Wipe the exterior of the coffee maker with a damp cloth. Do not use abrasive cleaners.

Descaling (Monthly or as needed):

Mineral deposits can build up over time, affecting performance. Descale your coffee maker regularly.

1. Fill the water reservoir with a mixture of one part white vinegar and two parts water.
2. Place a large mug on the drip tray.
3. Run a brew cycle without a pod or ground coffee, selecting the largest cup size.
4. Repeat this process until the reservoir is empty.
5. Rinse the reservoir and fill it with fresh water.
6. Run several full water cycles to flush out any remaining vinegar solution.



The removable components of the coffee maker are designed for easy cleaning.

TROUBLESHOOTING

If you encounter any issues with your REVOTRA Single Serve Coffee Maker, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Coffee not brewing / No water dispensing	Water reservoir empty or not properly seated. Red silicone plug not removed. Clogged needle.	Ensure reservoir is filled and correctly placed. Verify red silicone plug is removed. Clean the needle with a paperclip.
Weak coffee	Insufficient coffee grounds/pod strength. Incorrect brew size selected.	Use more coffee grounds or a stronger pod. Select a smaller cup size or the 'Strong' brew option.
Slow brewing	Mineral buildup (needs descaling). 'Strong' brew option selected.	Perform a descaling cycle. Note that 'Strong' brew intentionally slows the process for richer extraction.
Coffee grounds in cup	Reusable filter overfilled or not properly closed.	Do not overfill the reusable filter. Ensure the lid is securely closed.
Machine not turning on	Not plugged in. Power outlet issue.	Check if the power cord is securely plugged into a working outlet.

Problem	Possible Cause	Solution
---------	----------------	----------

SPECIFICATIONS


Feature	Detail
Brand	REVOTRA
Model Number	CM9429B-UL (ASIN: B0FWCDSMYG)
Product Dimensions	11.1"D x 5.5"W x 11.9"H
Water Reservoir Capacity	40 ounces
Brew Sizes	6, 8, 10, 12, 14 ounces
Coffee Input Type	Ground Coffee, Pods
Special Features	Adjustable Brew Strength, Removable Tank, Single Cup Brew, Water Filter, Auto Shut-off
Operation Mode	Fully Automatic
Item Weight	5.59 pounds

REVOTRA

PRODUCT DIMENSIONS

- 12 in High
- 5.5 in Wide
- 10.6 in Deep

5.5 in



5 in



6.3 in

12 in

10.6 in



Detailed product dimensions for placement and compatibility.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official REVOTRA website. Keep your purchase receipt as proof of purchase for any warranty claims. For additional assistance, you may contact REVOTRA customer service directly.



