

CROWNFUL FS301-CE

CROWNFUL Slushie and Soft Serve Ice Cream Machine (Model FS301-CE) User Manual

Brand: CROWNFUL

Model: FS301-CE

1. INTRODUCTION

Thank you for choosing the CROWNFUL Slushie and Soft Serve Ice Cream Machine. This appliance is designed to create a variety of frozen beverages and desserts, including slushies, soft serve ice cream, margaritas, frappés, milkshakes, and frozen juices, quickly and conveniently in your home. This manual provides essential information for safe operation, setup, usage, maintenance, and troubleshooting to ensure optimal performance and longevity of your machine.

Please read this manual thoroughly before first use and retain it for future reference.



Image: CROWNFUL Slushie and Soft Serve Ice Cream Machine in operation.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. These include:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.

- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended household use.

3. PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the main components of your CROWNFUL Slushie Machine:

- **Main Unit:** Houses the motor, compressor, and control panel.
- **Transparent Tank:** Where ingredients are mixed and frozen. It has MIN/MAX fill lines.
- **Auger/Mixing Paddle:** Rotates inside the tank to process ingredients.
- **Dispensing Handle:** Used to release the finished product.
- **Drip Tray:** Collects any drips from the dispenser.
- **Control Panel:** Features an LED display, 6 preset program buttons, temperature display, and thickness adjustment settings.



Image: Side view of the machine with key dimensions.

4. SETUP AND FIRST USE

Before using your CROWNFUL Slushie Machine for the first time, follow these steps:

1. **Unpack:** Carefully remove all packaging materials and ensure all components are present and undamaged.
2. **Clean:** Wash the transparent tank, auger, dispensing handle, and drip tray with warm, soapy water. Rinse thoroughly and dry completely. The main unit should be wiped with a damp cloth.
3. **Assemble:** Place the auger inside the transparent tank, then securely attach the tank to the main unit. Ensure the dispensing handle is correctly installed. Position the drip tray at the base of the machine.
4. **Placement:** Place the machine on a stable, flat, and dry surface, away from direct sunlight or heat sources. Ensure adequate ventilation around the unit.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.

ETL-Certified Premium Frozen Drink Maker



Image: The machine highlighting its food-grade materials and ease of assembly.

5. OPERATING INSTRUCTIONS

Your CROWNFUL Slushie Machine features 6 preset programs and adjustable thickness settings for a variety of frozen treats.

General Operation Steps:

1. **Prepare Ingredients:** Ensure your liquid ingredients are chilled for best results. For slushies, ensure your mixture has sufficient sugar content (typically 12-15% sugar) to prevent it from freezing solid.
2. **Pour Ingredients:** Open the lid of the transparent tank and pour your prepared liquid into the tank. Do not exceed the MAX fill line (72oz liquid capacity, 92oz total volume).
3. **Select Program:** Use the touch control panel to select one of the 6 preset programs **Soft Ice Cream**, **Slushie**, **Spiked**, **Frappé**, **Milkshake**, or **Frozen Juice**.
4. **Adjust Thickness (Optional):** The machine offers 10 adjustable thickness settings. Use the up/down arrows on the control panel to select your desired consistency. A higher number indicates a thicker consistency.
5. **Start Operation:** Press the Start button. The machine will begin the freezing process, which typically

takes 15-30 minutes depending on the program and desired thickness. The LED display will show real-time temperature.

6. **Dispense:** Once the program is complete and the desired consistency is reached, place a cup under the dispensing spout and pull the handle to serve.

3 Simple steps to your perfect frozen treat



Pour in the drink



Select Mode



Wait for slushy



Image: Three simple steps for making a frozen treat.

Touch Controls

Make your frozen drink as thick or as light as you like



Image: Touch control panel with program selection and thickness settings.

Tips for Best Results:

- For soft serve ice cream, ensure your mixture is a proper ice cream base, not just milk.
- Always use chilled ingredients to reduce processing time.
- Do not overfill the tank.
- If the mixture is too thick, you may need to adjust the thickness setting or add a small amount of liquid.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures hygiene and extends the life of your appliance. The CROWNFUL Slushie Machine features an automatic cleaning mode and detachable, dishwasher-safe parts.

Automatic Cleaning:

1. Add approximately 85oz of clean water to the transparent tank.
2. Press the **RINSE** button on the control panel to start the self-cleaning cycle.
3. Press the **RINSE** button again to stop the cleaning process once complete.

4. Drain the water through the dispensing spout.



Image: Automatic cleaning process in action.

Deep Cleaning:

- Unplug the machine from the power outlet.
- Disassemble the transparent tank, auger, dispensing handle, and drip tray.
- These removable parts are **dishwasher-safe** for thorough cleaning.
- The evaporator (the metal cylinder inside the tank) should be wiped clean with a damp cloth.**Do not clean with a heated dry cycle in the dishwasher.**
- Wipe the main unit with a clean, damp cloth. Do not immerse the main unit in water.
- Ensure all parts are completely dry before reassembling and storing the machine.



Image: Detachable parts are dishwasher-safe for easy cleaning.

7. TROUBLESHOOTING

If you encounter issues with your CROWNFUL Slushie Machine, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outlet issue; power switch off.	Ensure the power cord is securely plugged into a working outlet. Check the power switch.
Slushie/Frozen drink is not forming or is too liquid.	Insufficient sugar content in mixture; ingredients not chilled; incorrect program selected; thickness setting too low.	Ensure mixture has adequate sugar (12-15%). Use pre-chilled ingredients. Select the appropriate program. Increase the thickness setting.
Soft serve ice cream is too liquid.	Mixture not suitable for soft serve; thickness setting too low.	Use a proper soft serve ice cream base. Increase the thickness setting.
Machine stops during operation or makes unusual noise.	Overload; ice buildup around auger; motor overheating.	Unplug the machine. Remove some mixture if overfilled. Check for ice buildup and clear it. Allow the machine to cool down before restarting.
Dispensing is slow or blocked.	Product too thick; dispensing spout clogged.	Decrease the thickness setting. Ensure the dispensing spout is clear of any frozen debris.

If the problem persists after trying these solutions, please contact CROWNFUL Customer Service.

8. SPECIFICATIONS

Feature	Detail
Brand	CROWNFUL
Model Number	FS301-CE
Color	Matte Black
Material	Plastic
Item Weight	13.1 kg
Parcel Dimensions	53 x 50.4 x 23.4 cm
Liquid Capacity	72 oz (92 oz total volume)
Preset Programs	6 (Soft Ice Cream, Slushie, Spiked, Frappé, Milkshake, Frozen Juice)
Thickness Settings	10 adjustable levels

9. WARRANTY AND CUSTOMER SUPPORT

CROWNFUL is committed to providing high-quality products and excellent customer service.

- **Warranty:** Your CROWNFUL Slushie Machine is covered by a**12-month return and exchange policy** from the date of purchase.

- **Customer Service:** We offer **lifetime customer service** and official guidance to assist you with any questions or issues you may encounter. Our team aims for a **24-hour fast email reply**.

For support, please refer to the contact information provided with your product packaging or visit the official CROWNFUL website.




Image: CROWNFUL customer support details.