



[Manuals.plus](#) /

› [TOPSKY](#) /

› TOPSKY DF02.01 Electric Standing Desk Frame User Manual

## TOPSKY DF02.01

# TOPSKY DF02.01 Electric Standing Desk Frame User Manual

Dual Motor Height Adjustable Sit-Stand Base with CPU Stand and Power Strip

## 1. INTRODUCTION

---

Thank you for choosing the TOPSKY DF02.01 Dual Motor Electric Standing Desk Frame. This desk frame is designed to provide a versatile and ergonomic workspace, allowing seamless transitions between sitting and standing positions. It features a robust dual-motor system, adjustable height and width, an integrated CPU stand, and a convenient power strip for enhanced productivity and organization.

## 2. SAFETY INFORMATION

---

**Please read all safety instructions carefully before assembly and use.**

- Always ensure that the desk is properly assembled and not overloaded. The maximum weight capacity is 225 lbs.
- Use the power strip according to the manufacturer's instructions.
- Supervise children and pets when using the desk to prevent accidents.
- Keep hands and objects clear of moving parts during height adjustments.
- Do not attempt to disassemble or repair the motor or control box yourself. Contact customer support for assistance.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly:

- Dual Motor Lift System (Legs and Crossbar)
- Control Panel with LCD Display
- CPU Holder (Adjustable Under-Desk PC Mount)

- Power Outlet (Integrated Power Strip)
- Cable Management Accessories (Trays and Clips)
- Assembly Tools and Hardware

## 4. SETUP AND ASSEMBLY

Follow these general steps for assembling your TOPSKY Electric Standing Desk Frame. Refer to the detailed instructions provided in your physical manual for specific screw placements and component connections.

### 4.1. Frame Assembly

1. Unpack all components and lay them out on a clean, flat surface.
2. Attach the feet to the bottom of the desk legs.
3. Connect the crossbar to the desk legs, ensuring proper alignment.
4. Securely fasten all screws as indicated in your manual.
5. Mount your chosen desktop (not included) to the assembled frame.

### 4.2. CPU Mount Installation

The adjustable under-desk PC mount helps save space and protect your computer. No drilling is required for installation.



Image: Adjustable Under-Desk PC Mount attached to the desk leg, holding a computer tower.

For a visual guide on installing the CPU mount, please watch the official installation video below:

Video: Installation guide for the TOPSKY Adjustable Under-Desk PC Mount. This video demonstrates measuring your PC tower, marking the desk leg, installing the bracket plate with protective pads, assembling the adjustment bracket, and mounting the bracket to the desk leg to secure your PC tower.

### 4.3. Power Strip and Cable Management

The desk frame includes a bonus power strip with 5 AC outlets, 4 USB-C ports, and 2 USB-A ports. Use the provided cable trays and clips to organize cords and maintain a tidy workspace.

# Plug In Easily Stay Organized




Image: Comparison of a desk with unmanaged cables versus a desk with organized cables, highlighting the integrated power strip and cable management solutions.

- Mount the power strip to the underside of your desktop using the designated attachment points.
- Route all power and data cables through the cable trays and secure them with clips to prevent tangling.

## 5. OPERATION

### 5.1. Height Adjustment

The dual-motor system allows for smooth and quiet height adjustments. Use the control panel with the LCD display to adjust the desk height.

# Adjust to Your Perfect Height



Image: Technical diagram illustrating the adjustable height range (27.5"-47.2") and width (43"-59") of the desk frame.

- **Up/Down Buttons:** Press and hold the up or down arrow buttons to move the desk to your desired height.
- **Memory Presets:** The control panel typically includes memory buttons (e.g., M1, M2, M3). To save a height, adjust the desk to the desired position, then press 'M' followed by the desired number button. To recall a saved height, simply press the corresponding number button.

## 5.2. Using the Integrated Power Hub

The integrated power hub provides convenient access to power for your devices.



Image: Detailed view of the All-in-One Power Hub, showcasing its various outlets and ports for charging electronics.

- Plug your devices into the available AC outlets, USB-C ports, or USB-A ports.
- Ensure the power strip is connected to a wall outlet.

## 6. MAINTENANCE

---

Regular maintenance ensures the longevity and optimal performance of your desk frame.

- **Cleaning:** Wipe down the desk frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cable Management:** Periodically check and reorganize cables to prevent tangles and damage.
- **Fasteners:** Ensure all screws and fasteners remain tight. Retighten if necessary.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 225 lbs.

## 7. TROUBLESHOOTING

---

If you encounter issues with your desk frame, try the following common troubleshooting steps:

- **Desk Not Moving:** Check all power connections. Ensure the power cord is securely plugged into both the desk and the wall outlet.
- **Error Code on Display:** Refer to your physical manual for specific error code meanings and solutions. Often, a simple power cycle (unplugging and replugging) can resolve minor issues.
- **Uneven Movement:** Ensure the desk is on a level surface and that the weight is evenly distributed.
- **Noise:** A slight hum during operation is normal. Excessive or unusual noise may indicate a loose component; check fasteners.

If problems persist, please contact TOPSKY customer support.

## 8. SPECIFICATIONS

---

Feature	Specification
Model Number	DF02.01
Brand	TOPSKY
Height Adjustment Range	27.6" - 47.3" (70 - 120 cm)

Feature	Specification
Frame Width Adjustment	43" - 59" (108.8 - 150 cm)
Maximum Weight Capacity	225 lbs
Motor Type	Dual Motor
Compatible Tabletop Sizes	Up to 70.8" x 31.5"
Included Components	Dual Motor Lift System, LCD Display, CPU Holder, Power Outlet, Cable Management
Material Type	Alloy Steel
Color	Black

## 9. WARRANTY AND SUPPORT

---

TOPSKY is committed to providing quality products and customer satisfaction.

### 9.1. Return Policy

This product is eligible for returns within 30 days of purchase, subject to the retailer's return policy.

### 9.2. Customer Support

For any questions, assistance, or warranty claims, please contact TOPSKY customer support. Our team is available to help you with product inquiries, troubleshooting, and parts replacement.

**Phone Call Hours:** Monday - Friday, 9:00 AM - 4:00 PM PST

**Email Support:** 7 days a week, 24 hours a day

Please visit the official TOPSKY Amazon Shop Page or website to find our email and other contact information.



Image: TOPSKY brand logo.