

Aroepurt BMAX I10 Plus 10.1 inch Tablet Case

Aroepurt BMAX I10 Plus 10.1 inch Tablet Case User Manual

Model: BMAX I10 Plus 10.1 inch Tablet Case

1. INTRODUCTION

This manual provides essential instructions for the proper use and care of your Aroepurt Tablet Case, designed for the BMAX I10 Plus 10.1 inch tablet. This case offers comprehensive protection and enhanced functionality through its 360-degree rotating support and hardened edge protection.

2. WHAT'S IN THE BOX

- 1 x Aroepurt Tablet Case Cover

3. SETUP AND INSTALLATION

Follow these steps to properly install your BMAX I10 Plus 10.1 inch tablet into the case:

- 1. Prepare the Tablet:** Ensure your tablet is clean and free of debris before insertion.
- 2. Align the Tablet:** Gently align your BMAX I10 Plus 10.1 inch tablet with the case's frame. The case is designed to fit the specific dimensions of your tablet.
- 3. Secure the Tablet:** Carefully press the tablet into the case, ensuring all corners and edges are securely seated within the protective frame. The flexible straps at the corners will hold the tablet firmly.
- 4. Check Camera Alignment:** Verify that the tablet's rear camera aligns with the pre-cut opening on the back of the case. The case features multiple pre-cut openings to accommodate various camera positions, supporting 99% of camera usage scenarios.
- 5. Confirm Port Access:** Ensure all ports, speakers, and buttons are accessible and functional. The case is designed with precise cutouts for unhindered access.

COMPATIBLE WITH A LOT OF TABLET


Please kindly check your tablet size before purchase as shown



Image: Demonstrates how to check tablet size compatibility and secure the tablet within the case.

ALL-OVER- PROTECTION

Goes into every side & corner,



Device ports, speakers,
buttons all work
fine



Slim & Lightweight



It can protect the
plate very well

Image: Illustrates the case's comprehensive protection, including access to device ports, speakers, and buttons, along with its slim and lightweight design.

4. OPERATING INSTRUCTIONS

Your Aroepurt tablet case offers versatile functionality to enhance your tablet experience:

4.1. Using the 360-Degree Rotating Stand

The integrated 360-degree rotating mechanism allows you to position your tablet in both portrait and landscape orientations, providing optimal viewing angles for various activities.

- 1. Rotate the Tablet:** Gently rotate the tablet within its frame to switch between portrait and landscape modes. The mechanism is designed for smooth rotation.
- 2. Engage the Stand:** Fold the front cover backward to form a triangular stand. The anti-slip strip on the interior of the cover helps secure the tablet in your desired viewing angle.
- 3. Adjust Viewing Angle:** Utilize the multiple grooves on the anti-slip strip to adjust the tablet to various viewing angles for comfortable use, whether watching videos, typing, or browsing.

ADJUSTABLE MULTIPLE ANGLES

Supports multiple viewing angles with 360° free rotate



Image: Shows the 360-degree rotation feature and how to set up the case for multiple viewing angles.

MULTIPLE VIEWING

It turns into a convenient stand.
Frees your hands and gives you a
best viewiing angle.



Image: Illustrates the case in stand configuration, emphasizing the anti-slip stripe for secure positioning.

4.2. Important Notes

- **No Auto-Sleep/Wake Function:** This case does not support the automatic sleep/wake function for any tablets. You will need to manually lock/unlock your tablet.
- **No Keyboard Storage:** This case does not include a dedicated storage design for a keyboard.

5. MAINTENANCE AND CARE

To ensure the longevity and appearance of your tablet case, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior of the case with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Interior Care:** The soft anti-slip interior should be kept free of dust and debris to prevent scratches on your tablet. Use a dry, soft cloth to gently clean the interior.
- **Avoid Extreme Conditions:** Do not expose the case to extreme temperatures, direct sunlight for prolonged periods, or excessive moisture, as this may affect the material's integrity.
- **Handling:** While the case offers hardened edge protection, avoid unnecessary drops or impacts to

maximize its protective capabilities.

6. TROUBLESHOOTING

If you encounter any issues with your tablet case, please refer to the following common solutions:

- **Tablet Does Not Fit:** Double-check that your tablet is indeed the BMAX I10 Plus 10.1 inch model. This case is specifically designed for this model. Ensure the tablet is aligned correctly before attempting to secure it.
- **Stand Instability:** Ensure the front cover is folded correctly into a triangular shape and that the tablet is resting firmly in one of the anti-slip grooves. Uneven surfaces can also affect stability.
- **Camera Obstruction:** While the case has multiple cutouts, ensure your tablet's camera is aligned with one of them. If not, re-adjust the tablet's position within the case.
- **Ports/Buttons Blocked:** Verify that the tablet is fully seated and aligned. If a port or button is blocked, gently adjust the tablet's position.

7. SPECIFICATIONS

Feature	Detail
Brand	Aroepurt
Compatible Devices	BMAX I10 Plus 10.1"
Product Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	2.46 ounces
Form Factor	Flip Case
Shell Type	Hybrid
Special Features	Curated Art Patterns, Thickened anti-drop corner protector + folding stand, Two-mode support standing

8. WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. For specific warranty details, return policies, or technical support, please refer to the seller's information on the purchase platform or contact Aroepurt customer service directly.

Please retain your proof of purchase for any warranty claims.

