

Aroepurt DYPB-3644

Aroepurt Case for MEIZE D138 Tablet

Model: DYPB-3644

INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your Aroepurt Case for the MEIZE D138 Tablet. This case is designed to offer comprehensive protection and enhanced functionality, including 360-degree rotating support and hardened edge protection against drops. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.

PACKAGE CONTENTS

- 1 x Aroepurt Tablet Case Cover

SETUP: INSTALLING YOUR TABLET

Follow these steps to correctly install your MEIZE D138 tablet into the Aroepurt case:

1. Ensure your MEIZE D138 tablet is clean and free of dust or debris.
2. Carefully align your tablet with the case's internal frame. The case is designed to fit the MEIZE D138 precisely.
3. Gently press the tablet into the case, ensuring all corners and edges are securely seated within the protective frame. The hardened edges provide enhanced drop protection.
4. Verify that all device ports, speakers, and buttons are accessible and functional through the case's precise cutouts. The pre-cut opening for the rear camera supports 99% of camera usage scenarios.

COMPATIBLE WITH A LOT OF TABLET

Please kindly check your tablet size before nurchase as shown



Image: Demonstrates the tablet fitting securely into the case, ensuring compatibility and proper alignment.

ALL-OVER- PROTECTION

Goes into every side & corner,



Device ports, speakers,
buttons all work
fine



Slim & Lightweight



It can protect the
plate very well

Image: Illustrates the comprehensive protection provided by the case, including access to ports and reinforced corners.

OPERATING INSTRUCTIONS

360-Degree Rotating Support

The case features a built-in mechanism that allows your tablet to rotate 360 degrees, providing versatile viewing options. To use this feature:

1. Open the front cover of the case.
2. Locate the rotating disc on the back of the tablet holder.
3. Gently rotate the tablet to your desired orientation (portrait or landscape).

SUITABLE FOR DIFFERENT PLATES

The 3 pre-cutouts can be used by tablets with different camera positions



Image: Shows the tablet rotating within the case to achieve various viewing angles.

Multiple Viewing Angles with Anti-slip Strip

The case includes an anti-slip strip design that allows you to prop up your tablet at various stable viewing angles:

1. Fold the front cover backward to form a triangular stand.
2. Place the edge of your tablet into one of the anti-slip grooves on the inside of the front cover.
3. Adjust the angle by selecting a different groove for optimal viewing.

MULTIPLE VIEWING

It turns into a convenient stand.
Frees your hands and gives you a
best viewing angle.



Image: Depicts the case folded into a stand, utilizing the anti-slip strip for stable viewing.

MAINTENANCE

To maintain the appearance and protective qualities of your Aroepurt tablet case:

- **Cleaning:** Wipe the exterior with a soft, damp cloth. For stubborn dirt, use a mild soap solution and then wipe clean with a dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the case in a cool, dry place away from direct sunlight when not in use for extended periods.
- **Avoid Extreme Conditions:** Do not expose the case to extreme temperatures or prolonged moisture, as this may affect the material's integrity.

TROUBLESHOOTING

This section addresses common questions and limitations of the Aroepurt tablet case:

- **Auto-Sleep/Wake Function:** This case does not support the auto-sleep/wake function for any tablets. You will need to manually lock/unlock your tablet.

- **Keyboard Storage:** This case lacks a dedicated keyboard storage design.
- **Camera Access:** The case features a pre-cut opening for the rear camera, supporting 99% of camera usage scenarios. In rare instances, specific tablet models or camera placements might have minor obstructions.

SPECIFICATIONS

Feature	Detail
Brand	Aroepurt
Model Number	DYPB-3644
Compatible Devices	MEIZE D138
Form Factor	Flip Case
Shell Type	Hybrid
Material	Polyurethane
Additional Features	360-Degree Rotating Support, Hardened Edge Protection, Anti-slip strip, Curated Art Patterns
Item Dimensions	0.39 x 0.39 x 0.39 inches (Packaging)

WARRANTY & SUPPORT

Aroepurt stands behind the quality of its products. For any questions, concerns, or support needs regarding your tablet case, please contact your retailer or the manufacturer directly through their official support channels. Please retain your proof of purchase for warranty claims.

© 2026 Aroepurt. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question