

[Manuals.plus](#) /

› [Wentronic](#) /

› Wentronic Y01 Wireless Noise Canceling Headphones User Manual

Wentronic Y01

Wentronic Y01 Wireless Noise Canceling Headphones User Manual

Model: Y01 | Brand: Wentronic

INTRODUCTION

Thank you for choosing the Wentronic Y01 Wireless Noise Canceling Headphones. These headphones are designed to provide an immersive audio experience with advanced active noise cancellation, high-fidelity sound, and comfortable wear. This manual will guide you through the setup, operation, and maintenance of your new headphones.



Image: The Wentronic Y01 Wireless Noise Canceling Headphones in pink, showcasing their sleek design.

PACKAGE CONTENTS

Please check the box to ensure all items are present:

- 1 x Wentronic Y01 Wireless Noise Canceling Headphones
- 1 x USB-C Charging Cable
- 1 x 3.5mm Audio Cable
- 1 x User Manual (this document)

In the box

Y01 ANC wireless headphones

USB-C charging cable

3.5mm audio cable

User manual




Image: A visual representation of all items included in the Wentronic Y01 headphone package.

PRODUCT OVERVIEW

Familiarize yourself with the various parts and controls of your Wentronic Y01 headphones.

Headphone Components

- **Adjustable Headband:** For a comfortable and secure fit.
- **Soft Protein Leather Earcups:** With memory foam cushioning for extended wear.
- **Control Buttons:** Located on the earcup for easy access to functions.
- **3.5mm Audio Jack:** For wired connection.
- **USB-C Charging Port:** For charging the headphones.
- **Built-in Microphone:** For hands-free calls.



Image: A close-up view of the right earcup, highlighting the volume, multi-function, and ANC control buttons.

Immersive Thumping Bass

40mm high-quality diaphragms improve resolution and detail, delivering immersive sound with deep, punchy bass and clear, vibrant highs.



Image: The bottom of the earcup, showing the USB-C charging port and the 3.5mm audio jack.

SETUP

1. Charging the Headphones

Before first use, fully charge your headphones. A full charge takes approximately 2 hours.

1. Connect the USB-C charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status (e.g., red for charging, blue for fully charged).

2. Power On/Off

- **To Power On:** Press and hold the Power button for 3 seconds until the LED indicator flashes blue.
- **To Power Off:** Press and hold the Power button for 3 seconds until the LED indicator turns off.

3. Bluetooth Pairing

The Wentronic Y01 headphones use Bluetooth 5.3 for a stable wireless connection.

1. Ensure the headphones are powered off.
2. Press and hold the Power button for 5 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "Wentronic Y01" from the list.
5. Once connected, the LED indicator will flash blue slowly.

Multipoint Connection

The headphones support connecting to two Bluetooth devices simultaneously.

1. Pair the headphones with the first device as described above.
2. Disable Bluetooth on the first device. The headphones will re-enter pairing mode.
3. Pair the headphones with the second device.
4. Re-enable Bluetooth on the first device. The headphones should automatically connect to both devices.
5. You can now switch between audio sources by pausing playback on one device and starting it on the other.

4. Wired Connection

Use the included 3.5mm audio cable for a wired connection, especially when the battery is low or for devices without Bluetooth.

- Plug one end of the 3.5mm audio cable into the headphone's audio jack.
- Plug the other end into your audio source's 3.5mm port.
- The headphones will automatically switch to wired mode.

OPERATING INSTRUCTIONS

1. Button Controls

Button	Function
Power Button (Long Press)	Power On/Off, Enter Pairing Mode
Multi-function Button (Short Press)	Play/Pause Music, Answer/End Call
Multi-function Button (Long Press)	Reject Call, Activate Voice Assistant
Volume Up (+)	Increase Volume (Short Press), Next Track (Long Press)
Volume Down (-)	Decrease Volume (Short Press), Previous Track (Long Press)
ANC Button	Toggle Active Noise Cancellation On/Off

2. Active Noise Cancellation (ANC)

The ANC feature reduces ambient noise for a more focused listening experience.

- Press the dedicated ANC button to activate or deactivate the noise cancellation function.

- An indicator light or voice prompt may confirm the status change.



Image: A visual representation of how active noise cancellation works to block out external sounds.

3. Making and Receiving Calls

When connected via Bluetooth, you can manage calls directly from your headphones.

- **Answer Call:** Short press the Multi-function button.
- **End Call:** Short press the Multi-function button during a call.
- **Reject Call:** Long press the Multi-function button when a call comes in.

MAINTENANCE

Proper care will extend the life of your headphones.

- **Cleaning:** Use a soft, dry cloth to wipe the earcups and headband. Do not use harsh chemicals or abrasive materials.
 - **Storage:** When not in use, store the headphones in a cool, dry place. The foldable design allows for compact storage.
 - **Avoid Moisture:** These headphones are not water-resistant. Avoid exposure to water or excessive humidity.
 - **Battery Care:** For optimal battery life, avoid fully discharging the headphones frequently. Charge them regularly.
-

Cloud-soft Leather Ear Cushions

Ergonomically designed leather ear cushions, cloud-soft and breathable for all-day comfort.




Image: The Wentronic Y01 headphones folded for compact storage and portability.

TROUBLESHOOTING

If you encounter any issues, refer to the solutions below:

Problem	Solution
Headphones won't power on.	Ensure the headphones are fully charged. Connect them to a power source using the USB-C cable.

Problem	Solution
Cannot pair with device.	Make sure headphones are in pairing mode (LED flashing red/blue). Ensure Bluetooth is enabled on your device and it's within range. Forget previous pairings on your device and try again.
No sound or low volume.	Check volume levels on both headphones and your connected device. Ensure the headphones are properly paired or the 3.5mm cable is securely connected.
Active Noise Cancellation (ANC) not working effectively.	Ensure the ANC feature is activated. Adjust the headphones for a snug fit over your ears to maximize noise isolation.
Poor call quality.	Ensure you are in an area with good Bluetooth signal. Check for obstructions between the headphones and your device.

SPECIFICATIONS

Key technical details of the Wentronic Y01 Wireless Noise Canceling Headphones:

- **Model:** Y01
- **Connectivity:** Bluetooth 5.3, 3.5mm Audio Jack
- **Driver Size:** 40mm Dynamic Drivers
- **Frequency Range:** 20 Hz - 40 kHz
- **Noise Control:** Active Noise Cancellation (ANC)
- **Battery Life:** Up to 48 hours (playback)
- **Charging Time:** Approximately 2 hours
- **Microphone:** Built-in for hands-free calls
- **Features:** Foldable Design, Adjustable Headband, Multipoint Pairing
- **Earcup Material:** Protein Leather



48
hours
of Listening time

Non-stop music, less time charging

Keep the music going non-stop for 48.
No need to worry about running out of Power
your soundtrack lasts as long as you do.

Image: Illustration highlighting the 48-hour battery life of the Wentronic Y01 headphones.

WARRANTY AND SUPPORT

The Wentronic Y01 Wireless Noise Canceling Headphones come with a 1-year warranty from the date of purchase. For warranty claims, technical support, or any questions not covered in this manual, please contact Wentronic customer service. Refer to the product packaging or the official Wentronic website for contact information.

