

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Aerogogo](#) /

› [Aerogogo GIGA Pump 4 Mini Air Pump 4.2kPa with Camping Lantern User Manual](#)

Aerogogo GP4FBAB

Aerogogo GIGA Pump 4 Mini Air Pump 4.2kPa with Camping Lantern User Manual

Model: GP4FBAB | Brand: Aerogogo

INTRODUCTION

The Aerogogo GIGA Pump 4 Mini Air Pump is a compact, multi-functional device designed for inflating and deflating various items, as well as providing illumination. This manual provides detailed instructions for its safe and efficient use.

PACKAGE CONTENTS

- Aerogogo GIGA Pump 4 Mini Air Pump
- 5 Different Air Nozzles
- USB-C Charging Cable
- Storage Pouch
- User Manual (this document)



Image: Aerogogo GIGA Pump 4 Mini Air Pump and its various accessories.

PRODUCT FEATURES

- **Ultra-light and Compact:** Weighs approximately 3.5 ounces (100g), making it highly portable.
- **High Pressure & Airflow:** Delivers 4.2kPa pressure and 220 L/min airflow for efficient inflation and deflation.
- **3-in-1 Functionality:** Serves as an air pump (inflation/deflation), vacuum pump, and camping lantern.
- **Integrated Camping Lantern:** Features 8 LEDs with 3 adjustable brightness levels (40lm, 160lm, 400lm).
- **Versatile Nozzles:** Includes 5 different nozzles to fit various inflatable products.
- **Rechargeable Battery:** Equipped with a Type-C charging port and a low battery indicator.
- **Durable Design:** IPX4 waterproof rating, concealed hook, and magnetic design for convenient use.

Ultra-light 3-in-1 Versatile Mini Air Pump

4.2kPa
High-Pressure



220L/Min
Airflow



 Inflation&Vacuum&Lantern



 3 Levels Camping Light



 Concealed Hook & Magnetic Design

 IPX4 Waterproof



Image: Key features of the GIGA Pump 4, including its compact size, pressure, and airflow capabilities.

SETUP

- Charge the Device:** Before first use, fully charge the GIGA Pump 4 using the provided USB-C cable. The indicator light will show charging status.
- Select Appropriate Nozzle:** Identify the correct nozzle from the 5 included options that matches the valve of the item you intend to inflate or deflate.
- Attach Nozzle:** Securely attach the selected nozzle to either the inflation port (for blowing air out) or the deflation port (for sucking air in) of the pump.

5 Different Air Nozzles

Applicable Scenarios Of The Product

Unit:inch



Not Suitable for These Products



Image: Various nozzles included with the GIGA Pump 4 for different inflation/deflation needs.

OPERATING INSTRUCTIONS

1. Inflation

1. Attach the appropriate nozzle to the inflation port (top of the pump).
2. Insert the nozzle firmly into the valve of the item to be inflated.
3. Double-click the power button to start inflation. The pump has two gear pressure modes.
4. Monitor the inflation process and double-click the power button again to stop once the desired firmness is reached.

4.2kPa High-Pressure & 220L/Min Airflow

Small Sleek and Powerful

4.2 kPa

220 L/Min

Inflation

Vacuum

Lantern

Magnetic absorption

Image: The GIGA Pump 4 in use, inflating an air mattress.

2. Deflation (Vacuum Storage)

1. Attach the appropriate nozzle to the deflation port (bottom of the pump).
2. Insert the nozzle firmly into the valve of the item to be deflated (e.g., a vacuum storage bag).
3. Double-click the power button to start deflation.
4. Allow the pump to extract air until the item is fully deflated. Double-click the power button to stop.

4.2kPa High-Pressure & 220L/Min Airflow

Small Sleek and Powerful





Inflation

Vacuum

Lantern

Magnetic absorption

Image: The GIGA Pump 4 in use, deflating a vacuum storage bag.

3. Camping Lantern

1. Press and hold the light button to turn on the lantern.
2. Press the light button repeatedly to cycle through the 3 brightness levels (40lm, 160lm, 400lm).
3. To turn off the lantern, press and hold the light button again.
4. Utilize the concealed hook or magnetic design to position the lantern as needed.

Easy to Use

Three Level Brightness



Image: The GIGA Pump 4's integrated lantern with adjustable brightness levels.

MAINTENANCE

- Charging:** After receiving the product, charge it initially. For optimal battery life, recharge the air pump every three months to prevent low battery voltage and ensure it remains operational.
- Storage:** Store the pump and all accessories in the provided storage pouch in a cool, dry place when not in use.
- Cleaning:** Wipe the exterior of the pump with a soft, damp cloth. Do not immerse the pump in water.

TROUBLESHOOTING

- Pump Not Turning On:** Ensure the device is charged. The low battery indicator will flash red if power is low.
- Insufficient Airflow/Pressure:** Check that the correct nozzle is securely attached and fully inserted into the item's valve. Ensure the pump is fully charged.
- Lantern Not Working:** Verify the device is charged. Press and hold the light button to activate.

SPECIFICATIONS

| | |
|-------|----------|
| Brand | Aerogogo |
|-------|----------|

| | |
|---------------------------|--|
| Model Name | GP4FBAB |
| Item Weight | 3.5 Ounces (approx. 100g) |
| Product Dimensions | 1.9" L x 1.7" W x 2.3" H (approx. 4.8cm x 4.3cm x 5.8cm) |
| Air Flow Capacity | 220 Liters Per Minute |
| Maximum Pressure | 4.2 Kilopascal |
| Lantern Brightness | 40lm / 160lm / 400lm (3 levels) |
| Charging Port | USB-C |
| Waterproof Rating | IPX4 |

WARRANTY AND SUPPORT

From the moment you purchase your Aerogogo GIGA Pump 4, you are entitled to a **5-year after-sales service** (for the pump only) for non-human-induced quality issues. We are committed to providing top-notch service and support to every customer.

For further assistance or inquiries, please visit the [Aerogogo Store on Amazon](#).