Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GAOMON 81-inch Leather Couch

GAOMON 81-inch Leather Couch Instruction Manual

Model: 81-inch Leather Couch

Introduction

Thank you for choosing the GAOMON 81-inch Leather Couch. This manual provides essential information for the safe assembly, operation, maintenance, and care of your new sofa. Please read these instructions carefully before assembly and retain them for future reference.

Safety Information

- All foam and upholstered surfaces meet flammability standards.
- Keep the sofa away from open flames or high heat sources to prevent fire hazards.
- Supervise children and pets around the sofa to avoid potential entrapment risks or injuries.
- Do not stand on the sofa or use it as a step stool.
- Ensure all components are securely fastened before use.

Package Contents

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Sofa Body (1)
- Sofa Legs (4)
- Throw Pillows (2)
- Hardware Pack (bolts, washers, Allen wrench)



Figure 1: Product Dimensions and Weight Capacity. Please confirm dimensions before assembly.

Setup and Assembly Instructions

Assembly is required for this sofa. All necessary tools are included in the hardware pack.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Attach Legs:** Locate the four sofa legs and the corresponding hardware (bolts, washers). Align each leg with the pre-drilled holes on the underside of the sofa frame. Insert the bolts with washers and tighten them securely using the provided Allen wrench. Do not overtighten.
3. **Position Sofa:** With assistance, carefully turn the sofa upright and place it in its desired location. Ensure all legs are stable and level.
4. **Place Pillows:** Arrange the two included throw pillows for comfort and aesthetic appeal.

For optimal stability, periodically check and retighten all bolts.

Operating Instructions (Usage)

The GAOMON 81-inch Leather Couch is designed for comfortable seating and lounging. Its deep seat and ergonomic back support provide a relaxing experience.

- **Seating:** The sofa is designed to comfortably seat three individuals.
- **Lounging:** The generous 26-inch deep seat allows for extended lounging and relaxation.
- **Ergonomic Support:** The design provides support for your lower back, enhancing comfort during prolonged use.



Figure 2: Ergonomically designed for comfort.




Figure 3: Extra-deep seating for ultimate lounging.

Maintenance and Care

Proper care will extend the life and appearance of your GAOMON leather couch.

- **Cleaning:** For spills or general cleaning, wipe the stain-resistant PU leather with a damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the material.
- **Dusting:** Regularly dust the sofa with a soft, dry cloth.
- **Sunlight Exposure:** Avoid placing the sofa in direct sunlight for prolonged periods, as this can cause fading or

cracking of the leather over time.

- **Sharp Objects:** Keep sharp objects away from the sofa to prevent punctures or tears in the upholstery.



Figure 4: Construction details highlighting durable materials.

Troubleshooting

If you encounter any issues with your GAOMON 81-inch Leather Couch, please refer to the following common solutions:

- **Wobbly Legs:** Ensure all leg attachment bolts are securely tightened. If the floor is uneven, use furniture pads or shims under the legs to stabilize the sofa.
- **Squeaking Noises:** Squeaking can sometimes occur if bolts are loose. Re-tighten all assembly hardware. If the issue persists, contact customer support.
- **Minor Scratches/Marks:** For minor surface marks on PU leather, gently rub with a soft, damp cloth. For deeper scratches, specialized leather repair kits may be available, but consult with customer support before applying any products.

For problems not addressed here, please contact GAOMON customer support.

Specifications

Feature	Detail
Brand	GAOMON
Model	81-inch Leather Couch
Product Dimensions (D x W x H)	81.1" x 31.5" x 28.4"
Item Weight	105.89 Pounds
Seating Capacity	3
Seat Depth	26 inches
Upholstery Fabric Type	PU Leather
Color	Dark Brown
Frame Material Type	Wood
Fill Material	Polyurethane Foam
Cushion Construction	Pocket spring foam with tufted design
Assembly Required	Yes
Includes All Assembly Tools	Yes
Product Care Instructions	Wipe with Damp Cloth
Indoor/Outdoor Usage	Indoor

Warranty Information

The GAOMON 81-inch Leather Couch comes with a**Limited Warranty**. For specific details regarding coverage, duration, and terms, please refer to the warranty card included with your product or contact GAOMON customer support directly.

Customer Support

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact GAOMON customer support. You can typically find contact information on the product packaging, the GAOMON official website, or through your retailer.
Please have your model number (81-inch Leather Couch) and purchase date available when contacting support.

© 2023 GAOMON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FWJQ9F5H

More documents and user manuals: **https://manuals.plus/**