

addlon B0FWJSQZTL

addlon 20-inch Low Profile Flush Mount Ceiling Fan with Dimmable LED Light and Remote

Model: B0FWJSQZTL

Brand: addlon

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your new addlon 20-inch Low Profile Flush Mount Ceiling Fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

IMPORTANT SAFETY INFORMATION

Risk of Electric Shock:

- Before installing this ceiling fan, disconnect the power supply by turning off the circuit breaker.
- All electrical connections must be in accordance with local and National Electric Code (N.E.C.) standards and ANSI/NFPA 70.
- Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Do not alter, re-locate, or remove wiring when nothing goes wrong with the product.
- Double-check all connections and screws to be sure they are tight and correct.
- Verify whether the supply voltage is correct by comparing it with the product information.
- To avoid fire, shock, and serious personal injury, please read the following instructions carefully.

General Safety Precautions:

- Make sure the installation site you choose allows a minimum of 7.5 feet from the fan blades to the floor.
- Ensure the ceiling structure can support the weight of the fan.

- Do not use a dimmer switch or gear switch with this fan. Only a conventional on/off switch is compatible.

PACKAGE CONTENTS

Please check the contents of your package against the list below to ensure all parts are present and undamaged.

- Ceiling Fan Unit (Motor Housing, LED Light Ring, Fan Blades)
- Ceiling Mounted Tray / Bracket
- Remote Control
- Mounting Hardware (Screws, Wire Nuts, Hook)
- User Manual

SETUP AND INSTALLATION

Follow these steps carefully for proper installation. If you are unsure about any step, consult a qualified electrician.

1. Prepare for Installation

1. **Disconnect Power:** Turn off the power at the circuit breaker to prevent electric shock.
2. **Remove Existing Fixture:** If replacing an old fixture, carefully remove it and its mounting bracket.
3. **Remove Ceiling-Mounted Tray:** Detach the ceiling-mounted tray from the fan's motor housing by loosening the screws.

2. Mount the Bracket

Choose a suitable installation method based on your ceiling type. Secure the provided ceiling-mounted tray to the ceiling junction box using the appropriate screws. Ensure it is firmly attached.



Image: Diagram illustrating the installation of the ceiling bracket.

3. Assemble the Fan Frame

1. **Attach Light Ring Segments:** Position the light ring segments properly into the slots on the main fan body, ensuring they are perfectly aligned. Repeat for all segments.
2. **Secure Segments:** Tighten the screws to secure the light ring segments in place.

4. Install Fan Blades

1. **Assemble Blades:** Insert the two blade halves from the top and bottom into the fan hub, ensuring a tight and seamless fit.
2. **Insert into Center Rod:** Insert the assembled fan blade unit into the center rod of the motor housing, making sure it is locked into the slot.
3. **Secure with Cap:** Place the fixing cap over the fan blade and tighten it securely.

5. Wiring and Hanging

1. **Hang Fan Body:** Install the safety hook onto the ceiling bracket and hang the fan body on it for support during wiring.
2. **Connect Wiring:** Connect the white wire from the fan to the neutral wire from the ceiling, and the black wire from the fan to the live wire from the ceiling. Secure connections with wire nuts. Connect the green ground wire to the ground wire from the ceiling.
3. **Secure Fan Body:** Align the slot on the motor housing with the slot on the ceiling-mounted tray, then rotate to lock it securely. Tighten all screws on all sides to firmly attach the fan to the ceiling.

Your browser does not support the video tag.

Video: Step-by-step installation guide for addlon Crystal Ceiling Fan. This video demonstrates the general installation process for a similar addlon ceiling fan model.

Your addlon ceiling fan can be controlled via the included remote control or a mobile application.

Remote Control Functions



Image: Remote control and mobile app interface for controlling the fan and light functions.

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed Adjustment:** Select from 6 fan speeds (levels 1-6) to achieve your desired airflow.
- **Light On/Off:** Control the light independently from the fan.
- **Dimmable LED Light:** Adjust the light brightness from 10% to 100%.
- **Color Temperature Adjustment:** Cycle through 3 color temperatures: 3000K (warm white), 4500K (natural white), and 6000K (cool white).
- **Reversible Motor:** Switch between summer cooling mode (downward airflow) and winter air circulation mode (upward airflow) for year-round comfort.
- **Timer Setting:** Set a 1-hour or 2-hour timer for automatic shutdown.
- **Memory Function:** The fan remembers your last-used settings (light brightness, color temperature, fan speed) when powered on again.

Mobile App Control

Download the dedicated addlon mobile application to control your fan and light settings from your smartphone.

The app offers the same functionalities as the remote control, including fan speed adjustment, light dimming, color temperature selection, and timer settings.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is disconnected before cleaning.
- **Blade Cleaning:** The fan blades are enclosed, reducing dust accumulation. If cleaning is needed, gently wipe the exterior.
- **Tighten Fasteners:** Periodically check all screws and fasteners to ensure they are secure. Loose connections can cause noise or malfunction.

TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power supply; Loose wiring; Remote control battery low	Check circuit breaker; Verify wiring connections; Replace remote control batteries.
Light does not work	No power to light; Loose wiring; LED driver issue	Check power supply; Verify light wiring; Contact customer support if LED driver is suspected.
Remote control not responding	Battery low/dead; Remote not paired; Obstruction between remote and receiver	Replace batteries; Re-pair remote (refer to remote pairing instructions); Remove obstructions.
Excessive noise	Loose mounting screws; Unbalanced fan blades; Obstruction	Tighten all mounting screws; Ensure fan blades are properly seated; Check for any objects interfering with the fan.

SPECIFICATIONS

Feature	Detail
Brand	addlon
Model Number	B0FWJSQZTL

Feature	Detail
Size	20 Inch
Color / Style	White / Crystal
Material	Plastic, Glass
Light Source	LED
Color Temperature	3000K (Warm White) / 4500K (Natural White) / 6000K (Cool White)
Dimmable	10%–100%
Wattage	55 watts
Voltage	110 Volts
Control Method	Remote Control, App
Fan Speeds	6 Levels
Motor Type	Reversible DC Motor
Special Features	Low Noise, Quiet Operation, Timer, Memory Function
Mounting Type	Flush Mount
Item Weight	4.63 Pounds

WARRANTY AND CUSTOMER SUPPORT

addlon stands behind the quality of its products.

- **Motor Warranty:** Enjoy a 10-year warranty on the motor.
- **Parts Warranty:** A 2-year warranty covers other parts of the fan.
- **Customer Support:** 24-hour customer support is available to assist you with any installation or usage questions. Please contact us if your ceiling fan or remote control is damaged or lost.