

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOKSOM](#) /

› [TOKSOM 47.2 inch Modern Lift Top Coffee Table User Manual](#)

TOKSOM 77552

TOKSOM 47.2 inch Modern Lift Top Coffee Table User Manual

Model: 77552

1. INTRODUCTION

Thank you for choosing the TOKSOM 47.2 inch Modern Lift Top Coffee Table. This manual provides important information regarding the safe assembly, operation, and maintenance of your new furniture. Please read it thoroughly before use and retain it for future reference.



The TOKSOM 47.2 inch Modern Lift Top Coffee Table in its closed position, showcasing the natural wood finish and fluted design.

2. SAFETY WARNINGS

- This product has a lift-top mechanism and drawers, which may present pinch points. Always keep hands and fingers away from these areas during operation.
- This product is heavy (approximately 74 pounds) and large (over 4 feet long). To prevent tipping or collapse, ensure it is properly anchored to the floor, especially if it will be used near high-traffic areas or by young children or pets.
- Do not allow children to climb on or play with the coffee table, especially the lift-top mechanism.
- Ensure all screws and fasteners are securely tightened before use and periodically check for looseness.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Tabletop panels (including lift-top section)
- Side panels with fluted design
- Bottom panel
- Legs (4x)
- Drawer components (fronts, sides, backs, bottoms)
- Lift mechanism hardware (2x)
- Drawer slides (4x)
- Handles (2x)
- Assembly hardware (screws, dowels, cam locks, etc.)
- Assembly instructions (separate document, if provided)

4. INITIAL SETUP AND ASSEMBLY

While the coffee table is designed for straightforward assembly, careful attention to the instructions is recommended. It is advisable to have a second person assist with certain steps, especially when handling larger components or the lift mechanism.

Tools Required:

- Allen Key (often included)
- Phillips Head Screwdriver

Assembly Steps (General Guidance):

1. **Unpack and Identify:** Carefully unpack all components and hardware. Lay them out on a soft, clean surface to prevent scratches. Refer to the parts list to ensure everything is present.
2. **Assemble the Base Structure:** Connect the side panels to the bottom panel using the provided hardware. Ensure all connections are secure.
3. **Attach the Legs:** Securely fasten the four legs to the bottom of the assembled base.
4. **Install Drawer Slides:** Attach the drawer slides to the interior of the table's frame and to the drawer boxes according to the instructions.
5. **Assemble Drawers:** Construct the two storage drawers, ensuring they are square and sturdy. Attach the handles to the drawer fronts.
6. **Install Lift Mechanism:** Carefully attach the metal lift mechanisms to the designated areas on the table frame and the lift-top panel. This step often requires precise alignment and may benefit from a second person.
7. **Attach Tabletop Panels:** Secure the fixed tabletop panels and the lift-top panel to the frame. Test the lift mechanism for smooth operation.
8. **Insert Drawers:** Slide the assembled drawers into their respective compartments.

Note: Some users have reported that assembly can be challenging. Pay close attention to the provided diagrams and ensure all parts are correctly oriented before tightening screws. Do not overtighten screws to avoid damaging the wood.

5. OPERATING INSTRUCTIONS

5.1 Lift-Top Function

The coffee table features a pneumatic lift-top mechanism, allowing you to raise a portion of the tabletop to a more ergonomic height for working, dining, or other activities.

- **To Raise:** Gently pull the designated section of the tabletop upwards. The pneumatic struts will assist in a smooth and controlled lift. Ensure there are no obstructions or hands near the mechanism during operation.
- **To Lower:** Apply gentle downward pressure on the raised tabletop section. The pneumatic struts will allow it to descend smoothly and quietly back into its closed position. Again, ensure hands and fingers are clear of pinch points.



This image demonstrates the lift-top mechanism in its raised position, providing a convenient surface for work or dining. The hidden compartment and side drawers are shown open, illustrating the ample storage capacity for various items.



Classic Wood Grain



Scratch-resistant



Waterproof

The lift-top feature allows the table to be used as a comfortable workstation for a laptop, bringing the surface closer to the user while seated on a sofa.



A detailed view of the robust metal lifting mechanism, equipped with pneumatic struts, designed for smooth and quiet operation of the lift-top.

5.2 Hidden Storage Compartment

Beneath the lift-top section, a large hidden compartment is available for storing various items, helping to keep your living area tidy.

- To access, simply raise the lift-top as described above.
- Store items such as blankets, books, laptops, or game controllers within this compartment.

5.3 Storage Drawers

The coffee table includes two large storage drawers located beneath the tabletop, providing additional space for organization.

- Gently pull the metal handles to open the drawers.
- Push firmly to close them completely.
- These drawers are suitable for entertainment essentials, toys, snacks, and other small items.



This image highlights one of the two large storage drawers, featuring smooth metal hanging rails and handles for easy access to stored items.

6. MAINTENANCE

Proper care will ensure the longevity and appearance of your TOKSOM coffee table.

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or furniture polish that may damage the finish.
- **Spills:** Although the table surface is designed to be waterproof, promptly wipe up any spills to prevent potential damage or staining.
- **Protection:** Avoid placing hot items directly on the surface; use coasters or placemats. Protect the table from direct sunlight and extreme temperature changes to prevent warping or fading.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.




The image shows water beading on the table's surface, indicating its waterproof and scratch-resistant properties, which simplify cleaning and maintenance.

7. TROUBLESHOOTING

- **Wobbly Table:** Ensure all leg and frame connections are securely tightened. If the floor is uneven, consider using furniture pads or shims under the legs.
- **Drawers Not Sliding Smoothly:** Check that the drawer slides are correctly installed and free of obstructions. Ensure the drawers are assembled squarely. A small amount of silicone lubricant can be applied to the slides if needed.
- **Lift Mechanism Not Operating Smoothly:** Verify that the mechanism is free of debris and that all attachment points are secure. Do not force the lift-top. If issues persist, contact customer support.
- **Missing or Damaged Parts:** If you discover any missing or damaged components during unpacking or assembly, do not proceed with assembly. Contact TOKSOM customer support immediately for assistance.

8. SPECIFICATIONS



Robotic vacuum friendly

A detailed diagram illustrating the overall dimensions of the coffee table, including depth, width, and height, as well as the extended height of the lift-top.

Feature	Specification
Brand	TOKSOM
Model Number	77552
Product Dimensions (D x W x H)	22.04" x 47.24" x 17.71" (56cm x 120cm x 45cm)
Item Weight	74 Pounds (approx. 33.5 kg)
Frame Material	Engineered Wood
Top Material	Engineered Wood
Color	Natural
Furniture Finish	Walnut (finish color)
Number of Drawers	2
Handle Material	Metal
Indoor/Outdoor Usage	Indoor
Assembly Required	Yes (minimal, tools recommended: Allen Key, Screw Driver)

9. WARRANTY INFORMATION

TOKSOM products are manufactured to high-quality standards. For specific warranty details regarding your coffee table, please refer to the warranty card included with your purchase or contact TOKSOM customer support. Keep your proof of purchase for any warranty claims.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or encounter any issues with your TOKSOM coffee table, please contact our customer support team. Refer to the contact information provided with your product or visit the official TOKSOM website for support options.

Online Support: [Visit the TOKSOM Store on Amazon](#)

