

Vonaural E11 Active Noise Cancelling Headphones

Vonaural E11 Hybrid Active Noise Cancelling Headphones User Manual

MODEL: E11 ACTIVE NOISE CANCELLING HEADPHONES

Introduction

Thank you for choosing the Vonaural E11 Hybrid Active Noise Cancelling Headphones. These headphones are designed to provide a superior audio experience with advanced noise cancellation, comfortable fit, and reliable wireless performance. This manual will guide you through the setup, operation, and maintenance of your new headphones.

Safety Information

- Do not expose the headphones to extreme temperatures, humidity, or corrosive substances.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not disassemble or modify the headphones. This may void the warranty and cause damage.
- Clean the headphones with a soft, dry cloth. Do not use liquid cleaners.
- Adjust volume to a moderate level to prevent hearing damage. Prolonged exposure to loud sounds can cause permanent hearing loss.

Package Contents

Please check the package for the following items:

- Vonaural E11 Hybrid Active Noise Cancelling Headphones
- USB-C Charging Cable
- 3.5mm Audio Cable
- User Manual (this document)

Product Overview

Familiarize yourself with the components and controls of your Vonaural E11 headphones.



Image: The Vonaural E11 Hybrid Active Noise Cancelling Headphones, showcasing their sleek black design and over-ear form factor.

EASY Button Functionality

Master your audio experience perfectly

- UP VOLUME BUTTON**
Quick Press X1: Volume Up
Long Press: Previous Song
- MULTIFUNCTIONAL BUTTON**
Long Press: Power On/Off
Short Press: Play/ Pause, Answer/ Hang Up
- DOWN VOLUME BUTTON**
Quick Press X1: Volume Down
Long Press: Next Song
- Ambient Sound Mode & ANC Toggle**

Image: A detailed diagram illustrating the button layout and functions on the Vonaural E11 headphones, including volume controls, power button, and ANC/Ambient Sound toggle.

Key Features:

- **Hybrid Active Noise Cancellation:** Reduces ambient noise for immersive listening.
- **Hi-Fi Stereo Sound:** Equipped with 40mm dynamic drivers for clear highs, balanced mids, and deep bass.
- **Crystal Clear Hands-free Calls:** Built-in microphones with noise reduction technology.
- **All-Day Comfort:** Ultra-soft ear cushions and an adjustable headband for extended wear.
- **Long-Lasting Playtime:** Up to 35 hours of playtime on a single charge.
- **Bluetooth 5.0 Technology:** Provides a stable and efficient wireless connection.

Setup

1. Charging the Headphones

Before first use, fully charge your headphones. Connect the provided USB-C charging cable to the charging port on the headphones and the other end to a USB power source (e.g., computer, wall adapter). The LED indicator will show charging status and turn off when fully charged.

2. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "Vonaural E11" from the list of devices.
5. Once connected, the LED indicator will flash blue slowly.



Image: A visual representation of the Bluetooth pairing process, showing the headphones connecting to a smartphone with "E11 Connected" displayed.



Image: The Vonaural E11 headphones positioned among a smartphone, laptop, and tablet, illustrating their wide compatibility with various Bluetooth-enabled devices.

Operating Instructions

Power On/Off

- **Power On:** Press and hold the Power button for 3 seconds. The LED indicator will flash blue.
- **Power Off:** Press and hold the Power button for 3 seconds. The LED indicator will turn off.

Volume Control

- **Volume Up:** Short press the '+' button.
- **Volume Down:** Short press the '-' button.

Music Playback

- **Play/Pause:** Short press the Multifunction button.
- **Next Track:** Long press the '-' button.
- **Previous Track:** Long press the '+' button.

Call Management

- **Answer/End Call:** Short press the Multifunction button.
- **Reject Call:** Long press the Multifunction button.

Active Noise Cancellation (ANC) & Ambient Sound Mode

The Vonaural E11 headphones feature Hybrid Active Noise Cancellation and an Ambient Sound Mode.

- **Toggle Modes:** Press the dedicated ANC button to cycle through ANC On, Ambient Sound Mode, and ANC Off.




Image: A person wearing the Vonaural E11 headphones, illustrating the effectiveness of Active Noise Cancellation in reducing external distractions.




Image: A person wearing the Vonaural E11 headphones, demonstrating the Ambient Sound Mode which allows awareness of surroundings while listening to audio.

Maintenance

Cleaning

Gently wipe the earcups and headband with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or chemical solvents. Ensure no moisture enters the headphone openings.

Storage

When not in use, store the headphones in a cool, dry place away from direct sunlight. The foldable design allows for compact storage. Avoid placing heavy objects on the headphones.

Troubleshooting

Problem	Solution
---------	----------

Problem	Solution
Headphones do not power on	Ensure the headphones are fully charged. Connect to a power source and try again.
Cannot pair with device	Make sure Bluetooth is enabled on your device and the headphones are in pairing mode (flashing blue/red). Try restarting both devices.
No sound or low volume	Check the volume levels on both the headphones and your connected device. Ensure the headphones are properly paired.
ANC not working effectively	Ensure ANC mode is activated. Note that ANC is most effective against low-frequency, constant noise.
Poor call quality	Ensure the headphones are close to your device. Check for environmental interference.

Specifications

Feature	Detail
Model Name	E11 Active Noise Cancelling Headphones
Noise Control	Active Noise Cancellation
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.0
Audio Driver Type	Hybrid Driver
Earpiece Shape	Over-Ear
Battery Life	Up to 35 Hours
Charging Time	Approximately 2-3 Hours (for 35 hours playtime)
Control Method	Touch/Buttons
Item Weight	10.8 ounces
Material	Fabric (ear cushions)
Compatible Devices	Laptops, Desktops, Tablets, Telephones, Smart Speaker, Television, Car Audio Systems, Cellphones

Warranty and Support

Vonaural products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Vonaural website. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Is it possible to completely eliminate external sound with the Vonaural E11 headphones to achieve total silence, and is there an application that allows this?

No, it is not possible to achieve "complete silence" or total elimination of all external sounds with the Vonaural E11 headphones, nor is there a specific application that can provide this result. This is...

[Read full answer](#)