Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOVHEIYL TY-01, TY-02, F-TY65BR-1D01, F-TY65SN-1D01, F-TY65EG-1D01, Y23FSD0045-2801, Y24FSD0003-3801, Y24FSD0003-2801, Y24FSD0001

MOVHEIYL Replacement Remote Control Instruction Manual

For Fanbulous Ceiling Fan Models: TY-01, TY-02, F-TY65BR-1D01, F-TY65SN-1D01, F-TY65EG-1D01, Y23FSD0045-2801, Y24FSD0003-3801, Y24FSD0003-2801, Y24FSD0001-3801

Introduction

This manual provides instructions for the setup, operation, and maintenance of your MOVHEIYL Replacement Remote Control. This remote is designed to be compatible with specific Fanbulous ceiling fan models, offering reliable control over fan speed, light functions, and other features. Please read this manual thoroughly before use to ensure proper functionality and longevity of your device.

Setup

1. Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Ensure correct polarity when inserting batteries.



Figure 1: Battery compartment for two AAA batteries. Ensure correct polarity.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two (2) AAA batteries, matching the positive (+) and negative (-) terminals as indicated inside the compartment.
4. Slide the cover back into place until it clicks securely.

2. Initial Use

This remote control utilizes infrared (IR) technology and typically does not require pairing. Once batteries are installed, point the remote directly at your compatible Fanbulous ceiling fan receiver to operate.

Operating Instructions

The remote control provides various functions for your ceiling fan and light. Familiarize yourself with the button layout and

their respective functions.



Figure 2: Front view of the remote control with key features.

Button Functions:

- **Power Button ( ):** Turns the fan and light on or off.
- **Fan Speed Buttons (1-6, OFF):** Adjusts the fan speed from 1 (lowest) to 6 (highest). "OFF" turns the fan off.
- **Light Control Button ( ):** Toggles the light on or off.
- **Light Brightness Adjustment:** (If applicable, typically long-press light button or separate dimming buttons). The remote supports light brightness control from 5% to 100%.
- **Timer Buttons (1H, 4H, 8H):** Sets the fan to turn off automatically after 1, 4, or 8 hours.
- **Wind Mode Button ( ):** Activates a natural wind mode, varying fan speed to simulate a breeze.
- **Mute Button ( ):** Mutes any audible feedback from the fan (if supported by the fan).



Figure 3: Multi-angle induction and effective range of the remote control.

The remote control offers multi-angle induction and a stable transmission distance of up to 10 meters (approximately 40 feet) without obstruction, ensuring responsive control from various positions within a room.



Figure 4: One remote control can operate multiple compatible ceiling fans.

This remote is designed for ease of use and can operate multiple compatible ceiling fans within its range, making it convenient for homes with several Fanbulous ceiling fans.

Maintenance

1. Battery Replacement

Replace batteries when the remote's range decreases or it becomes unresponsive. Always replace both AAA batteries simultaneously with new ones. Do not mix old and new batteries, or different types of batteries.

2. Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the surface or internal components.

3. Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote and the fan's receiver.
  - Confirm the remote is pointed directly at the fan's receiver.
- **Short transmission distance:**
  - Replace batteries with new ones.
  - Ensure there are no strong light sources or electronic devices interfering with the infrared signal.
  - Reduce the distance between the remote and the fan.
- **Fan or light functions intermittently:**
  - Check battery level.
  - Ensure the remote is within effective range and line of sight.
  - Verify that the fan model is listed as compatible.

Specifications

Brand	MOVHEIYL
Compatible Devices	Fanbulous Ceiling Fans (Models: TY-01, TY-02, F-TY65BR-1D01, F-TY65SN-1D01, F-TY65EG-1D01, Y23FSD0045-2801, Y24FSD0003-3801, Y24FSD0003-2801, Y24FSD0001-3801)
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Maximum Range	10 Meters (approx. 40 feet)
Power Source	2 x AAA Batteries (not included)
Material	High-quality ABS
Color	White
Special Feature	Ergonomic design, 0.2s fast response, Multi-angle induction

Limited Warranty

MOVHEIYL warrants this product against defects in materials and workmanship under normal use for a period from the date of purchase. This warranty does not cover damage caused by accident, misuse, abuse, alteration, or improper battery installation. For warranty claims or support, please contact customer service.

Customer Support

If you encounter any issues or have questions regarding your MOVHEIYL Replacement Remote Control, please do not hesitate to contact our customer support team. We are committed to assisting you with any concerns.

Contact Information:

- **Email:** support@movheiyl.com
- **Website:** www.movheiyl.com/support

Please provide your product model number and a detailed description of the issue when contacting support for faster assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I pair the MOVHEIYL replacement remote control with my Fanbulous ceiling fan?

According to the instruction manual, the MOVHEIYL Replacement Remote Control utilizes infrared (IR) technology and typically does not require pairing. To set up and use the remote, follow these steps: Install Batteries: Open the...

Read full answer

Open the live page

https://manuals.plus/asin/B0FWKD7QYM

More documents and user manuals: **https://manuals.plus/**