MOVHEIYL B0FWKDKTNV

MOVHEIYL Ceiling Fan Replacement Remote Control User Manual

Comprehensive instructions for setup, operation, and maintenance of your MOVHEIYL replacement remote control.

1. Product Overview

This MOVHEIYL replacement remote control is designed to operate various ceiling fan models, offering convenient control over fan speed and light functions. It is compatible with specific models including Acesal ALCF001, ALCF001BB-1, SPEVCH T001-180, Mpayel B7873, B7867, B7869, MYYCX M-CX09A, and AFWAO F033 Ceiling Fans.



Image: The MOVHEIYL remote control shown with a ceiling fan, highlighting its smart and quality control capabilities, including stable link, fast response, easy grip, and power saving.

The remote is constructed from high-quality ABS material, ensuring durability and a comfortable grip. It features an advanced chip for reliable performance and a long lifespan.



Image: A close-up of the MOVHEIYL remote control, detailing its construction from ABS safety materials and an advanced chip for long-lasting use and quality assurance.

2. Specifications

- **Brand:** MOVHEIYL
- **Special Feature:** Ergonomic design
- **Color:** Black
- **Max Number of Supported Devices:** 1 (per pairing)
- **Compatible Devices:** Ceiling Fans (specific models listed in Product Overview)
- **Connectivity Technology:** Infrared
- **Controller Type:** Button Control
- **Maximum Range:** 10 meters
- **Manufacturer:** MOVHEIYL

3. Setup

3.1 Battery Installation

The remote control requires 2 AAA batteries (not included). Ensure correct polarity when inserting the batteries.



Image: The back of the MOVHEIYL remote control with the battery cover removed, indicating the need for 2 AAA batteries and showing the battery orientation.

3.2 Compatibility Note

Important: This replacement remote control is designed to work only with ceiling fans that use a red light indicator for pairing. It is not compatible with systems that use a blue light indicator.

3.3 Pairing Instructions

To pair the remote control with your ceiling fan:

1. Ensure your ceiling fan's power is turned off at the wall switch or circuit breaker.
2. Turn on the power to your ceiling fan.
3. Within 5 seconds of powering on the fan, press and hold the "**PAIRCODE FAN OFF**" button on the remote control.
4. Hold the button until the fan's light flashes twice. This indicates successful pairing.
5. Release the button. Your remote control is now paired and ready for use.




Image: A detailed view of the MOVHEIYL remote control, showing the location of the "PAIRCODE FAN OFF" button, which is essential for the pairing process.

4. Operating Instructions

The MOVHEIYL remote control provides intuitive control over your ceiling fan's functions. The remote offers a maximum operating range of 10 meters and multi-angle induction for stable transmission.



Image: An illustration showing the MOVHEIYL remote control's multi-angle induction capability and effective range of up to 40 feet (approximately 12 meters) for consistent signal transmission to a ceiling fan.

4.1 Button Functions

- **ON/OFF (Light):** Toggles the ceiling fan light on or off.
- **ALL OFF:** Turns off both the fan and the light.
- **Fan Speed Buttons (1-6):** Adjusts the fan speed to one of six levels.
- **PAIRCODE FAN OFF:** Used for pairing the remote with the fan.
- **Light Brightness (+/-):** Increases or decreases the light brightness.
- **Fan Speed (+/-):** Increases or decreases the fan speed incrementally.
- **Fan Mode/Timer (2H):** Activates specific fan modes or sets a 2-hour timer.
- **Wind Mode:** Cycles through different wind simulation modes.



Image: The MOVHEIYL remote control illustrating its compatibility with different environmental settings, offering modes such as 'Gear-Sleep', 'Gear-Library', 'Gear-Chat', and 'Gear-Meeting' for optimized fan operation.

4.2 Controlling Multiple Fans

One MOVHEIYL remote control can be paired with and operate multiple ceiling fans, provided each fan is compatible and successfully paired. This allows for centralized control in different rooms.



Image: An illustration showing the MOVHEIYL remote control being used to operate ceiling fans in different household settings, including a dining room, living room, bedroom, and study room, highlighting its multi-fan control capability.

5. Maintenance

5.1 Battery Replacement

When the remote control's performance degrades or it stops responding, replace the 2 AAA batteries. Ensure to dispose of old batteries responsibly.

5.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

6. Troubleshooting

6.1 Code Clearing Instructions

If you need to clear the existing pairing code from the remote control:

1. Ensure your ceiling fan's power is turned off at the wall switch or circuit breaker.

2. Turn on the power to your ceiling fan.
3. Within 5 seconds of powering on the fan, press and hold the "**NO**/**OFF**" button on the remote control.
4. Hold the button until the fan's light flashes twice. This indicates successful code clearing.
5. Release the button. The remote is now ready to be paired again.

6.2 Common Issues

- **Remote not responding:**
  - Check if batteries are correctly inserted and have sufficient charge. Replace if necessary.
  - Ensure there are no obstructions between the remote and the fan's receiver.
  - Verify that the fan's power is on.
- **Pairing failure:**
  - Confirm that the fan uses a red light indicator for pairing (not blue).
  - Ensure you are pressing the "PAIRCODE FAN OFF" button within 5 seconds of turning on the fan's power.
  - Try clearing the code first (Section 6.1) and then re-attempt pairing.
  - Ensure the remote is within the 10-meter operating range.

7. Warranty and Support

For any questions, concerns, or issues not covered in this manual, please contact MOVHEIYL customer support.
Refer to your purchase documentation for specific warranty details and contact information.
We are committed to helping you resolve any issues you may encounter with your product.