Costzon 6960

Costzon 10-in-1 Toddler Slide Set Instruction Manual

Model: 6960

Introduction | Safety Warnings | Setup & Assembly | Operating Instructions | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

The Costzon 10-in-1 Toddler Slide Set is a versatile indoor playground designed to provide a safe and engaging environment for children aged 3 and above. This playset integrates multiple activities to encourage physical development, creativity, and social interaction.

Key features of this playset include:

- **Telescope:** For imaginative play and exploration.
- **Basketball Hoop:** To develop hand-eye coordination.
- **Peek-a-Boo Window:** Adds an element of discovery.
- **Aisle:** Connects different play areas.
- **Slide:** An extended slide with a waiting, acceleration, deceleration, and buffering area for safe descent.
- **Ring Toss:** Enhances precision and motor skills.
- **Magnetic Whiteboard:** For drawing, writing, and creative expression.
- **Crawling Tunnel:** Promotes exploration and physical activity.
- **Storage Space:** Convenient area for toys and accessories.
- **Climber:** Equipped with side handrails and anti-slip steps for secure climbing.



Figure 1: Overview of the 10-in-1 Toddler Slide Set with all features labeled.

2. Safety Warnings

Please read and understand all safety warnings before assembly and use. Failure to follow these instructions may result in serious injury.

- **Adult Supervision Required:** Always supervise children when they are using the playset.
- **Age Recommendation:** Suitable for children aged 3 years and older.
- **Weight Limit:** Do not exceed the maximum weight recommendation of 55 pounds (25 kg).
- **Proper Assembly:** Ensure all parts are correctly assembled and securely fastened before use. Regularly check for loose bolts or connections.
- **Stable Surface:** Place the playset on a flat, level, and soft surface, such as a carpet or play mat, to prevent tipping and cushion falls.
- **Clearance Area:** Maintain a clear space around the playset, free from obstacles, furniture, or other hazards.
- **Material Safety:** The playset is constructed from BPA-Free HDPE with a burr-free surface and rounded edges to

protect delicate skin.

- **No Climbing on Exterior:** Instruct children not to climb on the exterior frame or non-designated climbing areas.
- **One Child at a Time on Slide/Climber:** Ensure only one child uses the slide or climber at a time to prevent collisions.
- **Footwear:** Encourage children to wear appropriate footwear to prevent slipping.

3. Setup & Assembly

Assembly of the Costzon 10-in-1 Toddler Slide Set typically requires two adults and takes approximately one hour. Please ensure all components are present before beginning assembly.

3.1. Unpacking and Parts Check

Carefully unpack all components from the box. Refer to the included parts list in your package to verify that all pieces are present and undamaged. If any parts are missing or damaged, please contact customer support.



Figure 2: Package contents including accessories.

3.2. Assembly Steps

1. Begin by connecting the main structural panels. Ensure the L-shaped design and triangular structures are correctly aligned for stability.
2. Attach the slide sections, ensuring the waiting, acceleration, deceleration, and buffering areas are in the correct sequence. Secure the raised handrails.
3. Install the climber steps and side handrails, verifying that the anti-slip steps are facing upwards.
4. Assemble the basketball hoop and attach it to the designated area.
5. Integrate the crawling tunnel, peek-a-boo window, and aisle components into the main structure.
6. Attach the magnetic whiteboard and ensure it is securely mounted.
7. Fasten all connections using the provided hardware. Do not overtighten, but ensure a snug fit.
8. Once assembled, gently shake the playset to confirm its stability. Re-check all bolts and connections.




Figure 3: Secure and stable construction details.

4. Operating Instructions

This playset offers multiple activity zones for children. Encourage children to explore each feature safely.

4.1. Using the Slide

Children should sit down at the top of the slide, feet first. Ensure the path is clear before sliding. The extended slide is designed with a waiting area, acceleration area, deceleration area, and buffering area for a smooth and safe descent. Raised handrails provide additional security.



Figure 4: Details of the extended slide design.

4.2. Using the Climber

The climber features anti-slip steps and side handrails. Children should use both hands to grip the handrails while climbing up and down. Ensure they maintain a secure footing on each step.



Figure 5: Child-friendly climber with safety features.

4.3. Basketball Hoop & Ring Toss

Use the included basketball for shooting practice. The ring toss game can be played with the provided rings to improve aim and coordination.

4.4. Magnetic Whiteboard

The magnetic whiteboard allows children to draw and write using the included markers and eraser. Ensure only dry-erase markers are used on the whiteboard surface.

4.5. Crawling Tunnel, Telescope, Peek-a-Boo Window, Aisle, and Storage

These features encourage imaginative play, exploration, and provide additional areas for children to interact within the playset. The storage space can be used to keep toys tidy.

4.6. Folding for Storage

When not in use, the slide component can be folded to save space. Follow the specific folding instructions provided in the assembly manual to ensure proper and safe storage.



Figure 6: The slide can be folded for compact storage.

5. Maintenance

Regular maintenance ensures the longevity and safety of your Costzon 10-in-1 Toddler Slide Set.

- **Cleaning:** Wipe down all surfaces with a damp cloth and mild soap as needed. Avoid abrasive cleaners or solvents that could damage the plastic.
- **Inspection:** Periodically inspect all parts for wear, damage, or loose connections. Pay close attention to bolts, joints, and the integrity of the plastic components.
- **Tighten Fasteners:** Re-tighten any loose bolts or fasteners to maintain structural integrity. Do not overtighten.
- **Storage:** Store the playset in a cool, dry place when not in use for extended periods, especially if used outdoors, to protect it from extreme weather conditions.

6. Troubleshooting

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Playset feels unstable or wobbly.	Loose bolts or uneven surface.	Ensure all bolts are securely tightened. Move the playset to a flat, level surface.
Parts do not fit together during assembly.	Incorrect orientation or mismatched parts.	Refer to the assembly instructions and diagrams. Ensure parts are oriented correctly before attempting to connect them.
Magnetic whiteboard not erasing cleanly.	Non-dry-erase markers used or board needs cleaning.	Use only dry-erase markers. Clean the board with a damp cloth or specialized whiteboard cleaner.

7. Specifications

Detailed specifications for the Costzon 10-in-1 Toddler Slide Set:

- **Brand:** Costzon
- **Model Number:** 6960
- **Material:** High Density Polyethylene (HDPE)
- **Color:** Yellow (as per current variant)
- **Overall Product Dimensions (L x W x H):**67" x 66" x 38" (170 cm x 167 cm x 96 cm)
- **Slide Length:** 60" (152 cm)
- **Slide Width:** 11" (28 cm)
- **Aisle Dimensions (L x W):** 55" x 12.5" (140 cm x 32 cm)
- **Blackboard Dimensions (L x W):** 10" x 9.5" (25 cm x 24 cm)
- **Crawling Tunnel Dimensions (W x H):** 17.5" x 16.5" (44 cm x 42 cm)
- **Basketball Hoop Height:** 27" (69 cm)
- **Item Weight:** 35 pounds (15.9 kg)
- **Maximum Weight Recommendation:** 55 pounds (25 kg)
- **Certifications:** Complies with ASTM and CPSIA standards.



Figure 7: Product dimensions and measurements.

8. Warranty & Customer Support

Costzon products are designed for quality and durability. For specific warranty information regarding your 10-in-1 Toddler Slide Set, please refer to the documentation included with your purchase or visit the official Costzon website.

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact Costzon customer support:

- **Website:** Visit the Costzon Store on Amazon
- **Contact Information:** Please refer to the contact details provided on the product packaging or the official Costzon website for the most up-to-date support options.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question